



See safety datasheet (if applicable) and product label for safety information, handling and proper use.

Directions for Use

PRE-WASH STAIN TREATMENT: Dilute MEDICINAL STAIN REMOVER with water 1:1. Spray directly on fabric stain. Wash fabric through normal cycle. **POST-WASH STAIN TREATMENT:** Add 4-5 ounces of MEDICINAL STAIN REMOVER per gallon of hot water (140-160°F). Allow stained fabric to soak in solution for 20-30 minutes. Wash fabric through normal cycles, do not rinse before laundering. **PRECAUTION:** For colored fabric or unknown fiber content, test on hidden area prior to use.

Medicinal Stain Remover is highly effective for removing a wide range of stains caused by medicinal products. Medicinal Stain Remover is a blend of active solvents and surfactants. It is able to remove difficult stains without harming cotton and synthetic fibers. Phosphate Free. For institutional laundry use only.

Features & Benefits

- Solvent blend
- Contains surfactants
- Ready-to-use formula

Item Number & Unit of Measure

| | |
|-----------------|--------------|
| Item Number | HIL0005706 |
| Unit of Measure | 1 gal Bottle |

Specifications

| | |
|---------------------|-----------------|
| Color | Colorless |
| Dye Free | Yes |
| Appearance | Clear Liquid |
| Fragrance | Solvent |
| Formula Type | Liquid |
| Dilution Ratio | 1:1; 4-5 OZ/GAL |
| PH | 1% 11.3 - 11.9 |
| Non-Volatile Matter | 12.5 - 13.3% |

Safety