

MOTORIZED LEVELING - NEW CONTROLLERS AND HARNESSES

LEVELING AND STABILIZATION

TI-2

Pairing a new harness with an old controller would result in a system with no time delay provision. This would not necessarily be a catastrophic failure, but for optimization of system performance it would be best to make the substitutions as outlined below.

If a customer places an order for the controller, substitute the new controller for the old one. If a customer places an order for the harness only, we will need to send the new controller and the new harness. Basically, the new controllers are compatible with the old harnesses, but the new harnesses are only compatible with the new controls. The table below shows the new part numbers with the part numbers they are replacing.

NOTE: If the controller in question is the 333389 wireless controller, the new controller is not needed, no matter which pump harness is used.

	Controller		Harness	
	New	Old	New	Old
Leveling + Slide	364557	<u>175226</u>	365336	162987
Leveling Only	365150	339485	178373	<u>161400</u>

As a supplier of components to the RV industry, safety, education and customer satisfaction are our primary concerns. Should you have any questions, please do not hesitate to contact us at (574) 537-8900 or by email at <u>customerservice@lci1.com</u>. Self-help tips, technical documents, product videos and a training class schedule are available at <u>www.lci1.com</u> or by downloading the MyLCI app.