

ALLEGRO FIT TEST KITS

Qualitative OSHA-compliant fit testing
to ensure worker safety



ALLEGRO[®]
INDUSTRIES

WALTER
Achieve Greatness[™]

ALLEGRO FIT TEST KITS

Allegro's selection of Fit Test Kits offer qualitative OSHA-compliant fit testing for disposable and reusable tight-fitting particulate respirators. This procedure helps ensure the user has selected the correct size respirator and a proper seal has formed against the wearer's face ensuring their safety in any work environment.

Sweet (Saccharin) & Bitter (Denatonium Benzoate) Fit Test Kits

If the test subject detects either the sweet taste of Saccharin or bitter taste of Denatonium Benzoate, a breakthrough in the respirator seal has occurred and the respirator has failed its fit test.

Kit Contents:

- ▶ Reusable poly-coated test hood w/ surged seams
- ▶ Two nebulizers with labels
- ▶ Two sets of atomizers
- ▶ Wire cleaner
- ▶ Box of sensitivity solutions (6/box)
- ▶ Box of test solutions (6/box)
- ▶ Fit test documentation and instructions



Watch our full instructional video

ORDER NO.	DESCRIPTION
2040	Sweet (Saccharin) Fit Test Kit
2040-11K	Sweet (Saccharin) Sensitivity Solution Only (6/box)
2040-12K	Sweet (Saccharin) Test Solution Only (6/box)
2041	Bitter (Denatonium Benzoate) Fit Test Kit
2041-11K	Bitter (Denatonium Benzoate) Sensitivity Solution Only (6/box)
2041-12K	Bitter (Denatonium Benzoate) Test Solution Only (6/box)

WHEN TO FIT TEST Per OSHA...

- ▶ Fit tests must be performed before employer-mandated use of a tight-fitting respirator
- ▶ Fit testing of employees must occur at least annually
- ▶ Whenever a different size, style, model or make of respirator is used
- ▶ When any physical change occurs to the wearer that could affect respirator fit (i.e.: significant weight fluctuation, dental work, or other facial changes)

FOR MORE INFORMATION, TO SCHEDULE A FREE DEMO OR TO ORDER:

United States:

Email: CustSvc-Allegro@walter.com

Phone: 800-622-3530 | Fax: 800-362-7231

Canada:

Phone: (888) 592-5837 | Fax: (866) 581-1121

Email: csr@walter.com



FEATURES

- ▶ Multiple kit options with different testing agents to determine wearer's taste threshold
- ▶ Convenient, reliable, and economical to use
- ▶ Disposable ampules make pouring solution easier and lowers the risk of contamination
- ▶ Provides a consistent test atmosphere for test exercises
- ▶ Full instructional training video available online to help guide you through the test
- ▶ Ensures worker safety in any work environment
- ▶ Reduces work-related respiratory diseases
- ▶ Provides a consistent test atmosphere for test exercises

Standard & Deluxe Smoke Fit Test Kits

When activated, Stannic Chloride is a white gas with a strong odor that will provoke an involuntary reaction (i.e. coughing) by the test subject indicating a breakthrough in the respirator seal and the fit test has failed.



Standard Fit Test Kit Contents:

- ▶ Vinyl protective pouch
- ▶ Air bulb
- ▶ Poly tubing
- ▶ Breaker tool
- ▶ Smoke tubes (6/box) with rubber caps

Deluxe Fit Test Kit Contents:

- ▶ DC-powered pump
- ▶ Poly tubing
- ▶ Breaker tool
- ▶ Smoke tubes (6/box) with rubber caps

ORDER NO.	DESCRIPTION
2050	Standard Smoke Fit Test Kit
2055	Deluxe Smoke Fit Test Kit
2050-01	Replacement Smoke Tubes (6/box) Used in both kits

Banana Oil (Isoamyl Acetate)

Fit Test Kits also available, contact your local territory manager for full product SKUs.

Available at :

WALTER Surface Technologies Inc. © 2023 All Rights Reserved. WALTER Surface Technologies and ALLEGRO logos are trademarks or registered trademarks of WALTER Surface Technologies Inc. Other company, product or service names may be trademarks or service marks of WALTER Surface Technologies or others. 98-W 089 (02-23)