



CLAX

Magic Rust Reclaim

Effectively removes rust and iron stains on all linen.

Features & Benefits

- Effective on many types of mineral buildup
- Whitens and brightens mineral laden linens
- Reclaims up to 60 pounds of rejected linen
- Proven, highly effective process
- Keeps linens in service longer
- Reduces linen replacement costs and improves overall cost-efficiency

Applications

- For all types of linen





Clax® Magic Rust Reclaim

Use instructions

Up to 60 lbs. Washer to Reclaim Linen:

Programmable Washer Extractors:

- Start high temperature reclaim wash program.
- Dose full content of pouch of Magic Rust Reclaim in the washer.

CAUTION: Do not add any other chemicals!

- Wash for 20 minutes in hot water, then rinse 4 times.
- Allow machine to run full wash cycle.
- After the reclaim cycle, linen should go through a regular short cycle, like a new linen or blankets cycle.

Fixed Timer Washer Extractors:

- Select wash cycle with the longest wash bath without flushes.
- The rest of the steps will be the same as on the Programmable Washer Extractors.

Please contact your Diversey Technical Specialist for further information.

Technical data	Clax® Magic Rust Reclaim
Certifications	None
Color/Form	White powder
pH	1.8 (1% solution)
Scent	Odorless
Shelf Life	2 Years

Product	Pack size	Dilution	Product code
Clax® Magic Rust Reclaim	12 x .5 lb / 227 grams	Ready-to-Use	95955869 

Specific Applications	Recommended
Commercial Washers	Yes
Homestyle Washers	No
Tunnel Washers	No
Use with Ozone	Yes
Low Temperature Wash	Yes
Safe on Microfibers	No

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up-to-date shipping information.