



Bath Mate™/MC

16

Acid-Free Disinfectant Washroom Cleaner Concentrate

Heavy-duty, non-acid washroom cleaner.

Features & Benefits

- Formulated with detergents and solvents that quickly remove soap scum, body oils and lotions
- Deodorizes with a fresh lingering scent that keeps restrooms smelling pleasant
- Non-acid cleaner that works great on heavy soils

Applications

- For daily washroom cleaning in hospitals, motels, hotels, nursing homes, business and industrial buildings, restaurants and food plants
- Use on most water washable restroom surfaces including glazed porcelain, glazed ceramic, sealed grout, stainless steel, Formica®, Plexiglas®, chrome, fiberglass sinks and shower stalls
- Apply with toilet bowl swab. For other hard surfaces use cloth, sponge, mop or spray applicator to wet surface





Bath Mate™/MC

Acid-Free Disinfectant Washroom Cleaner Concentrate

Use instructions

DIRECTIONS FOR USE: READ AND UNDERSTAND LABEL AND SAFETY DATA SHEET (SDS) BEFORE USE.

Attach RTD bottle to cold water hose and turn water on (reference RTD® operating instructions sheet). Rotate control knob to either or to dispense at a 1:16 dilution into the appropriate container.

Cleaning Toilet Bowls and Urinals: Flush toilet or urinal. Ensure water level is low. Apply cleaner solution to bowl swab. Swab under the rim and work down. Allow to dwell on product surfaces. Flush toilet or urinal. Rinse bowl swab.

Cleaning Sinks, Tubs and Other Hard Surfaces: Apply with a cloth, sponge, mop, or spray applicator to wet surfaces thoroughly. Agitate and rinse thoroughly.

Note: When cleaning floors position wet-floor signs around area to be cleaned. Floors will be slippery when wet or contaminated with foreign materials.

Technical data	Bath Mate™/MC
Color/Form	Clear green, liquid
pH	11.85
Scent	Fresh
Shelf Life	2 Years

Product	Pack size	Dilution	Product code	
Bath Mate™/MC	2 x 50.7 oz. / 1.5 L RTD®	1:16	101104625	
Bath Mate™/MC	12 x 32 oz. / 946 mL Spray Bottles		D1225692	

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.

Formica® is a registered trademark of the Formica Corporation.

Plexiglas® is a registered trademark of the Arkema, Inc.