



Avert[®] Disinfectant Cleaner

A ready-to-use one-step defense against *Clostridium difficile* (*C. diff*) spores on hard, non-porous surfaces such as those found in hospitals and other healthcare facilities.

Features & Benefits

- Effective in 4 minutes against *Clostridium difficile* (*C. diff*) spores. Cleans, disinfects, and deodorizes in one labor-saving step
- Bleach-based formula means no quat-binding concerns. 1 minute contact time effective against a broad spectrum of pathogens including bacteria, antibiotic resistant bacteria, viruses, and fungi
- 12,500 ppm chlorine exceeds Health Canada, CDC, SHEA, IPAC and AORN recommendations

Applications

- Hard surface cleaning and disinfection
- Designed for disinfecting medical hard, nonporous inanimate surfaces including: glass, glazed porcelain and stainless steel. Not recommended for use on: aluminum, brass, chipped enamel, clear plastic, copper, finished floors, natural marble, painted surfaces, and silver.

Note: This product is compatible with the listed materials. If product is intended to be used on other surfaces, it is recommended to test product by applying to a small discrete area to determine compatibility before proceeding with its use or contact a Diversey representative





Avert® Disinfectant Cleaner

Use instructions

Special Instructions for Cleaning Prior to Disinfection against *Clostridium difficile* spores:

Personal Protection:

- Wear appropriate barrier protection such as gloves, gowns, masks or eye covering

Cleaning Procedure:

- Fecal matter/waste must be thoroughly cleaned from surfaces/objects before disinfection by application with a clean cloth, mop, and/or sponge saturated with the disinfectant product. Cleaning is to include vigorous wiping and/or scrubbing, until all visible soil is removed. Special attention is needed for high-touch surfaces. Surfaces in patient rooms are to be cleaned in an appropriate manner, such as from right to left or left to right, on horizontal surfaces, and top to bottom, on vertical surfaces, to minimize spreading of the spores. Restrooms are to be cleaned last. Do not reuse soiled cloths

Infectious Materials Disposal:

- Materials used in the cleaning process that may contain feces/wastes are to be disposed of immediately in accordance with local regulations for infectious materials disposal

Procedure for Disinfection of *C.difficile* Spores:

- Apply product to hard, non-porous surface, thoroughly wetting surface
- Let treated surface remain wet for 4 minutes
- Air Dry, wipe surfaces to dry and remove any residue, or rinse with potable water as necessary

For Use as a One-Step Cleaner/Disinfectant, Deodorizer, and Fungicide:

- Pre-clean heavily soiled areas
- Apply product to hard, non-porous surface, thoroughly wetting surface
- Let treated surface remain wet for 1 minute
- Air Dry, wipe surfaces to dry and remove any residue, or rinse with potable water as necessary

Technical data	Avert® Disinfectant Cleaner
DIN	02436094
Color/Form	Pale Yellow, Liquid
pH	12.5
Scent	Chlorine
Shelf Life	12 months

Product	Pack size	Dilution	Product code	
Avert® Disinfectant Cleaner	12 x 32 oz. / 946 mL Bottles	Ready-to-use	100842726	

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up-to-date shipping information.