



Professional LYSOL®

Deodorizing Cleaner

This economical, concentrated formula makes up to 64 gallons (1:64) and can be used for a variety of needs to clean, disinfect and deodorize. Use on walls, floors, restroom fixtures and surfaces, garbage cans, cabinets, glazed tile, enamel and glazed porcelain.

Features & Benefits

- Kills 99.9% of bacteria & Viruses, including E.Coli, Listeria, MRSA, Staph, Strep, Influenza A*
- Lemon Scent
- Provides Efficacy Against multiple Microorganisms



* When used as directed.





Professional LYSOL®

Deodorizing Cleaner

Use Instructions

- It is a violation of Federal law to use this product in a manner inconsistent with its labeling. This product is not for use on critical & semi-critical medical devices or medical equipment surfaces.

General Cleaning and Deodorizing:

- Dilute 1/4 cup (2 fl. oz.) per gallon of warm water. Apply with a sponge, mop, or coarse sprayer until surface is thoroughly wet. Then wipe surface clean. For heavily soiled surfaces, repeat until surface is clean. Prepare a fresh bucket of solution every time you clean or more often as needed.

To Sanitize hard non-porous non-food contact surfaces:

- Pre-clean surface. Dilute 1 cup [8 fl. oz.] per gallon of water.
- Apply to surface until thoroughly wet

To Disinfect hard non-porous surfaces:

- Pre-clean surface. Dilute 1 cup [8 oz.] per 1/2 gallon of water. Apply to surface until thoroughly wet. To Sanitize hard non-porous non-food contact surfaces: Leave for 90 seconds before wiping. To Disinfect: Leave for 10 minutes before wiping. Rinse all food contact surfaces with clean potable water after use. Do not use on glasses, dishes or utensils. For Disinfecting Toilet Bowls: Flush toilet bowl and then add 1 cup [8 fl. oz.] full strength into the bowl water. Thoroughly brush all bowl surfaces and under the rim. Let stand for at least 10 minutes before flushing.
- KILLS HUMAN IMMUNODEFICIENCY VIRUS TYPE 1 [HIV-1 AIDS VIRUS] ON PRE-CLEANED ENVIRONMENTAL SURFACES / OBJECTS PREVIOUSLY SOILED WITH BLOOD / BODY FLUIDS in settings where there is an expected likelihood of soiling of inanimate surfaces / objects with blood / body fluids; and in which the surfaces / objects likely to be soiled with blood / body fluids can be associated with the potential for transmission of HIV-1 (associated with AIDS).

SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 [AIDS VIRUS] ON SURFACES/OBJECTS SOILED WITH BLOOD / BODY FLUIDS:

- PERSONAL PROTECTION: When handling items soiled with blood / body fluids, use disposable latex gloves, gowns, masks and eye protection.
- CLEANING PROCEDURES: Blood / body fluids must be thoroughly cleaned from surfaces / objects before application of this product.
- CONTACT TIME: Allow surfaces / objects to remain wet for 10 minutes.
- DISPOSAL OF INFECTIOUS MATERIALS: Blood/body fluids must be autoclaved and disposed of according to local regulations for infectious waste disposal.

Technical data	Professional LYSOL® Deodorizing Cleaner
Color/Form	Green-Yellow, Liquid
pH	10.7 to 11.8
Scent	Lemon
Shelf Life	2 Years

Product	Pack size	Dilution	Product code
Professional LYSOL® Deodorizing Cleaner - Lemon Scent	4 x 128 oz. Containers	1:64	CB763340

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up-to-date shipping information.