

# Virex® Plus

## Dilution and Shelf Life / Stability



Pull the blue tip with a needle nose pliers for **1:128 DILUTION**

**NOTE: It is required to wear gloves and goggles when working with concentrates**

Virex® Plus J-Fill® metering tips come from production at 1:256 dilution for 3-minute bactericidal / virucidal. There is a blue tip that can be removed manually to make it 1:128 by trained staff prior to putting into locked dispenser. This is for specific viruses which have a 5-minute dwell time.

### PPM for Virex® Plus:

- 1:256 – 870 PPM
- 1:128 – 1740 PPM – you use 5 minute dwell time for this for small non-enveloped virus or SARS-2, CoV-2 Virus

Test strips for 1:256 can be found [HERE](#). We have sources for titration kits. Please contact your representative for more information.

### The stability/shelf life for Virex® Plus:

- 2-year shelf (concentrate)
- 1-year in a bottle (closed container)
- 1-day in open bucket, or when visibly soiled

**Questions: 1-800-558-2332**