

ALL-PURPOSE
VIREX[®]
DISINFECTANT CLEANER

All Purpose Virex[®]

Disinfectant Cleaner

All Purpose Virex[®] Disinfectant Cleaner is a ready-to-use, quaternary-based, hospital-use disinfectant that provides excellent cleaning and deodorizing in one step.

Features & Benefits

- Bactericide, tuberculocide, virucide, fungicide
- Kills Norovirus, VRE and MRSA
- Ready to use
- Citrus scent
- Disinfects multiple organisms in three minutes
- Kills Norovirus, VRE and MRSA
- Meets OSHA's bloodborne pathogen standards for decontaminating blood and body fluids (HBV, HCV and HIV-1).
- Provides broad spectrum kill of microorganisms including HBV, HIV-1, VRE, MRSA, MRSE, VISA, PRSP, Herpes Simplex Types 1&2, Influenza Type A2, Adenovirus, Rotavirus and many more
- Kills the organisms that cause odors and works as an odor counteractant

Applications




- Can be applied with a mop, sponge, or cloth
- For use on hard, inanimate, nonporous surfaces such as floors, walls, porcelain, and plastic surfaces in hospitals, nursing homes, schools, colleges and hotels



Use instructions

- **DISINFECTION, DEODORIZING AND CLEANING** - Remove gross filth or heavy soil prior to application of the product. Hold container six to eight inches from surface to be treated. Spray area until it is covered with the solution. Allow product to penetrate and the surface to remain wet for 3 minutes (for Bloodborne Pathogens: allow surface to remain wet for HIV-1 1 minute and for HBV and HCV 5 minutes). No scrubbing is necessary. Wipe off with a clean cloth, mop or sponge. The product will not leave grit or soap scum.
- **To disinfect food service establishment food contact surfaces:** Before using this product food products and packaging materials must be removed or carefully protected. For countertops, appliances, tables, hold container six to eight inches from the surface to be treated and spray area until it is covered with the solution. Allow product to penetrate and remain wet for 3 minutes (for Bloodborne Pathogens: allow surface to remain wet for HIV-1 1 minute and for HBV and HCV 5 minutes). Wipe off with a clean cloth, mop or sponge and thoroughly rinse all surfaces in the area with potable water. Heavily soiled areas must be pre-cleaned before using this product. Do not use on eating utensils, glassware and cookware.
- **Using approved AOAC test methods, in the presence of 5% blood serum and a 3 minute contact time, unless otherwise noted, this product kills the following organisms on hard non-porous inanimate surfaces: BACTERIA:** Pseudomonas aeruginosa, (ATCC 15442), Staphylococcus aureus, (ATCC 6538), Salmonella enterica, (ATCC 10708).
- **MILDEWSTAT** - To control mold and mildew on pre-cleaned, hard, non-porous surfaces spray surface to be treated making sure to wet completely. Let air dry.

Technical data	All Purpose Virex [®] Disinfectant Cleaner
EPA Reg No.	1839-83-70627
Color/Form	Clear
pH	12.13
Scent	Clear
Shelf Life	3 years

Product	Pack size	Dilution	Product code	
All Purpose Virex [®] Disinfectant Cleaner	8 x 32 fl. oz / 946 mL	Ready-to-use	CBD540533	
All Purpose Virex [®] Disinfectant Cleaner	4 x 32 fl. oz / 946 mL	Ready-to-use	CBD540540	
All Purpose Virex [®] Disinfectant Cleaner	2 x 1 gal. / 3.78 L Container	Ready-to-use	CBD540557	

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.