



Diversey

Extraction Rinse



Removes hard water deposits and neutralizes alkaline residue on synthetic and wool carpets.

Effective

- Removes hard water deposits and neutralizes alkaline residue from previous cleanings
- Safe to use on all colorfast carpets
- Slightly acidic product keeps extractor jets from clogging

For Most Carpet Types

- Strong enough for advanced generation carpet fibers at low dilution, yet delicate enough for wool carpets at high dilution
- Carpets Stay Cleaner Longer

Leaves no tacky residue

- Makes salt residue more soluble, meaning less passes to remove winter salt



Extraction Rinse



Use Directions

- Apply Heavy Duty Prespray according to use directions, depending on soil level.
- For synthetic carpets, dilute 1 oz. Extraction Rinse with 1 gallon luke warm water (130 mL per 3.8 L) in extractor. Dilute 1 oz. with 5 gallons (30 mL per 19 L) water for wool carpets (use cool water).
- Thoroughly extract carpet.
- Groom carpet with clean carpet rake or stiff synthetic broom and allow to air dry.

Note: If being used for the first time, test for colorfastness in an inconspicuous area before use.

Product Specifications

Description	
Color/Form	Clear liquid
Flash Point	> 200° F (> 93.4° C)
pH	3.19 (Concentrate) 2.75 (Use Dilution 1:128)
Scent	Fruity fresh
Shelf Life	2 years
Solubility	Complete
Specific Gravity	1.02

Available Items

Product Code		Description/Package Size	Dilution
903730		4 x 1 gallon / 3.78 L Containers	1:128 (Synthetics),
03730			1:640 (Wool)

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up to date shipping information.