

6GL2

Liquid Laundry Sour

Liquid laundry sour specifically formulated for use in commercial and on-premise laundries.

Features & Benefits

- Effective neutralization of residual alkalinity
- Controls iron stains
- Prevents yellowing of fabric
- Non-phosphated

Applications

- Formulated for use in commercial and on premise laundries
- Should be applied in the last rinse to neutralize residual alkalinity
- Can be used on all washable fabrics





Clax[®] Launch[®] 6GL2 Liquid Laundry Sour

Use instructions

- Use Clax[®] Launch[®] liquid laundry sour as directed by your Diversey representative
- This product can be used in all commercial stainless steel washing machines. Do not use in homestyle washers.
- This product is designed to be dispensed directly to the laundry machine by a Diversey dispenser and should not be diluted manually
- Clax[®] Launch[®] liquid laundry sour is dispensed at various rates depending on water conditions and equipment
- Commercial Machines: Dispense automatically with Diversey dispenser
- Food Plant Use: Thoroughly rinse all laundered fabrics used in food plants with potable water before re-use. Avoid contamination of food during use or storage.

Technical data	Clax [®] Launch [®] 6GL2
Color/Form	Clear, liquid
рН	2
Scent	Odorless
Shelf Life	2 Years

Product	Pack size	Dilution	Product code	
Clax [®] Launch [®] 6GL2	1 x 5 gal. / 18.9 L Pail	Auto Dosed	95150690	1+1

Specific Applications	Recommended
Commerical Washers	Yes
Homestyle Washers	No
Tunnel Washers	Yes
Use with Ozone	Yes
Low Temperature Wash	Yes
Safe on Microfibers	No

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, http://naextranet.diversey.com/dot/, for up-to-date shipping information.