

J-Fill® Uno

Dispensing System

Accurately dispenses a single J-Fill® product into spray bottles, buckets or auto scrubbers with the push of a button. The J-Fill® platform is a close-looped system which virtually eliminates contact with chemical concentrates.

Features & Benefits

- Rugged powder coated steel construction resists corrosion and comes with lockable cabinet doors (comes with keys)
- Dispenses one product at the push of a button and meets ASSE 1055-B back-flow prevention requirements
- Design only allows J-Fill® packaging to be used within dispenser
- Uses super-concentrated and hyper-concentrated chemicals, reduces "in-use" cost and solid waste disposal
- J-Fill® Spill-Tite^{TM/MC} cartridges are leak proof to eliminate chemical exposure, tampering and manually diluting products
- Metering tip in each J-Fill® cartridge ensures precise dilution ratios

Applications

- Wall mounted four product chemical dispenser
- For filling bottles, buckets or floor care machines
- For use in schools, office buildings, foodservice, hospitality, industrial, retail stores and health care facilities





J-Fill® Uno

Dispensing System

Use Overview

J-Fill® Uno Dispensing system safely and accurately dispenses one product at the touch of a button. This slim and durable locking dispenser is perfect for special cleaning needs in any facility. The Uno allows you to dispense one product at a time. This is an ideal dispenser for filling floor care machines or can be used to dispense kitchen care product with a push of a button.



High flow bucket filling



Easy product change-out



Low flow bottle fill

Technical data	J-Fill [®] Uno
Depth	6.5"
Height	20 1/8"
Width	5 5/8"
Weight	9.35 lbs
High Flow Rate	4.0 gal./min. (15.0 L/min.)
Low Flow Rate	1.5 gal./min. (5.1 L/min.)

Operating Range Requirements	J-Fill [®] Uno
Water Pressure	30-85 psi (206-586 KPA)
Water Flow	2.0 gal./min. (7.6 L /min.)
Water Temperature	40-120° F (5-48° C)

ASSE 1055-B backflow prevention requirements.

Product Name	Product Description	Product Code
J-Fill® Uno	High Flow Bucket Fill / 1 unit	D5753036
J-Fill® Uno	Low Flow Bucket Fill / 1 unit	D5753079

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.