

# [Tehuti] PCIe 10 Gigabit Network Card

## Installation Guide

---

This guide contains installation instructions for the following operating systems:

1. [Windows](#)

# [Tehuti] PCIe 10 Gigabit Network Card

## Installation for Windows

## Install Guide

Before you install the device, make sure that your operating system is current (for example, the most recent service pack is installed).

### To install the driver:

1. Right-click the zip folder that you downloaded, click **Extract All**, and complete the instructions.
2. Press the **Windows** key+**R**, type **devmgmt.msc**, and press **Enter** to open Device Manager.
3. Right-click the Ethernet controller device, which will have a “!” or “?” next to it to indicate a driver issue.
4. Click **Update Driver** > **Browse my computer for driver software**.
5. Select the **Let me pick from a list of device drivers on my computer** option.
6. On the **Select your device’s type from the list below** screen, click **Show All Devices**, and click **Next**.

**Note:** The **Select your device’s type from the list below** screen does not appear on all systems. If you do not see this screen, skip this step.

7. Select the **Have Disk** option.
8. Browse to the **Windows** folder.

**Note:** To view your system type, press **Windows** key + **R** and type **control /name microsoft.system** and press **Enter**.

10. Click the **TN40xxmp\_** file.
11. Click **OK** > **Next**.