

ClearVue and ClearVueKübe Pump Demo Display

MKT-DEMO-CLRVUE

1. Remove the base from inside the tank and set the display tank on the base.
2. Position a ClearVue pump underneath the tank drain with the drain directly over one of the pump inlets (Figure A). Make sure tank drain is not open.
3. Fill the display tank about $\frac{1}{2}$ full with clean water (about .75 gallons). Put lid on top.
4. Install a section of clear vinyl tubing from the ClearVue pump outlet into the opening in the tank lid. The tube should go into the lid opening about 3 inches to prevent it from falling out. (Fig. B)
5. Plug in the ClearVue pump and open the tank drain.



Figure A



Figure B

