

HOW TO USE FIDO MAX 1



More Info: www.b-air.com/cesarmillan



Fido MAX 1 DOG DRYER



Cesar Millan
PREMIER GROOMING COLLECTION

FIDO MAX 1 OWNER'S MANUAL



Features:

- Dryer
- 6 foot hose
- 4 grooming nozzles
- High impact ABS construction
- Insulated for quiet operation
- Easy filter replacement
- Washable filter
- Easy carrying handle
- Rubberized feet for stability.



INTRODUCTION

- 

1 **USE IN OPEN SPACE**

We recommend using the Fido Max 1 in an open space and avoid small rooms like a bathroom where noise can be amplified.
- 

2 **SMELL DRYER**

To introduce your dog to the Fido Max 1, place the dryer in a room where the dog is comfortable and let him/her smell and get familiar with the dryer, without turning it on.
- 

3 **6 FT**
KEEP DISTANCE

Keep the Fido Max 1 motor turned away from your dog. The 6 foot hose helps to keep enough distance from him/her.
- 

4 **HEAR SOUND**

Once the dog is comfortable with the Fido Max 1, plug it in and turn the dryer on facing it away from your dog, letting your dog get used to its sound. This will provide a better experience for your dog's ears.
- 

5 **START DRYING**

Start drying the top coat, and then move onto the undercoat to dry the skin and help avoid future skin issues. Use this experience as a bonding moment by creating a fun environment.

Use the 4 nozzles to create the perfect dog grooming experience



The cone is used for the deepest drying and is great on very thick coated dogs.



The slot nozzle is designed for de-shedding the coat.



The airflow nozzle allows more airflow for drying small dogs, cats, and sensitive areas such as ears and face.



The brush nozzle is designed for de-shedding the coat.