

Schedule 40 Rough-In Bath Waste Kit with Quick Test

Parts List

A. Spud	G. Overflow Elbow
B. Drain Gasket	H. Overflow Gasket
C. Drain Elbow	I. Retainer Nut
D. Schedule 40 Pipe (Drain Tube)	J. O-Ring
E. 1.5" Tee	K. Test Nut
F. Schedule 40 Pipe (Overflow Tube)	L. Test Cap
	M. Test Cap Gasket

Additional Parts Needed

- Pliers
- PVC Cement

Installation Instructions

1. Cut the 1-1/2" Schedule 40 pipes (D and F) to the desired lengths to fit the tub.
2. Using the proper solvent cement, assemble the bath drain pipes and fittings (C–G).
3. Place the overflow gasket (H) onto the overflow elbow (G) and insert into the tub overflow hole from the back of the tub.
4. Screw the retainer nut (I) onto the overflow assembly from the inside of the tub. Hand-tighten only.
5. Secure the drain elbow (C) and drain gasket (B) under the tub, by screwing in the spud (A) through the tub drain hole from inside the tub.
If not testing, skip to Step 7.
6. Screw the test cap gasket (M) and the test cap (L) into the spud (A) and test the system. Once testing is complete, remove the test cap gasket and the test cap.

Note: If the test membrane on the overflow elbow (G) is damaged, you can use the O-Ring (J) and the Test Nut (K) on the overflow elbow (G) to test the system.

7. Cut away the test membrane from the overflow elbow assembly (G).

