



HOW TO USE INSTRUCTION GUIDE

PACKAGE FEATURE

- 900 mAh Variable Voltage Battery
- 4 Temperature Settings
- 4.0V
- 3.8V
- 3.6V
- 3.4V
- Trigger Style Button
- 15sec Prep Mode
- Dual Quartz Wax Tank
- · Ceramic Glass Oil Tank
- Magnetic Connectors
- USB Charger

HOW TO USE STEP BY STEP INSTRUCTIONS

900mAh ADJUSTABLE BATTERY

CERAMIC GLASS OIL TANK





POWER BUTTON

ADJUST VARIABLE VOLTAGE

POWER BUTTON

TO ADJUST VOLTAGE:

Once the DUPLEX is ON

Press POWER BUTTON

3 times quickly - • Red Light 4.0V

Press 3 times - • Blue Light 3.4V

Press 3 times - Orange Light 3.8V
Press 3 times - Green Light 3.6V

TURN ON:

Press POWER BUTTON 5 times quickly.

Press POWER BUTTON 5 times quickly.

HOW TO TURN ON/OFF



POWER BUTTON

PRE-HEAT OPTION

Once the DUPLEX is ON Press POWER BUTTON 2 times quickly to begin preheat 15 SECOND PREP MODE Press POWER BUTTON 1 time to deactivate.



LOADING ESSENTIAL OILS INTO THE CERAMIC **GLASS OIL TANK**

- 1.) Remove Mouthpiece from the
- 2.) Load the essential oils on the side walls
- 3.) Place mouthpiece back on.
- 4.) Attach the magnetic adapter onto the cartomizer and place into the DUPLEX battery.

MOUTH PIECE HEATING CHAMBER

LOADING EXTRACTS INTO THE DUAL QUARTZ WAX TANK

- 1.) Unscrew the mouthpiece from the DUAL QUARTZ WAX TANK heating chamber
- 2.) Place extracts inside the heating chamber
- 3.) Screw the mouthpiece back onto the heating chamber
- 4.) Attach the magnetic adapter onto the concentrate heater and place into

the **DUPLEX** battery.

CHARGING INSTRUCTIONS

- 1.) Attach the DUPLEX USB CHARGER into the charging port located on the front of the unit
- The USB LED indicator will turn Red oduring charging and TURN OFF when the charge is complete.

Total charge time around 1 hour.

WARRANTY

One Year Warranty is included with **DUPLEX** purchase.

Warranty DOES NOT apply to DUPLEX batteries at fault from use of NON DUPLEX CHARGER.

If for any reason your DUPLEX stops working please contact us to open a claim

To ensure the best experience, please read and understand the instructions fully before your first use of the DUPLEX. We strongly recommend these instructions are kept for future reference.





FOR MORE INFO VISIT WWW.OOZELIFE.COM