

EP20PAD OPTIONAL ASH DRAWER KIT INSTALLATION

PEDESTAL MODEL ONLY (2100/2200)


! WARNING

FAILURE TO ACHIEVE A GOOD SEAL BETWEEN THE ASH OPENING AND ASH PLUG WILL RESULT IN AN OVER FIRE CONDITION THAT COULD CAUSE DAMAGE TO THE APPLIANCE

This kit includes:

PART #	DESCRIPTION	QTY
W010-1534	Ash Drawer Assembly	1
W200-0283	Ash pan opening cover	1
W510-0011	Ash Plug	1
W325-0028	Handle	1
W525-0009	Rails, Ash Pan	2
W570-0020	Screw, Handle	2
W570-0018	Screw, 9-14 x 1/2"	4

Provisions have been made on the appliance to install an optional ash drawer kit. The kit allows for convenient removal of excess ash.



NOTE: It is recommended to install the rails on the pedestal base prior to installing the pedestal assembly to the firebox.

1. If the appliance has been previously operated, it must be cold and the ashes must be removed in order to access the ash plug.
2. If the pedestal has been installed with the opening to the back, it will be necessary to lay the appliance onto its back, remove the pedestal and re-install it with the opening to the front. It is recommended that all fire brick, including baffles, be removed prior to placing the appliance on its back.
3. From the underside of the appliance, remove the nuts that secure the ash opening cover plate.
4. Install the ash pan rails using the screws provided. (Figure 2)
5. Snap the magnets into place. (Figure 2)
6. Slide the ash drawer into the ash housing. (Figure 3)
7. Install the handle using the screws provided and affix the logo to the ash pan housing cover as illustrated. (Figure 3)
8. Place the ash pan housing cover in front of the opening, engaging it into the slots. (Figure 3)
9. Remove the small light weight brick that is covering the ash opening and discard. It is important that the area around the ash opening be cleaned well to ensure that a proper seal is created between the new ash plug and the ash opening.
10. Once the area surrounding the opening has been cleaned, place the new ash plug (supplied) over the opening, allowing the protrusion on the bottom to recess into the opening on the bottom of the firebox.

Figure 2





Figure 3



INSTALLATION DU TIROIR À CENDRES OPTIONNEL EP20PAD MODÈLES SUR PIÉDESTAL SEULEMENT (2100/2200)


! AVERTISSEMENT

SI LE JOINT ENTRE L'OUVERTURE DE LA CHUTE À CENDRES ET LE COUVERCLE N'EST PAS ÉTANCHE, CELA ENTRAÎNERA UNE SURCHAUFFE POUVANT CAUSER DES DOMMAGES À L'APPAREIL.

Cet ensemble comprend :

N° DE PIÈCE	DESCRIPTION	QTÉ
W010-1534	Tiroir à cendres	1
W200-0283	Porte d'accès	1
W510-0011	Couvercle de la chute à cendres	1
W325-0028	Poignée	1
W525-0009	Rails du tiroir à cendres	2
W570-0020	Vis pour poignée	2
W570-0018	Vis 9-14 x 1/2"	4

Le poêle a été conçu pour recevoir un tiroir à cendres optionnel. Cet ensemble vous permettra de disposer aisément des cendres.



NOTE : Nous vous conseillons d'installer les rails sur la base du piédestal avant d'installer le piédestal au caisson.

1. Si le poêle a déjà été utilisé, il doit être refroidi et vous devez enlever les cendres pour accéder au couvercle de la chute à cendres.
2. Si le piédestal est installé avec l'ouverture située à l'arrière, vous devrez coucher l'appareil sur le dos, retirer le piédestal et le réinstaller avec l'ouverture située à l'avant. Nous vous conseillons de retirer toutes les briques réfractaires ainsi que les déflecteurs avant de coucher l'appareil sur le dos.
3. À partir du dessous du poêle, retirez les écrous qui retiennent la plaque de recouvrement.
4. Installez les rails du tiroir à cendres à l'aide des vis fournies. (Figure 2)
5. Installez les deux loquets aimantés. (Figure 2)
6. Insérez le tiroir à cendres dans le compartiment à cendres. (Figure 3)
7. Installez la poignée à l'aide des vis fournies et apposez le logo sur la porte d'accès comme illustré. (Figure 3)
8. Placez la porte d'accès devant l'ouverture en l'insérant dans les fentes. (Figure 3)
9. Retirez la petite brique qui couvre l'ouverture de la chute à cendre et jetez-la. Il est important de bien nettoyer la région de l'ouverture de la chute à cendres afin d'assurer une étanchéité adéquate entre le nouveau couvercle et l'ouverture.
10. Une fois que la région est bien nettoyée, mettez le nouveau couvercle de la chute à cendres (fourni) sur l'ouverture, en vous assurant que la protubérance sous la brique est enchâssée dans l'ouverture du plancher de la chambre de combustion.

Figure 2




Figure 3

