


ITEM: SP-AZ079 ANZZI COLLINES SHOWER PANEL INSTALLATION & OPERATION MANUAL

V1.0

08/01/2024



DON'T WAIT! REGISTER NOW!

Register your product within 90 days to ensure your product is recognized as an official purchase and is eligible for warranty coverage.


Register online at <u>https://anzzi.com/pages/register</u> or scan the QR code at PG. 2.

PRODUCT REGISTRATION*

IMPORTANT: Warranty will not be recognized unless product is registered.

Register online at <u>https://anzzi.com/pages/register</u> or Scan the QR code below. Registering online is fast, secure, and ensures we receive your information.






Part	Description	Qty	Part	Description	Qty
[01]	Shower Head	1	[12A]	Washer	4
[02]	Shower Panel	1	[12B]	Spring Washer	4
[03]	Diverter Cartridge	1	[12C]	Butterfly Nut	4
[04]	Escutcheon	1	[13]	Hand Shower	1
[05]	Diverter Handle	1	[14A]	Nut	1
[06]	Thermostatic Handle	1	[14B]	Washer	1
[07]	Escutcheon	1	[14C]	Hand Shower Holder	1
[08]	Thermostatic Restrictor	1	[15A]	Washer	2
[09]	Thermostatic Cartridge	1	[15B]	Shower Hose	1
[10A]	Anchor	4	[16]	Washer	2
[10B]	Bracket	2	[17]	Elbow Fittings	2
[10C]	Screw	4	[18]	Hose	2
[11]	Washer	2			



IAPMO IGC 154 ASME A112.18.1/ CSA B125.1



- A. Shower Head
- B. Body Jets
- C. Diverter
- D. Thermostatic control
- E. Hand Shower

DUCT FEATURE -5

- Ultra thin shower panel design with thermostatic valve inside
- Anti-scold protection
- Preset water temperature providing constant warm water
- Single diverter controls water flowing between Rain Shower/ Body Jets/ Hand Shower

Rust-free materials



Read Before Using Your New Shower Panel

Congratulations on purchasing our Shower Panel. Your new shower panel will be a great addition to your bathroom for years to come. Our luxury Shower Panel brings a spa experience into your life in the comfort of your personal bathroom. Adding the shower panel as a modification to your present shower will allow you to enjoy the pleasures of massaging body spray jets. Furthermore, the shower panel will operate with your existing plumbing supply lines with standard line pressure and flow rates. Before using our Shower Panel, please read this document carefully and thoroughly. The instructions and safety information in this document are essential to the safe operation of your personal ways of the pressure of the safe operation of your present are using the differently.

new unit. Additionally, neglect or improper or incorrectly performed installation, maintenance or repair, including failure to follow the applicable care and cleaning instructions, may affect your new product's warranty.

IMPORTANT

- 1. Prior to installation, please make sure your package is intact. Look over the product and contact your dealer or ANZZI if you find damaged sections.
- 2. In order to install this shower panel, simple understanding of plumbing techniques will be necessary. Please contact your dealer or a professional plumber if you are unfamiliar with plumbing techniques or have questions.
- 3. This shower panel is designed for indoor use only. It is not intended for outdoor or other uses.
- 4. The product is provided with flexible supply hoses. It is to recommended to put stop valves between the hoses and water supplies.
- 5. Product requires between 20-125 psi supply pressure. Install a pressure reducing valve if your water pressure is too high.
- 6. Check all connections for leaks. Retighten if necessary, but do not overtighten.
- 7. For the product using thermostatic valve, the pressure difference between cold/hot supply shall not more than 30%. Otherwise, the product may not function.
- 8. For the product using thermostatic valve, the highest temperature is 49°C to avoid scald.


Mounting the Brackets of the Shower Panel

-It is recommended that the shower panel be mounted at a height that will make the unit accessible to people with varying heights. Establish the precise height and position of the unit on the wall. We recommend leaving a 6"(15cm) space between the shower head and the average height of the people in the house as well as a minimum distance of 1"(2.5cm) from the ceiling.(Figure A)

-Adjust the plumbing to ensure that there is adequate space for the shower panel to be installed.(Figure B)


-The height you choose shall allow the shower panel to completely cover up the connection points for the cold and hot water supplies. In order to determine your installation location of the shower panel, you should use a tape measure and a pencil.


(or some type of marking tool).



19.69" 6" 70" **Figure A**


Figure B








- **1-1** Install Shower Head [01] from the top of Shower Panel [02] as Fig 1.2 shows.
- 1-2 Slide Washers [12A] and Spring Washers [12B] to the screws of Shower Head [01] from the back of Shower Panel [02] and secure it with Butterfly Nuts [12C]. (Fig 1.2)
- 1-3 Connect the outlet hose to the shank of Shower Head [01]. Tighten the nut of outlet hose to secure. DO NOT OVER TIGHTEN!



- 2-1 Position the shower panel on the wall according to figure A on page 5. Draw line 1 on the wall along the bottom of shower panel. (Fig 2.1) Notice: Make sure the outlets are located 2.2" 4.4" above the bottom of Shower Panel [02].
- 2-2 Measure the distance A between the bottom of the shower panel and the lower Bracket [10B]. Then draw line 2 above line 1 at the distance A. (Fig 2.2)
- 2-3 Position the Bracket [10B] on the wall with its lower corners aligned with line 2 and center with the center line between the outlets. Then mark the wall through the screw holes of the Bracket [10B]. (Fig 2.3)
- 2-4 Position another Bracket [10B] above the previous one on the wall so the screw holes are 37.8" above the screw hole marks for the first bracket and center with the center line between the outlets. Then mark the screw holes of the second Bracket [10B] on the wall. (Fig 2.2)



IMPORTANT Before drilling any holes for the shower panel brackets, be sure there are no hidden cables or pipelines aligned with the desired drilling position.

- **3-1** Drill 1/4" holes at the marked positions. (Fig 3.1)
- 3-2 Install the Anchors [10A]. (Fig 3.2)
- 3-3 Secure the Brackets [10B] with Screws [10C]. (Fig 3.3)







Fig 4.2

- **4-1** Install the **Shower Holder [14C]** through the hole from the right of **Shower Panel [02]**. Make sure the shower hose connector faces downward. (Fig 4.1)
- 4-2 Slide the Washer [14B] to the Shower Holder [14C] from the inside ofShower Panel [02] and secure it by tightening the Nut [14A]. Do not over tighten. (Fig 4.1)
- **4-3** Install the **connector** with **Washer [11]** in it to the **Shower Holder [14C]**. Then tighten the **nut** of the **connector** to secure. (Fig 4.1)
- **4-4** Connect the **connector 1** of **Shower Hose [15B]** to **Shower Holder [14C]** and **connector 2** to **Hand shower [13]**. Tighten the connectors to secure. Make sure there are washers inside the connectors. (Fig 4.1, Fig 4.2)



IMPORTANT: Before connecting the inlet hoses and water supplies, turn on cold and hot water supplies and flush water lines for one minute. This flushes away any debris that could cause damage to internal parts.







Fig 6.1

Fig 6.2

- 6-1 Install Washers [16] and Elbow Fittings [17] to the outlet. Adjust the direction of the Elbow Fittings [17] and tighten them. DO NOT OVER TIGHTEN! (Fig 6.1)
- 6-2 Connect the Hoses labeled with "Hot" or "Cold" to the Elbow Fittings [17], then tighten the nuts of the hoses. DO NOT OVER TIGHTEN! (Fig 6.2)
 Notice: Make sure the hose labeled with "Hot" connected to the hot water outlet, the hose labeled with "Cold" connected to the cold water outlet. Otherwise the outlet water won't be warm or can't maintain the water temperature.
- **6-3** Before hanging the shower panel onto the wall, turn on the faucet and test all water functions of the shower panel and check all connections for leaks. Retighten if necessary, but do not overtighten. (Fig 6.2)
- **6-4** Slide the shower panel down until it rests on the mounting brackets. Slightly pull down the shower panel to secure. (Fig 6.2, Fig 6.3)

Fig 6.3



Note: If the water flow becomes smaller, please clean the filter screen at the inlet hoses. If the problem cannot be solved after cleaning, remove the thermostatic cartridge for cleaning by following the steps in page 14 to 15.


CARE AND MAINTENANCE


 $(\mathbf{2})$


IMPORTANT:

 $\mathbf{\Pi}$


It is not recommended that the user disassemble the thermostatic cartridge by himself, and it is recommended to ask professional personnel for treatment.








Remove the thermostatic handle. **Note:** The rod of cartridge can only be rotated when the handle is right in place. Don't rotate the rod of cartridge during and after removing the handle.



Loosen the screw with the hexagon wrench.

Remove the Escutcheon.



Remove thermostatic restrictor with the plier. **Note:** We suggest recording the position of thermostatic restrictor by camera.

8



Remove the bonnet nut.




Unplug the thermostatic cartridge.

Soak the thermostatic cartridge in vinegar for 10 minutes Rinse the cartridge with clean flowing water.

6

ARE AND MAINTENANCE





Put the cartridge back into the faucet.

Note: Beware the side hole of the cartridge is pointing downside and aligning with the side hole of body. 4




Secure the cartridge with bonnet nut again.




3

6


The white dot must be aligned with 104 degrees Fahrenheit and face up.1




Install the thermostatic restrictor back again.



Install the escutcheon back again.



Put the plug on.



5

Install the handle onto the cartridge with the button pointing upward.

Screw the handle to finish the installation.

CARE AND MAINTENANCE

ANZZI[®] products are crafted with superior quality standards and workmanship and engineered to stand the test of time. However, that does not mean the product can be neglected – it will need some care and cleaning.

It is recommended to use regular soap and hot water along with a non-abrasive cloth or sponge to regularly clean the product. This avoids any build up or deposits which would be tougher to remove.

If you feel the use of stronger cleaning solutions or chemicals is necessary, always test the cleaning solution or chemical on an inconspicuous area before applying to the entire surface.

Wipe all surfaces clean and rinse completely with water immediately after applying cleaner. Rinse and dry any overspray that lands on nearby surfaces.

DO NOT ALLOW THE CLEANER TO SOAK.

Following these simple procedures will ensure your ANZZI® product remains as lustrous and stunning as the day it was first received. ENJOY!

Sincerely,

La Familia ANZZI®

