Temperature







- This product is not intended for life or safety applications. Do not install this product in hazardous or classified locations. Read and understand the instructions before installing
- Turn off all power supplying equipment before working on it. The installer is responsible for conformance to all applicable codes.

No responsibility is assumed by Veris Industries for any consequences arising out of the use of this material.

TB/TRA Series

Speciality Temperature Sensors

Product Overview

The TB Series temperature sensor is designed to strap onto a pipe. The copper sensing plate provides a secondary measurement of the temperature inside the pipe. The TRA Series temperature sensor is designed for remote sensing applications. Both devices have output options compatible with building control systems and both are warranted to meet accuracy specifications for a period of five years.

Product Identification

| | Bracket | Sensor | | |
|----|-------------------------------------|-----------------------------------|------------------------------------|----------------------------|
| | Diameter | Туре | Cal Certificate | |
| TB | 口 | 口 | | 口 |
| | $A = 2 \frac{1}{2}$ " (6.4 cm) max. | B = 100R platinum, RTD | M = 20k NTC, Thermistor | 0 = None |
| | D = 8'' (20 cm) max. | C = 1k platinum, RTD | N = 1800 ohm, Thermistor | 1 = 1 point Cal validation |
| | E = 12'' (31 cm) max. | D = 10k T2, Thermistor | R = 10k US, Thermistor | 2 = 2 point Cal validation |
| | | E = 2.2k, Thermistor | S = 10k 3A 221, Thermistor | |
| | | F = 3k, Thermistor | T = 100k, Thermistor | |
| | | G = 10k CPC, Thermistor | U = 20k "D", Thermistor | |
| | | H = 10kT3, Thermistor | W = 10k T2 high accuracy, Thermis | stor |
| | | I = 1k Balco (Nickel-iron) RTD | Y = 10k T3 high accuracy, Thermist | tor |
| | | J = 10k Dale, Thermistor | Z = 10k E1, Thermistor | |
| | | K = 10k w/11k shunt. Thermistor | CC = 15k, Thermistor | |


| | Sensor Type | | Cal Certificate | Cable Length |
|-----|---------------------------------|------------------------------|--|--|
| TRA | P ^r | | P | Р |
| | B = 100R platinum, RTD | M = 20k NTC, Thermistor | 0 = None | None = $3 \text{ ft } (0.9 \text{ m})$ |
| | C = 1k platinum, RTD | N = 1800 ohm, Thermistor | 1 = 1 point Cal validat | ion $A = 6 \text{ ft } (1.8 \text{ m})^*$ |
| | D = 10kT2, Thermistor | R = 10k US, Thermistor | 2 = 2 point Cal validat | ion $B = 10 \text{ ft } (3.1 \text{ m})^*$ |
| | E = 2.2k, Thermistor | S = 10k 3A 221, Thermistor | • | C = 20 ft (6.1 m)** |
| | F = 3k, Thermistor | T = 100k, Thermistor | | $D = 25 \text{ ft } (7.6 \text{ m})^{**}$ |
| | G = 10k CPC, Thermistor | U = 20k "D", Thermistor | | E = 50 ft (15 m)** |
| | H = 10kT3, Thermistor | W = 10k T2 high accuracy, T | hermistor | F = 100 ft (30 m)** |
| | I = 1k Balco (Nickel-iron) RTD | Y = 10k T3 high accuracy, Th | nermistor | |
| | J = 10k Dale, Thermistor | Z = 10k E1, Thermistor | | |
| | K = 10k w/11k shunt, Thermistor | CC = 15k, Thermistor | * Not available for sen ** Not available for se | sor types B, C, & I. nsor types B. C. E. F. I. & N. |

Specifications

| | T T T T T T T T T T T T T T T T T T T |
|--------|---------------------------------------|
| Wiring | 22 AWG; 2-wire RTD/Thermistor |




Dimensions



Installation

TB:

- 1. Clamp the sensor around the pipe to be monitored. Make sure the copper sensing plate is in contact with the pipe surface.
- 2. Wire the sensor to the controller as shown.



TRA:

- 1. Set the stainless steel sensing probe in contact with the area to be monitored. No mounting necessary.
- 2. Wire the sensor to the controller as shown.

