


Item # : BRMOR1DNS

Assembly Instructions




Walker
Edison®

Please visit our website for the most current instructions, assembly tips, report damage,
or request parts. www.walkerredison.com


Revised 04/2020

General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product.



- V I. Power tools should not be used to assemble this product.




VII. Maintenance Guide



To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.


1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.

Parts List



Hardware List


| | | | | |
|---|---|-------------|------------|-----|
| A |  | Ø8,0 x 25mm | Wood Dowel | 28x |
| B |  | Ø4,0 x 25mm | Screw | 6x |
| C |  | Ø3,5 x 30mm | Screw | 12x |
| D |  | Ø4,0 x 40mm | Screw | 7x |
| E |  | Ø4,0 x 50mm | Screw | 4x |
| F |  | Ø3,0 x 30mm | Screw | 4x |
| G |  | ØM4 x 22mm | Screw | 2x |
| H |  | 30 x 15mm | Puller | 2x |
| I |  | Ø8 x 8mm | Nail | 20x |





Philips head screwdriver required for assembly
(not included)

The hardware quantities listed above are required for proper assembly
Some extra hardware may also have been included


Step 1 Insert wood dowel A(x24) into parts (01),(02),(03),(05),(06),(11),(12).




Step 2 Insert screw B (x6) into parts (02),(03).





Step 3 Insert screw C (x3) into parts (01),(02).





Step 4 Insert screw C (x3) into parts (01),(03).






Step 5 Insert screw D (x7) into parts (01),(04).







Step 6 Insert screw E (x4) into parts (09).



Step 7 Insert screw C (x2) into parts (05).



Step 8 Insert Nail I (x20) into parts (07),(08).




Step 9



Insert screw C (x4) into parts (11),(12).

Insert screw F (x4) into parts (11),(12),(13).

Use screw G (x2) to attach Puller H (x2) to the drawers.




Step 10




Insert wood dowel (A) into part (6) (Runner small).

| | | |
|---|--|----|
| A | | 02 |
|---|--|----|

Step 11



Step 12



Final Assembly