
# Item #: W48CLCR2D Assembly Instructions






Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com Revised 27/05/2019(L)

#### **General Assembly Guidelines**

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.




VI. A Phillips head screwdriver is required for the assembly of this product.




VII. Power tools should not be used to assemble this product.




- VIII. Drill may be needed for securing product to wall.
- IX. Concealed hinges are three-way adjustable.




Horizontal by screw adjustment



In-and-Out by loosening the hinge-arm mounting screw or via cam adjustment



Vertical
Via slots in the mounting
plate or via cam adjustment




#### Hardware List

Α		Ø8x30mm	Wooden dowel	26	pcs
В		Ø6x32mm	Cam bolt	24	pcs
С		Ø15x11mm	Cam lock	20	pcs
D		Ø15x9mm	Cam lock	4	pcs
E		Ø30mm	Sticker	16	pcs
F			Hinge	4	pcs
G		Ø3.5x14mm	Screw	24	pcs
Н		Ø5x16mm	Shelf support pin	4	pcs
J	<i>ammm</i>	Ø6x50	Bolt	16	pcs
J K		Ø6x50	Bolt Handle	16 2	pcs pcs
		Ø6x50 Ø4x22mm			
K			Handle	2	pcs
K L		Ø4x22mm	Handle Handle Bolt	2	pcs
K L M		Ø4x22mm M4	Handle Handle Bolt Hex Key	2 2 1	pcs pcs pc
K L M N		Ø4x22mm M4	Handle Handle Bolt Hex Key Bolt	2 2 1 16	pcs pcs pc




Philips head screwdriver required for assembly (not included)


The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.




Insert wooden dowel (A) into parts (5,6,8,9,10,11) as per diagram.




Insert wooden dowel (A) into parts (3,4,12,13) ,and using cam bolt (B) into parts (1,3,4,12,13) with Philips head screwdriver as per diagram.




Using cam lock (C) secure parts (10,11) into parts (3,4,12,13) with Philips head screwdriver as per diagram.




Using bolt (J) secure part (2) into parts (3,4,12,13)with hex key (M) as per diagram.




Using bolt (J) secure part (2) into parts (5,6,8,9) with hex key (M) as per diagram.




Using bolt (N) secure part (15) into parts (2) with hex key (M) as per diagram.




Put part (7) into parts (6,8) as per diagram.




Using cam lock (C) secure part (1) into parts (3,4,6,8,12,13) ,using cam lock (D) secure parts (5,9) with Philips head screwdriver as per diagram.




Using screw (Q) secure plastic wedge (P) into back panel as per diagram.




Place sticker (E) cover the holes as per diagram.




Insert shelf support pin (H) into parts (12,13) as per diagram.




insert part (14) into parts (12,13) as per diagram.







Using screw (L) secure handle (K) into part (16) with Philips head screwdriver as per diagram.



Using screw (G) secure hinge (F) into part (16) with Philips head screwdriver as per diagram.



Using screw (G) secure hinge (F) into parts (13,16) with Philips head screwdriver as per diagram.



Using screw (G) secure hinge (F) into parts (12,16) with Philips head screwdriver as per diagram.

