



The application of acrylic floor polish provides a wear coating that protects flooring substrates from undue wear and damage, extending the life of the flooring system.



People

- Team Assignments – 1 to 2 people.
- Safety Equipment – Please refer to product Safety Data Sheets. Wet Floor Signs
- Pre-Training: Since floor finish application is performed at a very low frequency and can involve the moving of heavy furniture, it is important to review the proper procedures and safety measures before proceeding with this maintenance activity.



Product & Equipment

- Hillyard Multi-flo XP equipped with Trident Flat Mop Frame
- Blue Stripped Flat Mop Finish Pad
- Preferred Hillyard Finish / Seal
- Wet Floor Signs



Procedures

1. Place wet floor signs in appropriate positions.
2. Use at least two weights on the finish head to ensure proper application rate.
3. With the proper finish head and pump installed, attached the 5-gallon Bag in Box of Hillyard floor polish or seal and turn on the finish valve.
4. Pump enough product to saturate the mop head, then move in a straight line to apply finish, keeping enough finish on the floor to prevent dry slips, but not so much that finish trails around the finish head.
5. At the end of a run, pull up the finish head, then re-square to the wall before starting the return run.
6. Use the Trident microfiber finish mop to coat any inaccessible areas.
7. After entire area is coated, let dry 45 min.
8. Apply additional coats in the same manner listed above. Do not apply more than three coats in a single day. Allow last coat to dry 4-6 hours (preferably overnight) before opening area to traffic.
(TEMPERATURE AND HUMIDITY CONDITIONS AFFECT CURING TIME)

NOTE: Proper curing between coats prevents pulling or streaking. Best results are obtained with adequate ventilation and floor temperatures above 60F.



Fresh Start
3-5 Years



Protect
Daily



Maintain
Weekly



Revitalize
Annually