


# Pedestal Desk




## IMPORTANT

Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.


Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

Do not use power tools above 8 volts to assemble.


## Part List



B.  
Side Panel  
1 pc.



C.  
Side Panel  
1 pc.



D.  
Side Panel  
1 pc.




E.  
Side Panel  
1 pc.




F.  
Front Rail  
2 pcs.




G.  
Front Rail  
1 pc.




R.  
Shelf  
1 pc.




H.  
Base  
2 pcs.




J.  
Plinth  
2 pcs.




I.  
Back Panel  
2 pcs.




S.  
Door  
1 pc.



T.  
Drawer  
2 pcs.



U.  
Drawer  
1 pc.



V.  
Drawer  
1 pc.

Refer to later page(s) of these instructions for drawer assembly.

Carton 5531-181 is also needed for assembly.

Tool(s) required for assembly: Phillips screwdriver

homestyles Customer Service: [www.homestylesfurniture.com](http://www.homestylesfurniture.com),  
servicedesk@homestylesfurniture.com, 888-680-7460

## Assembly Instructions 2/10

### IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

### STEP 1

Insert Cam Lock Screws into pre-drilled holes in Top (A), Side Panels (B), (C), (D), (E), Back Panels (I), Plinths (J) and Back Panel (O), then tighten. (See Figure 1)

Attach Magnet to Side Panel (C) by inserting Wood Screws into pre-drilled holes. (See Figure 2)






Figure 1





Figure 2



## STEP 2

Attach Plinth (J) and Back Panel (I) to Base (H) with Cam Locks. (See Figure 3)

Note: Arrow label indicates front of Base (H).






Figure 3



## STEP 3

Attach Side Panel (C) to unit with Cam Locks.


Insert Tapered Wood Screws (long) into pre-drilled holes in unit, then tighten.

## STEP 4

Attach Front Rail (F) to unit with Cam Locks.

Attach Side Panel (B) to unit with Cam Locks.



Insert Tapered Wood Screws (long) into pre-drilled holes in unit, then tighten.



## STEP 5

Attach Plinth (J) and Back Panel (I) to Base (H) with Cam Locks.

Note: Arrow label indicates front of Base (H).



## STEP 6

Attach Side Panel (D) to unit with Cam Locks.


Insert Tapered Wood Screws (long) into pre-drilled holes in unit, then tighten.

## STEP 7

Attach Front Rails (F) and (G) to unit with Cam Locks.

Attach Side Panel (E) to unit with Cam Locks.

Insert Tapered Wood Screws (long) into pre-drilled holes in unit, then tighten.



## STEP 8

Attach Front Rail (M) to Side Panels (P) and (Q) with Head Cap Bolts. (See Figure 4)






Figure 4




## STEP 9

Attach Front Rail (N) to unit with Head Cap Bolts.

Attach Back Panel (O) to unit with Cam Locks.

## STEP 10

Attach units from Steps 4 and 7 to Keyboard Box with Head Cap Bolts.



## STEP 11

Attach Keyboard Front (K) to Keyboard (L) with Tapered Wood Screws (short). (See Figure 5)

Attach Knobs to Keyboard with Machine Screws. (See Figure 6)






Figure 5





Figure 6




## STEP 12

Attach Top (A) to unit with Cam Locks.

# Assembly Instructions 7/10

## Drawer (T)



### STEP 13



Attach Drawer Front (T1) and Drawer Back (T2) to Drawer Side (T3) with Wood Screws (long).

Attach Drawer Side (T4) to unit with Wood Screws (long).

### STEP 14

Insert Drawer Bottom (T5) into groove.


Attach Drawer Bottom (T5) to unit with Wood Screws (short).




### STEP 15

Attach Knob with Machine Screw.


## Part List




T1.  
Drawer Front  
2 pcs.




T2.  
Drawer Back  
2 pcs.



T3.  
Drawer Side  
2 pcs.




T4.  
Drawer Side  
2 pcs.



T5.  
Drawer Bottom  
2 pcs.

## Drawer (U)



### STEP 16



Attach Drawer Front (U1) and Drawer Back (U2) to Drawer Side (U3) with Wood Screws (long).

Attach Drawer Side (U4) to unit with Wood Screws (long).

### STEP 17

Insert Drawer Bottom (U5) into groove.


Attach Drawer Bottom (U5) to unit with Wood Screws (short).




### STEP 18

Attach Knob with Machine Screw.


## Part List




U1.  
Drawer Front  
1 pc.




U2.  
Drawer Back  
1 pc.



U3.  
Drawer Side  
1 pc.



U4.  
Drawer Side  
1 pc.




U5.  
Drawer Bottom  
1 pc.



## Assembly Instructions 9/10



### Drawer (V)



### STEP 19

Attach Drawer Front (V1) and Drawer Back (V2) to Drawer Side (V3) with Wood Screws (long).


Attach Drawer Side (V4) to unit with Wood Screws (long).



### STEP 20


Insert Drawer Bottom (V5) into groove.

Attach Drawer Bottom (V5) to unit with Wood Screws (short).



### STEP 21

Attach Knob with Machine Screw.




### STEP 22


Place Metal Strips (W) into position.

Metal Strip (W) can be adjusted for letter or legal files.


### Part List




V1.  
Drawer Front  
1 pc.




V2.  
Drawer Back  
1 pc.



V3.  
Drawer Side  
1 pc.



V4.  
Drawer Side  
1 pc.



V5.  
Drawer Bottom  
1 pc.

## Assembly Instructions 10/10





Figure 7




Figure 8




Figure 9




Figure 10

### STEP 23

Insert Adjustable Pins into side panels at desired level. (See Figure 7)

Place Shelf (R) into position.

Attach Door (S) to unit by sliding door hinges into side panel hinges. (See Figure 8)

Attach Knob to Door (S) with Machine Screw. (See Figure 9)

Slide Drawers (T) and (U) into position.

Slide ball cages left and right to front unit, slide keyboard and Drawer (V) into position. (See Figure 10)

Note: To remove Drawers (V) and keyboard in future, push plastic lever on left side up, push plastic lever on right side down and pull open. (See Figures 11 and 12)




Figure 11




Figure 12

# CARE INSTRUCTIONS

## NEVER


allow liquids to remain on furniture.  
Absorption causes parts to warp  
and split and finishes to delaminate.

## NEVER

use glass cleaners on  
finished furniture. Ammonia  
chemically attacks the finish.



Do not use power tools  
above 8 volts to assemble.  
**PREVENT  
CRACKING**



Do not place  
in direct sunlight.  
**PREVENT  
FADING**



Do not write  
directly on surface.  
**PREVENT  
MARKING**



Do not place hot  
objects on surface.  
**PREVENT  
FINISH DAMAGE**




Do not use rubber  
based placemats.  
**PREVENT  
DISCOLORING**



Do not use commercial  
waxes and polishes.  
**PREVENT  
YELLOWING**

## CLEAN

with a soft cloth moistened  
in lukewarm soap and water.  
Buff with a dry clean cloth.



**homestyles** will provide replacements free of charge for missing or damaged parts within 30 days of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, **homestyles** is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info below.

**homestyles** Customer Service: [www.homestylesfurniture.com](http://www.homestylesfurniture.com),  
[servicedesk@homestylesfurniture.com](mailto:servicedesk@homestylesfurniture.com), 888-680-7460