


# Item # : BR2DMILNS

## Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkerredison.com](http://www.walkerredison.com)


Revised 15/04/2019

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product.




- VII. Power tools should not be used to assemble this product.




- VIII. Drill may be needed for securing product to wall.


- IX. Concealed hinges are three-way adjustable.



Horizontal  
by screw adjustment




In-and-Out  
by loosening the hinge-arm  
mounting screw or via cam  
adjustment



















Vertical  
Via slots in the mounting  
plate or via cam adjustment

# Parts List



# Hardware List


A		Ø8x30mm	Wooden dowel	8 pcs
B		Ø6x32mm	Cam bolt	4 pcs
C		Ø15x11mm	Cam lock	4 pcs
D		Ø6x12mm	Bolt	8 pcs
E		Ø6x25mm	Bolt	4 pcs
F		Ø6x12mm	Bolt	16 pcs
G			Plastic wedge	4 pcs
H		Ø3x17mm	Screw	4 pcs
J			Hinge	4 pcs
K		Ø3.5x14mm	Screw	26 pcs
L			Handle	2 pcs
M		Ø4x22mm	Bolt	2 pcs
N		30x10mm	Glass pads	6 pcs
P		M4	Hex key	1 pc
Q			Glue tube	1 pc
R			Door stopper	1 pc
S			Screw	4 pcs
T		Ø30mm	Sticker	4 pcs



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1





Insert wooden dowel (A) into parts (5,6), using cam bolt (B) secure part (4) with Philips head screwdriver as per diagram.

## Step 2




Using screw (S) secure part (8) into parts (5,6) with hex key (P) as per diagram.

## Step 3





Put part (7) into parts (5,6) as per diagram.

## Step 4




Using bolt (D) secure part (3) into part (2) ,then using bolt (E) secure part (4) into part (3) with hex key (P) as per diagram.

## Step 5




Using cam lock (C) secure part (4) into parts (5,6) with Philips head screwdriver as per diagram.

## Step 6




Using bolt (F) secure part (9) into part (8) with hex key (P) ,place sticker (T) cover the holes as per diagram.

## Step 7




Using screw (H) into plastic wedge (G) to part (7) as per diagram.

## Step 8





Using screw (K) secure hinge (J) into part (10,11) , and using screw (M) secure parts (10,11) into handle (L) with Philips head screwdriver as per diagram.

## Step 9




Using screw (K) secure hinge (J) into part (10,11) ,with Philips head screwdriver as per diagram.

## Step 10



Tear off and put class pads (N) into part (2) as per diagram.

## Step 11



Put part (1) into part (2) as per diagram.

## Step 12



Final Assembly