

One-Hole Bathtub Faceplate with Conversion Bar and Drain

Parts List

- | | |
|-----------------------|--|
| A. Faceplate Screw | I. Pre-Cut Double-Sided Tape |
| B. Overflow Faceplate | J. Decorative Cover |
| C. Conversion Bar | K. Stopper |
| D. Overflow Gasket | L. Drain Elbow |
| E. Overflow Elbow | M. Drain Gasket |
| F. Drain Tube | N. Lift and Turn Drain Assembly (Stopper and Spud) |
| G. 1.5" Tee | |
| H. Drain Tube | |

Installation Instructions

- Determine if the faceplate being replaced is a One-Hole or Two-Hole model.

Scenario 1: One-Hole Faceplate:

Remove the old faceplate and screw and replace with the new faceplate (B) and new screw (A). Make sure the faceplate slot is facing downward.

When replacing a One-Hole faceplate, the conversion bar (C) is not needed.

Scenario 2: Two-Hole Faceplate:

Remove the old faceplate and screws. Place the conversion bar (C) on the tub drain hole and fix it in place with the new faceplate (B) and new screw (A). Make sure the faceplate slot is facing downward.

- Remove the old drain assembly from the floor of the tub and determine if it needs replacement.

For Lift and Turn Drain Assemblies:

Unscrew the stopper from the lift and turn drain assembly (N). Place the drain gasket (M) on top of the drain elbow (L) underneath the tub and align with the tub drain hole. Screw the spud into the drain hole from the top of the tub. Re-install the stopper.

For Stoppers with Trim Ring:

Unscrew the stopper (K) from the drain assembly. Remove the protective film from one side of the pre-cut double-sided tape (I), stick it to the back of the decorative cover (J), and press firmly. Remove the protective film from the other side of the pre-cut double-sided tape (I) and press the decorative cover (J) on top of the spud firmly. Install the stopper (K) into the spud. Test for leakage.

