


















<p><b>Record your model number.</b></p>	<p><b>Important Information</b> Follow all local plumbing and building codes.</p>	<p><b>1</b> Determine the valve stem adapter length. Refer to the plaster guard.</p> 	<p><b>2</b> Hold a pencil against the wall and guard. Mark the edge of the guard on the pencil.</p> 	<p><b>3</b> Place the pencil inside the guard, aligning the mark with the edge of the guard.</p> 
<p><b>Thin Wall:</b> Use the #3 adapter and the 1-3/8" (35 mm) screw.</p> 	<p><b>Standard Wall:</b> Use the #1 adapter and the 1-3/4" (44 mm) screw.</p> 	<p><b>Thick Wall:</b> Use the #2 adapter and the 2-3/8" (60 mm) screw.</p> 	<p><b>NOTE:</b> If the guard is inside the finished wall, the valve needs to be moved forward.</p> 	<p><b>4</b> Remove the plaster guard. Place the spline adapter on the valve stem.</p> 
<p><b>5</b> Temporarily fit the valve stem adapter on the spline adapter.</p> 	<p><b>6</b> Position the handle on the valve stem adapter.</p> 	<p><b>7 Cold Position:</b> Turn the handle clockwise. It should stop between 9 and 10 o'clock.</p> 	<p><b>8 Hot Position:</b> Turn the handle counterclockwise. It should stop between 3 and 4 o'clock.</p> 	<p><b>9</b> To adjust position, remove the handle and valve stem adapter. Turn the spline adapter.</p> 
<p><b>10</b> Turn the handle to the 6 o'clock position. Remove the handle.</p> 	<p><b>11</b> Secure the valve stem adapter with the proper length screw. Thread the studs into the valve.</p> 	<p><b>12</b> Install the plate assembly and the nuts. The studs should not protrude beyond 7/16" (11 mm) Max.</p> 	<p><b>13</b> Place the escutcheon on the wall with the notch located downward in the 6 o'clock position.</p> 	<p><b>14</b> Point the handle down. Thread the bonnet to valve trim.</p> 