

THE BATTERY

1. The battery is the power source for the system.

2. It provides the energy to start the engine and to power the electrical system when the engine is not running.

3. The battery is connected to the engine and the electrical system through the battery cables.

4. The battery is located in the engine compartment and is secured to the chassis.

5. The battery is a lead-acid battery and is composed of several cells.

6. Each cell contains a lead plate and a lead dioxide plate.

7. The plates are immersed in an electrolyte solution of sulfuric acid and water.

8. The battery is charged by the alternator when the engine is running.

9. The battery is discharged when the engine is not running and the electrical system is used.

10. The battery is a critical component of the vehicle's electrical system.

11. It is important to check the battery regularly and to keep it clean and well-maintained.

12. The battery is a key component of the vehicle's performance and reliability.

13. It is essential to have a good battery to ensure that the vehicle starts and runs properly.

14. The battery is a vital part of the vehicle's electrical system and should be replaced when it is worn out.

15. The battery is a key component of the vehicle's performance and reliability.

DISASSEMBLY



Part No.	Description	QTY	Notes
1	BATTERY	1	
2	TERMINAL POST	2	
3	CABLE	2	
4	TERMINAL BLOCK	1	

1. The battery is the power source for the system.

2. It provides the energy to start the engine and to power the electrical system when the engine is not running.