

ROLLER SUPPORT STAND

Item Number W54010

OWNER'S MANUAL



Performance Tool®

▲WARNING!

READ, UNDERSTAND AND FOLLOW ALL INSTRUCTIONS AND WARNINGS BEFORE OPERATING THIS TOOL. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

FOR YOUR SAFETY,

please read these instructions carefully and retain them for future use.

SPECIFICATIONS

Height: 27 - 43 in.
Width: 17 in.
Roller Width: 11 in.
Weight Capacity: 132 lbs.
Weight: 8.8 lbs.

Specifications are
subject to change
without notice

IMPORTANT SAFETY INFORMATION

▲WARNING!

READ, UNDERSTAND AND FOLLOW ALL INSTRUCTIONS AND WARNINGS BEFORE OPERATING THIS TOOL. FAILURE TO DO SO MAY RESULT IN PERSONAL INJURY AND/OR PROPERTY DAMAGE AND WILL VOID WARRANTY.

1. Keep work area clean. Cluttered areas invite injuries.
2. Observe work area conditions. Ensure roller support stand is set up on firm, level ground in a stable manner.
3. Keep children away. Children must never be allowed in the work area. Do not let them handle machines, tools or extension cords.
4. Be aware of over-balancing. When a large piece is cut from one end of a job the remaining piece may be heavy enough to tip the stander. Always ensure the workpiece is well supported.
5. Use the right tool for the job. Do not modify this tool and do not use this tool for a purpose for which it was not intended.
6. Dress properly. Do not wear loose clothing or jewelry as they can be caught in moving parts. Protective, electrically non-conductive clothes and non-skid footwear are recommended when working. Wear restrictive hair covering to contain long hair.
7. Use eye and ear protection. Always wear ANSI approved impact safety goggles.
8. Work Safe. Keep proper footing and balance at all times. Never use support stand as step ladder nor stand on support stand top. Never exceed recommended maximum weight capacity of support stand (132 lbs.). Always lower heavy loads onto stand gently, so that strain is taken up gradually.
9. Stay alert. Watch what you are doing and use common sense. Do not operate any tool when you are tired.
10. Check to make sure that all fixing screws and knobs are tight and all legs are locked into place before operating the stand.
11. Check damaged parts. Before further use of tool it should be carefully checked to determine that it will operate properly and perform its intended function.
12. Do not operate any tool if under the influence of alcohol or drugs. Read warning labels on prescriptions to determine if your judgment or reflexes are impaired while taking drugs. If there is any doubt, do not operate any tool.
13. When not in use, tools should be stored in a dry locked-up place, out of the reach of children and do not allow persons unfamiliar with it.

IMPORTANT SAFETY INFORMATION

▲WARNING: The use of any accessory or attachment other than one recommended in this instruction manual may present a risk of personal injury.

▲WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator. Read and understand all of the instructions provided in the instruction manual as well as any other tool (s) used with the roller support stand.

PARTS DESCRIPTION

1. Roller Assembly
2. Height Adjustment Handle
3. Leg Assembly
4. Stand Assembly
5. Hex key & Hardware



ASSEMBLY INSTRUCTIONS

Use hex key provided.

1. Remove the pins from the leg assembly (3) and insert the pins into the holes of the stand assembly (4) as shown in Fig. 1. Connect the leg assembly and stand assembly with the hex bolt as shown in Fig 2. Use the hex key to tighten the hex bolt, make sure the leg assembly is locked firmly as shown in Fig 3. Repeat this step with the other leg assembly.




ASSEMBLY INSTRUCTIONS CONT.

- Put the roller assembly (1) on the stand assembly and connect them with two hex bolts and washers (5). Use the hex key to tighten the hex bolts as show in Fig 4.
- You can adjust the height of the stand with the adjustment handle by turning counter-clockwise to loosen. While loose, raise the roller assembly to desired height and turn adjustment handle clockwise to tighten in place as shown in Fig 5.



NOTE: Set the roller assembly parallel with a support stand or other saw table to better support longer work-pieces.



LIMITED WARRANTY

PERFORMANCE TOOL® extends only the following warranties, and only to original retail purchasers. These warranties give specific legal rights. Except where prohibited by local law, the law of the State of Washington governs all warranties and all exclusions and limitations of warranties and remedies. There may be other rights which vary from state to state.

PERFORMANCE TOOL® warrants the product to be free from defects in materials and workmanship under normal use and service. A defective product may be returned for a free replacement within 90 days from the date of purchase, provided that product is returned to place of purchase immediately after discovery of defect. After 90 days and up to one year from date of purchase, PERFORMANCE TOOL® will replace at no charge any parts which our examination shall disclose to be defective and under warranty. These warranties shall be valid only when a sales receipt showing the date of purchase accompanies the defective product or defective part (s) being returned. For part (s) after 90 days, please remit your request, postage prepaid to:

PERFORMANCE TOOL, P.O. Box 88259 Tukwila, WA 98138

These warranties exclude blades, bits, punches, dies, bulbs, fuses, hoses, and other consumables which must be replaced under normal use and service. These warranties shall not apply to any product or part which is used for a purpose for which it is not designed, or which has been repaired or altered in any way so as to affect adversely its performance or reliability, nor shall these warranties apply to any product or part which has been subject to misuse, neglect, accident or wear and tear incident to normal use and service.

PERFORMANCE TOOL® does not authorize any other person to make any warranty or to assume any liability in connection with its products.

Except for warranties of title and the limited express warranties set forth above, PERFORMANCE TOOL® makes no express or implied warranties of any kind with respect to its products. In particular, PERFORMANCE TOOL® makes no implied warranty of merchantability and no implied warranty of fitness for any particular purpose, except that for goods purchased primarily for personal, family or household use and not for commercial or business use, PERFORMANCE TOOL® makes an implied warranty of merchantability (and, if otherwise applicable, an implied warranty of fitness for a particular purpose), but only for the particular qualities or characteristics, and for the duration, expressly warranted above.

The laws on limitation of implied warranties may differ from state to state, so the above limitations may not apply in all cases.

PERFORMANCE TOOL® shall not be liable for consequential, incidental or special damages resulting from or in any manner related to any product, or to the design, use, or any inability to use the product. The sole and exclusive remedy for a defective product or part shall be the repair, or replacement thereof as provided above. The laws on limitation of remedies or on consequential, incidental or special damages may vary from state to state, so the above limitations may not apply in all cases.