



C60/950CA/BZ/LED

To order, contact FEIT ELECTRIC COMPANY

1-866-326-BULB (2852), [www.feit.com](http://www.feit.com), [info@feit.com](mailto:info@feit.com)

# INSTRUCTION MANUAL

## READ & SAVE IMPORTANT SAFETY INSTRUCTIONS

Please read the manual carefully before attempting to install and operate this product. When using or cleaning this product, always exercise basic safety precautions. For outdoor use, please ensure that the bulb is well protected from rain and humidity, and that the bulb is not encapsulated in an enclosed fixture.

### CAUTION

- High Voltage, keep out of reach of children.
- High Voltage, power off unit before servicing.
- Collected insects may be a fire hazard. Clean dead insects from the unit frequently.
- ELECTRICAL SHOCK HAZARD MAY EXIST IF WATER FROM A GARDEN HOSE IS DIRECTED AT UNIT WHILE IN OPERATION.
- Do not stick foreign objects, metal objects or fingers in the unit.
- Do not tamper with or modify the unit.
- Do not clean unit while it is powered on.
- Before cleaning, allow unit to sit for at least 5 minutes to release charge from electric grid.
- Do not clean or spray the unit with water, cleaning spray, or any other liquid.
- Do not submerge unit in water or any liquid.
- Keep out of contact with flammable items such as paper or clothing.
- Not for emergency lighting.

### INSTALLATION

- Screw the product in to any E26 socket. With the base facing upwards, turn the bulb clockwise until firmly set in socket.

### OPERATION

1. Turn the light switch ON once to enable regular lighting.
2. Turn the light switch OFF and ON a second time to enable bug zapper light.
3. Turn the light switch OFF and ON a third time to enable regular lighting and bug zapper light.

**Note:** Electric grid feature is always ON during operation.

**CLEANING INSTRUCTIONS:** TURN POWER OFF AND REMOVE BULB FROM SOCKET BEFORE CLEANING. NEVER CLEAN BULB BY SPRAYING WITH WATER OR OTHER LIQUIDS. DO NOT ATTEMPT TO TAKE BULB APART. Wait 5 minutes for electric grid to lose power. Remove the catch tray located at the bottom of the product. Do not clean the bulb with any metal objects. Use ONLY the plastic brush provided to clean and remove debris from the lamp. Be careful not to bend, break or damage the wire cage or plastic outer frame. Insert the tray back into the product when done.

#### Supplier's Declaration of Conformity:


47 CFR § 2.1077 Compliance Information

**Responsible Party:** Feit Electric Company 4901

Gregg Road, Pico Rivera, CA 90660, USA 562-463-2852

**Unique Identifier:** C60/950CA/BZ/LED

**HIGH VOLTAGE! DON'T TOUCH  
THE ELECTRIC GRID!  
ELECTRIC SHOCK RISK!**



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment. CAN ICES-005 (B).