


# Item # : BR20ELR2D

## Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. [www.walkerredison.com](http://www.walkerredison.com)


Revised 09/10/2019(L)

# General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.






















- VIII. Drill may be needed for securing product to wall.


# Parts List



# Hardware List

A		Ø8x30mm	Wooden dowel	14 pcs
B		Ø6x35mm	Cam bolt	14 pcs
C		Ø15x11mm	Cam lock	6 pcs
D		Ø15x9.5mm	Cam lock	8 pcs
E		Ø30mm	Sticker	14 pcs
F		Ø6x50mm	Screw	4 pcs
G			Plastic wedge	4 pcs
H		Ø3x17mm	Screw	4 pcs
J		4mm	Hex Key	1 pcs
K		Ø4x32mm	Screw	12 pcs
L		Ø3x12mm	Screw	24 pcs
M		Ø5x15mm	Screw	16 pcs
N		Ø6x12mm	Bolt	4 pcs
P			Velcro strap	1 pc
Q		Ø4x25mm	Screw	1 pc
R			Nut	1 pc
S		Ø4x12mm	Screw	1 pc
T			Glue tube	1 pc
U			Drawer slider	1 Set


\* Note: This piece comes preassembled for shipping purposes and must be disassembled to complete the desk assembly.



Philips head screwdriver required for assembly  
(not included)


*The hardware quantities listed above are required for proper assembly.  
Some extra hardware may also have been included.*

# Step 1




Secure cam bolt (B) into parts (1,12,16) with Philips head screwdriver as per diagram.

## Step 2




Insert wooden dowel (A) into parts (3,4,6,7) , then secure cam bolt (B) into parts (3,4) with Philips head screwdriver as per diagram.

## Step 3



Using screw (K) attach part (6) into parts(1,2) with Philips head screwdriver .


## Step 4



Pick up the slider arm (U) and separate the slide Runner for the following Steps. Extend the Slide Runner all the way forward, press the plastic release lever of the slider arm up and pull the Slide Runner Complete out .




## Step 5




Using screw (L) attach part (U) into parts(9,10,13,14) with Philips head screwdriver .

## Step 6




Using screw (L) attach parts (U) into parts(3,4) with Philips head screwdriver as per diagram .

## Step 7




Using cam lock (C) secure parts (3,4) into part (7) with Philips head screwdriver as per diagram. .

## Step 8




Using screw (F) attach part (2) into parts (3,4) with Philips head screwdriver as per diagram .

## Step 9




Using bolt (N) and screw (M) attach part (8) into parts (2) with hex key (J) as per diagram .

## Step 10





Using bolt (N) and screw (M) attach part (8) into parts (2) with hex key (J) as per diagram .

## Step 11



Put part (5) as per diagram.


## Step 12



Using cam lock(C) secure part (1) to parts (3,4) with Philips head screwdriver as per diagram.




## Step 13





Using screw (H) secure plastic wedge (G) to part (5) with Philips head screwdriver as per diagram.

## Step 14





Using screw (K) attach parts (9,10) to part (11),parts (13,14) to part (15) with Philips head crewdriver as per diagram.

## Step 15




Put part (17) as per diagram.

## Step 16



Using cam lock(D) secure part (12) into parts (9,10),part (16) into parts (13,14) with Philips head screwdriver as per diagram.


## Step 17



Insert the assembled drawers into the unit frame, extend the Ball Bearing Slide Tracks (U) on the pedestal Side Panel all the way forward. Then align the Slide Runners on the assembled drawers with the Slide Tracks and push the drawer carefully inside until it stops.

Note : if the drawer does not go in smoothly, please take it out and repeat the step. If you need to remove the drawer, please pull the drawer all the way out, then push the plastic release lever of the ball bearing slide up on one side and down on the other side, and then pull it completely out.


## Step 18



Insert the assembled drawers into the unit frame, extend the Ball Bearing Slide Tracks (U) on the pedestal Side Panel all the way forward .Then align the Slide Runners on the assembled drawers with the Slide Tracks and push the drawer carefully inside until it stops.


Note : if the drawer does not go in smoothly, please take it out and repeat the step. If you need to remove the drawer, please pull the drawer all the way out, then push the plastic release lever of the ball bearing slide up on one side and down on the other side, and then pull it completely out.

## Step 19



Using screw (S) attach velcro strap (P) into part (1) with Philips head screwdriver as per diagram.

## Step 20




If necessary, adjust the Floor Levelers at the bottom of metal legs to level the unit.




## Step 21

### WARNING




Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall



Using screw (Q) attach velcro strap (P) into nut (R) to wall with Philips head screwdriver as per diagram.

## Step 22



Final Assembly