


### ASSEMBLY INSTRUCTIONS Linen Cabinet-Shutter Door



Please provide the following information when contacting for parts or questions: the name of the company you purchased from, the UPS/FedEx tracking number.

#### ASSEMBLY INSTRUCTIONS-IMPORTANT

Carefully unpack & identify each component before attempting to assemble. Refer to parts list. Please take care when assembling the unit and always set the parts on a clean, soft surface. If you require any assistance with assembly, parts, please call the company you place order with or please email to:service@eleganthf.net


#### **INSTRUCCIONES PARA ARMAR-IMPORANT:**

Desempaque cuidadosamente e identifique cada componente antes de tartar de empezar su ensambladura. Verifique la lista de partes. Por favor tenga cuidado cuando arme la unidad y siempre coloque las piezas sobre una superficie plana, suave y limpia. Si necesita ayuda con el armado, envie un correo electzórico a service@eleganthf.net

#### **DIRECTIVES DE MONTAGE-IMPORTANT:**

Avant de commencer l'assemblage, déballez délicatement toutes les pièces et repérez-les sur la liste des pièces. Procédez avec soins durant l'assemblage et posez toujours les pièces sur une surface proper, douce et lisse. sie vouo plait e-mail á service@eleganthf.net

Emission Standard: TSCA Title VI



# **COMPONENTS**

PART	FIGURE	DESCRIPTION	QTY	PART	FIGURE	DESCRIPTION	QTY
А		TOP LEFT SIDE PANEL	1PC	I	$\Diamond$	ADJUSTABLE SHELF	1PC
В		TOP RIGHT SIDE PANEL	1PC	J		BOTTOM FIXED SHELF	1PC
С		UPPER RAIL	1PC	К		TOP PANEL	1PC
D		BOTTOM BACK RAIL	1PC	L		UPPER FIXED SHELF	2PCS
E		BOTTOM LEFT SIDE PANEL	1PC	M		LARGE DOOR	1PC
F		BOTTOM RIGHT SIDE PANEL	1PC	N		SMALL DOOR	1PC
G		BOTTOM PANEL	1PC	0		UPPER BACK PANEL	1PC
Н		BOTTOM FRONT RAIL	1PC	Р		BOTTOM BACK PANEL	1PC


## HARDWARE & TOOLS

					,		
PART	FIGURE	DESCRIPTION	QTY	PART	FIGURE	DESCRIPTION	QTY
1	Ø8*30	WOODEN DOWEL	34PCS	9		ALLEN WRENCH	1 PC
2	<b>\$</b> 5 m	CAM BOLT	8PCS	10		KNOB	2 PCS
3	ø15*12	CAM LOCK	8PCS	11		KNOB BOLT	2 PCS
4		HEX BOLT	8 PCS	12	D	SHELF PIN	4 PCS
5		ANCHOR	1 PC	13	93*12	SCREW	8 PCS
6	<b>©</b> 1000000000000000000000000000000000000	SCREW	2 PCS	14	<b>€</b> 000000000000000000000000000000000000	SCREW	1 PC
7		FIX BELT	1 PC	15	Φ3*12 D=7	SCREW	20PCS
8	<b>©</b>	WASHER	2 PCS				

#### TOOL NEEDED:




PHILIPS SCREWDRIVER REQUIRED
- NOT INCLUDED






#### **WARNINGS:**

- 1. DO NOT LET ANY SHARP OBJECTS TOUCH OR RUB THE SURFACE OF THE PRODUCT.
- 2. WHEN ASSEMBLING, DO NOT LET CHILDREN PLAY AROUND THE WORKING AREA.
- 3. PLEASE CONFIRM ALL PARTS ARE CORRECT BEFORE STARTING THE ASSEMBLY PROCESS.
- 4. DO NOT TIGHTEN ALL BOLTS AND SCREWS COMPLETELY UNTIL THE ENTIRE UNIT HAS BEEN ASSEMBLED AND SET UP.




#### STEP 1:

- 1. Connect panels A, B, L, and rail C with dowels (1).
- 2. Insert dowels (1) to the tops of panels A & B. Attach top K to panels A & B and rail C and secure with screws (4 & 14).




- Attach cambolts (2) and dowels (1) to panels E & F.
   Attach shelves G & J and rails H & D to panel F. Secure shelves G & J with camlocks (3).



#### STEP 3:

- 1. Attach panel E to shelves G & J and rails H & D. Secure shelves G & J with camlocks (3).
- 2. Insert dowels (1) to the tops of panels E & F. Connect the two halves of the towers and secure with screws (4).



#### STEP 4:

- 1. Attach back panels O & P with screws (15).
- 2. Lay the tower on its side to attach doors M & N with screws (13).
- 3. Attach knobs (10) to the doors with screw (11).
- 4. Insert shelf pins (12) and rest adjustable shelf I on the shelf pins.

