

16" Lift and Turn Tubular Full Bath Waste Kit with Quick Test

Parts List

A. Stopper Assembly	I. Overflow Gasket
B. Spud	J. Retainer Nut
C. Drain Gasket	K. Overflow Faceplate
D. Drain Elbow	L. O-Ring
E. 1.5" Tee	M. Test Nut
F. Slip Nut	N. Test Cap
G. Gasket	O. Test Cap Gasket
H. Overflow Elbow	

Installation Instructions

1. Place the overflow gasket (I) onto the overflow elbow (H).
2. Insert the overflow elbow and gasket (H-I) into the tub overflow hole from the back of the tub.
3. Screw the retainer nut (J) onto the overflow elbow and gasket (H-I) from inside of the tub. Hand-tighten only.
4. Set the drain elbow (D) under the tub with the drain gasket (C) between drain elbow (D) and the tub.
5. Screw in the spud (B) through tub into the drain elbow (D). Use pliers to secure the spud (B) into the drain elbow (D).
6. Place a slip nut (F) (threads facing outward) and a gasket (G) on the drain elbow (D) and on the overflow elbow (H).
7. Set the 1.5" tee (E) in place in the drain line and tighten the slip nuts (F).
8. Screw the O-Ring (L) and test nut (M) onto the overflow elbow (H).
9. Screw the test cap gasket (O) and test cap (N) into the spud (B) and test the system.
10. Once testing is complete, remove the test cap gasket (O) and test cap (N), and remove the O-Ring (L) and test nut (M).
11. Snap on the overflow faceplate (K) with the slot facing downward.
12. Install the stopper assembly (A) into the spud (B).

