



Manufactured by:
Backyard Discovery
3305 Airport Drive, Pittsburg, KS 66762
800-856-4445

*Basepoint Business Centre: Rivermead Drive, Westlea, Swindon SN5 7EX Phone: 0800-118-2476 J.P. Coenstraat
7, The Bridge, The Hague, 2595 WP, Netherlands Phone: 08005678990*

14x12 WOODBURY GAZEBO GUTTER KIT

MODEL #: 9260368



Please visit www.backyarddiscovery.com


For the most up to date assembly manual, to register your product, or to order

replacement parts Para obtener instrucciones en español, visite

www.backyarddiscovery.com

OWNER'S MANUAL - PARTS IDENTIFICATION


Hardware Components




H101480 SCREW SELF TAPPING #9x1 BLK
(x14) 1/4 x 1



H101414 SCREW SELF PIERCING #8x1/2 BLK
(x10) #8 x 1/2




H101205 SCREW PWH BLK
(x8) 8x3/4



H100764 SCREW SETTER
(x1)




A6P01531 10 OZ SILICONE TUBE
(x1)




H101278 6" MAGNETIC DRIVER EXTENSION
(x1)

OWNER'S MANUAL - PARTS IDENTIFICATION


Hardware Components




A4M06238 DOWNSPOUT ELBOW - LONG
(x2) 3"x10 5/8"x10 11/16" [76x270x271]




A4M04765 GUTTER SPLICE
(x2) 2 1/2"x3 11/16"x5 1/16" [64x94x129]




A4M04782 DOWNSPOUT CLIP
(x4) 1 7/16"x1 7/16"x3 1/8" [37x37x79]



A4M04759 GUTTER HANGER
(x14) 3/4"x1"x4 15/16" [19x25x125]




A4M06684 DOWNSPOUT OFFSET - 8"
(x2) 3"x9 5/8"x12 9/16" [76x244x319]




A4M04761 DOWNSPOUT OUTLET
(x2) 1 7/16"x2 7/8" [37x73]



A4M04783 DOWNSPOUT - 60"
(x2) 2"x3"x60" [51x76x1525]



A4M06682 GUTTER W/ OUTLET
(x2) 3 11/16"x5 1/8"x83 5/16" [93x130x2117]




A4M06683 GUTTER
(x2) 3 11/16"x5 1/8"x83 5/16" [93x130x2117]

PRE-ASSEMBLY STEP 1 - SORTING PARTS

It is critical for ease of assembly that you take the time to sort and organize the parts and hardware.

HARDWARE PARTS:

- We recommend that you have a separate table to organize the hardware.
- Hardware bags are printed with a seven-digit, alpha-numeric part number.
- You can organize your hardware by part number or group by hardware type (e.g. bolts, nuts, etc.).
- During assembly you only need to reference the last four digits of the number.




TOOLS REQUIRED:



Cordless Drill or
Electric Drill



Caulk Gun




Tape Measure




1/8" Drill Bit

GUTTER SPLICE PAGE

- NOTE:**
- APPLY SILICONE TO INSIDE CHANNEL ON BOTH SIDES.
 - ENSURE SILICONE IS EVENLY APPLIED ALONG THE CHANNEL.
 - AFTER GUTTER SPLICE HAS BEEN SLID ONTO GUTTERS AND SILICONE HAS HAD TIME TO CURE, USING HAND PRESSURE ONLY, FOLD THE TOP TAB OVER EDGE OF GUTTER




- IMPORTANT:**
- APPLY SILICONE LIBERALLY INTO CORNERS AS INDICATED ABOVE.




WAIT APPROXIMATELY 45 MINUTES FOR SILICONE TO BECOME TACKY.
AFTER 24 HOURS, SILICONE HAS CURED AND CAN HOLD WATER

OFFSET ORIENTATION


TO ENSURE WATER FLOWS PROPERLY, IT IS IMPORTANT TO ORIENT DOWNSPOUT PIPING CORRECTLY. STARTING AT THE TOP, DOWNSPOUTS MUST FEED INTO THE NEXT SECTION AS SHOWN.




IF PIPING IS REVERSED, WATER WILL RUN OUT OF GAPS AROUND JOINTS



STEP 1 - GUTTER ASSEMBLY




A4M04761 DOWNSPOUT OUTLET
(x2)




A4M06682 GUTTER W/ OUTLET
(x2)

- APPLY A BEAD OF SILICONE UNDER THE LIP OF THE DOWNSPOUT OUTLET AND PLACE OUTLET INSIDE GUTTER.
- COMPLETE THIS STEP TWICE.




TIP: PRESSURE MAY NEED TO BE APPLIED TO GET OUTLET INTO POSITION. USE A WET FINGER TO FLATTEN SILICONE AFTER INSTALLED.




STEP 2 - GUTTER ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
2	H101480	SCREW SELF TAPPING #9x1 BLK




GUTTER W/ OUTLET - STEP 1
(x1)



4759 GUTTER HANGER
(x2)


- SLIDE GUTTER ASSEMBLY UP UNDER EDGE TRIM AND ENSURE IT IS SNUG AGAINST THE ROOF LINE.
- CENTER DOWNSPOUT OUTLET TO POST.
- INSTALL THE FIRST HANGER APPROXIMATELY 4" [100mm] FROM EDGE OF ROOF.
- INSTALL THE NEXT HANGER AT THE 9TH ROOF RIB
- USE A CLAMP TO HOLD GUTTER TO WOODEN BEAM FOR ASSISTANCE.
- PRE-DRILL A 1/8" [3mm] PILOT HOLE FOR EASE OF ASSEMBLY.



FLUSH THESE SURFACES

CENTER DOWNSPOUT OUTLET TO POST

DOWNSPOUT OUTLET




4759 (x2) GUTTER HANGER

ROOF RIB #1

UNDER DRIP EDGE SNUG TO ROOF SHEETS

POST






GUTTER HANGERS

GUTTER W/ OUTLET - STEP 1


STEP 3 - GUTTER ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
2	H101480	SCREW SELF TAPPING #9x1 BLK




- SLIDE GUTTER ASSEMBLY UP UNDER EDGE TRIM AND ENSURE IT IS SNUG AGAINST THE ROOF LINE.
- FLUSH SURFACES AS SHOWN.
- INSTALL THE FIRST HANGER APPROXIMATELY 4" [100mm] FROM EDGE OF ROOF.
- INSTALL THE NEXT HANGER AT THE 9TH ROOF RIB.
- USE A CLAMP TO HOLD GUTTER TO WOODEN BEAM FOR ASSISTANCE.
- PRE-DRILL A 1/8" [3mm] PILOT HOLE FOR EASE OF ASSEMBLY.


FLUSH THESE SURFACES



APPLY SILICONE TO SPLICE GROOVE BEFORE INSERTING INTO GUTTER



APPLY SILICONE TO SPLICE GROOVE BEFORE INSERTING GUTTER INTO SPLICE




GUTTER HANGERS


6683 (x1) GUTTER

STEP 4 - GUTTER ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
2	H101480	SCREW SELF TAPPING #9x1 BLK




GUTTER W/ OUTLET - STEP 1
(x1)




4759 GUTTER HANGER
(x2)

- SLIDE GUTTER ASSEMBLY UP UNDER EDGE TRIM AND ENSURE IT IS SNUG AGAINST THE ROOF LINE.
- CENTER DOWNSPOUT OUTLET TO POST.
- INSTALL THE FIRST HANGER APPROXIMATELY 4" [100mm] FROM EDGE OF ROOF.
- INSTALL THE NEXT HANGER AT THE 9TH ROOF RIB
- USE A CLAMP TO HOLD GUTTER TO WOODEN BEAM FOR ASSISTANCE.
- PRE-DRILL A 1/8" [3mm] PILOT HOLE FOR EASE OF ASSEMBLY.



FLUSH THESE SURFACES

CENTER DOWNSPOUT OUTLET TO POST



1480 (x2) SCREW - 1"


4759 (x2) GUTTER HANGER

ROOF RIB #1

UNDER DRIP EDGE SNUG TO ROOF SHEETS

DOWNSPOUT OUTLET

POST






GUTTER HANGERS

GUTTER W/ OUTLET - STEP 1


STEP 5 - GUTTER ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
2	H101480	SCREW SELF TAPPING #9x1 BLK




- SLIDE GUTTER ASSEMBLY UP UNDER EDGE TRIM AND ENSURE IT IS SNUG AGAINST THE ROOF LINE.
- FLUSH SURFACES AS SHOWN.
- INSTALL THE FIRST HANGER APPROXIMATELY 4" [100mm] FROM EDGE OF ROOF.
- INSTALL THE NEXT HANGER AT THE 9TH ROOF RIB.
- USE A CLAMP TO HOLD GUTTER TO WOODEN BEAM FOR ASSISTANCE.
- PRE-DRILL A 1/8" [3mm] PILOT HOLE FOR EASE OF ASSEMBLY.


FLUSH THESE SURFACES




APPLY SILICONE TO SPLICE GROOVE BEFORE INSERTING INTO GUTTER




APPLY SILICONE TO SPLICE GROOVE BEFORE INSERTING GUTTER INTO SPLICE




GUTTER HANGERS




STEP 6 - GUTTER ASSEMBLY



A4M06238 DOWNSPOUT ELBOW - LONG
(x2)




A4M06684 DOWNSPOUT OFFSET - 8"
(x2)




A4M04783 DOWNSPOUT - 60"
(x2)

- INSERT TAPERED ENDS INTO LARGER ENDS.
- NOTE ORIENTATION OF DOWNSPOUT OFFSET. SEE DOWNSPOUT OFFSET PAGE FOR DETAIL.
- COMPLETE THIS STEP 2 TIMES.



STEP 7 - GUTTER ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
6	H101205	SCREW PWH 8x15x3/4 BLK




A4M04782 DOWNSPOUT CLIP
(x4)

- IT IS IMPORTANT TO CENTER 6338 CLIPS AND HARDWARE ON POST.
- COMPLETE THIS STEP ON THE 2 POSTS WHERE DOWNSPOUTS ARE LOCATED.

ATTENTION:
IF MOSQUITO NETTING IS ATTACHED, ZIP NETTING TOGETHER TO ENSURE IT CLOSES COMPLETE AND IS PULLED TIGHTLY, THEN FASTEN CLIP ON OUTSIDE OF NETTING.

NETTING MUST BE BETWEEN POST AND DOWNSPOUT CLIP




74-1/2" [1890mm]

2 DOWNSPOUT CLIPS ON BACK POST

13-3/4" [350mm]


STEP 8 - GUTTER ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
2	H101414	SCREW SELF PIERCING #8x1/2 BLK



DOWNSPOUT ASSEMBLY - STEP 6
(x2)


- FASTEN DOWNSPOUT TO DOWNSPOUT OUTLETS USING HARDWARE PROVIDED.
- COMPLETE THIS STEP AT ALL BOTH CORNERS WITH A DOWNSPOUT.
- DOWNSPOUT WILL NOT REST ON THE GROUND, THERE WILL BE FLOATING SPACE.



STEP 9 - GUTTER ASSEMBLY


QTY	PART NUMBER	DESCRIPTION
8	H101414	SCREW SELF PIERCING #8x1/2 BLK

- FASTEN DOWNSPOUT CLIPS TO DOWNSPOUT.
- COMPLETE THIS STEP AT BOTH DOWNSPOUTS.




STEP 10 - GUTTER ASSEMBLY

QTY	PART NUMBER	DESCRIPTION
6	H101480	SCREW SELF TAPPING #9x1 BLK



A4M04759 GUTTER HANGER
(x6)

- ATTACH ALL REMAINING GUTTER HANGERS
- IT IS RECOMMENDED TO ATTACH THE MIDDLE HANGER FIRST THEN ATTACH THE REMAINING HANGERS.
- HANGERS SHOULD BE EVENLY SPACED.



ATTACH MIDDLE HANGERS FIRST

ATTACH MIDDLE HANGERS FIRST

STEP 11 - GUTTER ASSEMBLY

- IT IS RECOMMENDED TO APPLY A SECOND BEAD OF SILICONE AT THE GUTTER SPLICE AFTER THE GUTTER HAS BEEN INSTALLED.
- BY WETTING ONES FINGER, GENTLY PUSH CAULK INTO SPLICE TAB AND CORNERS TO ENSURE PROPER SEALING.
- SEE BELOW FOR DETAILS.

