

Attach rear mounting block to the back of the shelf instead of notching and boring.



## 1/4" (6mm) 1/8" (3mm) Setback

## Align inside of mounting block tip with the inside apron edge

## FRONT VIEW OF THE SHELF INSIDE THE CABINET

## **OUTSIDE SHELF WIDTH CALCULATIONS**

| - INSIDE CABINET WIDTH   |                   |
|--|-------------------|
| - OUTSIDE SHELF WIDTH  |                   |
| MAX SHELF RUNNER THICKNESS ——————————————————————————————————— | 24.30<br>(15/16") |
| MAX SHELF RUNNER HEIGHT 16 (5/8")                              | 36.3<br>(1-7/16") |
|  |                   |

| Drawer Side<br>Thickness | Inside Cabinet Width Deduction |
|--------------------------|--------------------------------|
| 5/8"                     | 3/8"                           |
| 16mm                     | 10mm                           |
| <b>19/32"</b>            | <b>15/32"</b>                  |
| 15mm                     | 12mm                           |
| 9/16"                    | <b>9/16"</b>                   |
| 14mm                     | 14mm                           |
| 1/2"                     | 5/8"                           |
| 13mm                     | 16mm                           |
| <b>15/32"</b>            | 23/32"                         |
| 12mm                     | 18mm                           |

NOTE: Shelf length = length of slide minus 13/32" (10mm)

