




bestchoiceproducts



INSTRUCTION MANUAL

Set of 4 Infrared Laser Tag
Blasters & Vests



bestchoiceproducts

As shoppers, we're always trying to find the perfect balance between quality & value. At BCP, we believe we've achieved that. Our diverse catalog of everyday essentials is tailored especially to our customers & guaranteed to hit that sweet spot of high quality & low price.

— Always. —

NOTICE

Please retain these instructions for future reference.

- Avoid exposure to direct sunlight and excessive heat.
- Do not immerse product in water.
- Do not alter this product in any way as it may result in personal injury, product failure, and property damage.
- If any parts are missing, broken, damaged, or worn, stop using this product until repairs are made and/or factory replacement parts are installed.
- Do not use this item in a way inconsistent with manufacturer's instructions as this could void the product warranty.

REQUIRED



PHILLIPS
SCREWDRIVER



3 AAA BATTERIES
PER BLASTER



3 AAA BATTERIES
PER VEST



8 YEARS
OLD AND UP




1 PERSON
ASSEMBLY



UP TO 5 MIN.
ASSEMBLY



BLASTER DIAGRAM

- **LIFE INDICATORS (3):** Each life indicator represents 3 health (for a total of 9).
- **LOW BATTERY:** The 3 life indicators will flash slowly to indicate that the blaster has low battery.
- **MAX STRIKE DISTANCE:** 40 meter



VEST DIAGRAM



- **INFRARED RECEIVER:** Vibrates and flashes colors when hit
- **LIGHT INDICATOR:** Displays team color
- **LIFE INDICATORS (4):** Each life indicator represents 3 health (for a total of 12)



NOTE: When vest and gun are paired, only the health points of the vest are active (12 health points).


BATTERY INSTALLATION - BLASTER & VEST

1. Use a screwdriver to remove the battery covers.
2. Insert 3 AAA batteries into the blasters and 3 AAA batteries into the vests. Make sure the batteries are inserted with the correct polarity.
3. Replace & secure battery covers.



VEST INSTRUCTIONS

1. Place vest strap over your neck.
2. Fasten the buckle in the back. Tighten the straps until secure.



OPERATING INSTRUCTIONS

- 1 Switch the blaster on. The blaster will default to pistol mode.
- 2 Press the team selection button to toggle between teams. There are 4 colors to represent possible teams—Blue, red, yellow, and white. You cannot fire upon your own team. A player cannot change teams during a game.
- 3 Switch the vest on and it will cycle through different colors. Use the blaster to shoot the vest and turn the color of your team. The vest is now assigned to your team. The blaster and vest will flash slowly, the infrared receivers are now synchronized and share health points (12 points total).
- 4 Press the Fire-Type Selection button to toggle between four firing modes:

FIRING MODES	Single Shot	Laser Gun	Machine Gun	Plasma Gun
SHOTS				
HEALTH REDUCED BY EACH SHOT				


When you run out of ammo, press the reload button under the grip to reload.

OPERATING INSTRUCTIONS

5 Aim and fire at an opponent's blaster or vest to register a hit. Once hit, the life indicator will reduce accordingly and the blaster/vest will vibrate and emit a sound. Each life indicator will show a different level of health:

- 1 health point lost = Life indicator flashes slowly.
- 2 health points lost = Life indicator flashes quickly.
- 3 Health points lost = Life indicator will be dark.

When all life indicators reach 0, the indicator will be dark and you will be unable to fire anymore.



RESET BLASTER & VEST

- A player cannot change teams or reset a blaster/vest during a game.
- Press the team selection button to change your team before a game.
- To reset a blaster/vest, switch the blaster/vest off and on again.

TROUBLESHOOTING

PROBLEM	REASON	SOLUTION
Blasters do not work	Low battery	Replace the batteries
	Infrared signal could not reach the blaster because the distance is too far or angle is wrong	Reduce the firing distance and firing angle
	Obstacles blocking the infrared signal	Remove the obstacles
Blasters operate automatically	Low battery	Replace the batteries
	Overexposure to direct sunlight	Block sunlight or play in an area without direct sunlight
	Competing infrared transmission from other devices, such as TV remotes	Stop using or move away from competing infrared devices

NOTE: If normal operation of the product is disturbed or interrupted, strong electro-magnetic interference may be causing a problem. Reset the product by turning it completely off and then back on. If normal operation does not resume, try replacing the batteries and moving the product to another location.

WARNINGS REGARDING BATTERIES

- Do not mix alkaline, standard (carbon zinc) and rechargeable (nickel hydride) batteries.
- Do not mix old and new batteries.
- Non-rechargeable batteries should not be charged.
- Rechargeable batteries should be charged under adult supervision only.
- Exhausted batteries should be removed.
- The supply terminals should not be short-circuited.
- Do not put batteries next to or in a heat source (fire, electronic heating device, etc.).
- Do not hit batteries against hard objects.
- Do not submerge batteries in water.
- Batteries should be inserted with the correct polarity.

MAINTENANCE & REPAIR

- If this item will not be used for an extended period, remove all batteries to prevent degradation and damage.
- Clean off dust with a dry cloth.
- Do not leave this product exposed to excessive heat or sunlight.

FCC COMPLIANCE STATEMENT

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This product may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Responsible party (contact for FCC matters only):

Quality Control Dept.
15101 Red Hill Ave.
Tustin, CA 92780



HELP CENTER



Question about your product? We're here to help. Visit us at:

help.bestchoiceproducts.com



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

PRODUCT WARRANTY INFORMATION

All items can be returned for any reason within 60 days of the receipt and will receive a full refund as long as the item is returned in its original product packaging and all accessories from its original shipment are included. All returned items will receive a full refund back to the original payment method. All returned items will not be charged a re-stocking fee.

All returned items require an RA (Return Authorization) number, which can only be provided by a Best Choice Products Customer Service Representative when the return request is submitted. Items received without an RA may not be accepted or may increase your return processing time. Once an item has been received by Best Choice Products, refunds or replacements will be processed within 5 business days.

All returns must be shipped back to the Best Choice Products Return Center at the customer's expense. If the reason for return is a result of an error by Best Choice Products then Best Choice Products will provide a pre-paid shipping label via email. Boxes for return shipping will not be provided by Best Choice Products, and is the customer's responsibility to either use the original shipping boxes or purchase new boxes.

Pictures may be required for some returns to ensure an item is not damaged prior to its return. Items returned are not considered undamaged until they are received by Best Choice Products and verified as such. All damages to items are the customer's responsibility until the item has been received by and acknowledge by Best Choice Products as undamaged.

WARNING

Manufacturer and seller expressly disclaim any and all liability for personal injury, property damage or loss, whether direct, indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, unapproved modification, or neglect of this product.