

Item: LEEB4C

Assembly Instructions





Please visit our website for the most current instructions, assembly tips, to report damage or request parts. www.walkerediton.com


Revised 09/2024-V3

General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver and hammer are required for the assembly of this product.



- VI. Power tools should not be used to assemble this product.




VII. Maintenance Guide

To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.

1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.











Parts List




| Part# | Description | Qty |
|-------|------------------|--------|
| 06 | Drawer front | 02 pcs |
| 15 | Top crossbeam | 01 pc |
| 17 | Drawer runner | 04 pcs |
| 24 | Left side panel | 01 pc |
| 26 | Right side panel | 01 pc |
| 28 | Top panel | 01 pc |
| 30 | Back panel | 01 pc |
| 32 | Base panel | 01 pc |

| Part# | Description | Qty |
|-------|------------------------|--------|
| 33 | Bottom side crossbeam | 02 pcs |
| 34 | Bottom front crossbeam | 02 pcs |
| 36 | Leg | 04 pcs |
| 45 | Drawer back | 02 pcs |
| 46 | Drawer left side | 02 pcs |
| 47 | Drawer right side | 02 pcs |
| 48 | Drawer bottom | 02 pcs |

Hardware List

| | | | | |
|---|---|-----------|--------------|--------|
| A |  | Ø8*30mm | Wooden dowel | 41 pcs |
| B |  | Ø10*20mm | Wooden dowel | 12 pcs |
| C |  | Ø4,0*40mm | Screw | 22 pcs |
| D |  | Ø3,0*12mm | Screw | 04 pcs |
| E |  | Ø15*12mm | Cam lock | 08 pcs |
| F |  | Ø6*31mm | Cam bolt | 08 pcs |
| G |  | Ø3,5*30mm | Screw | 18 pcs |
| H |  | Ø8*40mm | Wooden dowel | 04 pcs |
| I |  | Ø4,0*25mm | Screw | 12 pcs |
| J |  | | Handle | 02 pcs |



Hammer recommended
for assembly (not included)


Phillips head screwdriver required
for assembly (not included)




*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1



4x




Attention to the
dowel size:
Ø10*20mm



Insert wood dowel (B)
into parts 17.




Step 2




Please assemble on
a clean soft surface
to avoid damage.







Insert wood dowel (A) into parts 15, 24, 26, 28, 33,
34, 36, 46 and 47.




Step 3



1 - Ensure cam bolt is installed straight and not at an angle.
2 - Tighten cam bolt until shoulder on cam bolt is flush. Do not over-tighten.





Attach cam bolt (F) into the holes in parts 24 and 26 with Phillips head screwdriver.




Step 4

Secure parts 17 to parts 24 and 26 with screw (I) and Phillips head screwdriver.




| | | |
|-----------|---|----|
| I |  | 12 |
| Ø4,0*25mm | | |


Step 5




Secure part 28 to part 15 with screw (G) and Phillips head screwdriver.




Step 6





Align the opening in cam lock to the cam bolt and press into opening. Using a screwdriver, rotate the cam lock until it engages with the cam bolt and locks in place (anywhere between 90-180 degrees). Do not over-tighten the cam lock. Doing so may result in damaged or broken parts.




Fit parts 28 and 15 to part 26. Insert Cam lock (E) in the hole of the parts 28 and 15 and attach with Phillips head screwdriver.




Step 7



Fit part 24 to parts 28 and 15.
Insert Cam lock (E) in the hole of the parts 28 and 15
and attach with Phillips head screwdriver.






Step 8




Insert part 30 into parts 24, 26 and 28.



Step 9




Secure part 32 to parts 24 and 26 with screw (C) and Phillips head screwdriver.




Step 10


Secure parts 34 to parts 36 with screw (C) and Phillips head screwdriver.




Step 11



Secure parts 33 to parts 36 with screw (C) and Phillips head screwdriver.




Step 12






Fit parts 34 and 36 to part 32.

Secure parts 33 and 34 to part 32 with screw (C) and Phillips head screwdriver.




Step 13

Rotate 90°




FRONT


Insert wood dowel (A) into the front hole in the wood slider 17.




Step 14




Secure parts 46 and 47 to parts 06 with screw (G) and Phillips head screwdriver.



Step 15







Insert part 48 into grooves to the parts 46 and 47, and secure part 45 with screw (G) and Phillips head screwdriver.



Step 16




Attach Handle (J) with screw (D) and Phillips head screwdriver.




| | | |
|--------------------------|---|----|
| D |  | 04 |
| <small>Ø3.0*12mm</small> | | |
| J |  | 02 |

Step 17

Insert wood dowel (H) on the inside of all drawers, with the drawer inside the unit after having passed the wood dowel that is in the drawer slide. The dowel is not flush with the panel, it is a little inside the drawer to help when you need to remove the lock dowel to remove the drawer.



| | | |
|------------------------|---|----|
| H |  | 04 |
| <small>Ø8*50mm</small> | | |

Step 18

Assembly Complete!

