


SUMMERSIDE SWING SET



OBSTACLE FREE SAFETY ZONE - 27' 1-11/16" L x 22' 9-5/16" D x 16' 1-5/16" H (8.27 x 6.94 x 4.91 m) area requires

Protective Surfacing. See page 4.









INSTALLATION AND OPERATING INSTRUCTIONS

FOR 24/7 ONLINE PARTS REPLACEMENT

parts.kidkraft.com

Backyard Kids, LLC DBA KidKraft 317 S. Main St. Ann Arbor, MI 48104

customerservice@kidkraft.com 1.800.933.0771 972.385.0100

9409885

Rev 04/24/2025

AWARNING

To reduce the risk of serious injury or death, please read and follow these instructions. Keep and refer to instructions as needed and pass along to any future owners of this item.

Congratulations on purchasing a KidKraft product!

Our items are made of high-quality, durable Cunninghamia Lanceolata wood from the cypress family.

Lumber from these trees are known for their light weight and excellent strength. The porosity of this wood allows the moisture to absorb and evaporate in the fibers, resisting rot and bugs.

Engineered for great play, our products also go through extensive testing for safety.

Plus, our team has developed a series of proprietary methods for a simpler, more organized assembly. Less build time and more play time is our motto!

However, during assembly if you have any questions or concerns, please reach out. Our Customer Service can help with missing parts, instructions or maintenance.



Warnings and Safe Play Instructions



CONTINUOUS ADULT SUPERVISION REQUIRED. Most serious injuries and deaths on playground equipment have occurred while children were unsupervised! Our products are designed to meet mandatory and voluntary safety standards. Complying with all warnings and recommendations in these instructions will reduce the risk of serious or fatal injury to children using this play system. Go over the warnings and safe play instructions regularly with your children and make certain that they understand and follow them. Remember on-site adult supervision is required for children of all ages.



WARNING

SERIOUS HEAD INJURY HAZARD

Installation over concrete, asphalt, dirt, grass, carpet and other hard surface creates a risk of serious injury or death from falls to the ground. Install and maintain shock absorbing material under and around play-set as recommended on page 4 of these instructions.

COLLISION HAZARD

Place play-set on level ground at least 2m from any obstruction such as a garage or house, fences, poles, trees, sidewalks, walls, landscape timbers, rocks, pavement, planters, garden borders, overhanging branches, laundry lines, and electrical wires. (See OBSTACLE FREE SAFETY ZONE on cover)

CHOKING HAZARD/SHARP EDGES & POINTS

Adult assembly required. This product contains small parts and parts with sharp edges and points. Keep parts away from children until fully assembled.

WARNING LABEL

Owners shall be responsible for maintaining the legibility of the warning labels.

STRANGULATION HAZARD

- NEVER allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this play-set or to attach these items to play-set.
- NEVER allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, items with draw-strings, cords or ties when using this play-set.
- NEVER allow children to wear bike or sport helmets when using this play-set.

Failure to prohibit these items, even helmets with chin straps, increases the risk of serious injury and death to children from entanglement and strangulation.

TIP OVER HAZARD

Choose a level location for the equipment. This can reduce the likelihood of the play set tipping over and loose-fill surfacing materials washing away during heavy rains.

DO NOT allow children to play on the play-set until the assembly is complete and the unit is properly anchored.

Never add extra length to chain or rope. The chains or ropes provided are the maximum length designed for the swinging element(s).



WARNING – Safe Play Instructions

- Observe capacity limitations of your play-set. See front cover.
- Dress children with well fitting and full foot enclosing footwear.
- Teach children to sit with their full weight in the center of the swing seat to prevent erratic swing motion or falling off.
- ✓ Check for splintered, broken or cracked wood; missing, loose, or sharp edged hardware. Replace, tighten and or sand smooth as required prior to playing.
- ✓ Verify that suspended climbing ropes, rope ladders, chain or cable are secured at both ends and cannot be looped back on itself as to create an entanglement hazard.
- On sunny and or hot days, check the slide and other plastic rides to assure that they are not very hot as to cause burns. Cool hot slide and rides with water and wipe dry prior to using.
- ✓ Orientate slide such that it gets the least amount of exposure to the sun.

- ➤ Do not allow children to wear open toe or heel footwear like sandals, flip-flops or clogs.
- Do not allow children to walk, in front, between, behind or close to moving rides.
- Do not let children twist swing chains or ropes or loop them over the top support bar. This may reduce the strength of the chain or rope and cause premature failure.
- X Do not let children get off rides while they are in motion.
- > Do not permit climbing on equipment when it is wet.
- ➤ Do not permit rough play or use of equipment in a manner for which it was not intended. Standing on or jumping from the roof, elevated platforms, swings, climbers, ladders or slide can be dangerous.
- > Do not allow children to swing empty rides or seats.
- Do not allow children to go down slide head first or run up slide.





A Protective Surfacing - Reducing Risk of Serious Head Injury From Falls

One of the most important things you can do to reduce the likelihood of serious head injuries is to install shock-absorbing protective surfacing under and around your play equipment. The protective surfacing should be applied to a depth that is suitable for the equipment height in accordance with ASTM F1292. There are different types of surfacing to choose from; whichever product you select, follow these guidelines:

Loose-Fill Materials

- Maintain a minimum depth of 9 inches (23 cm) of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet (2.45 m) high; and 9 inches (23 cm) of sand or pea gravel for equipment up to 5 feet (1.5 m) high. NOTE: An initial fill level of 12 inches (31 cm) will compress to about a 9-inch (23 cm) depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically raked and refilled to maintain at least a 9-inch (23 cm) depth.
- Use a minimum of 6 inches (16 cm) of protective surfacing for play equipment less than 4 feet (1.22 m) in height. If maintained properly, this should be adequate. (At depths less than 6 inches (16 cm), the protective material is too easily displaced or compacted.)

NOTE: Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are not adequate protective surfacing. Ground level equipment -- such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface -- does not need any protective surfacing.

- Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.
- Periodically rake, check and maintain the depth of the loose-fill surfacing material. Marking the correct depth on the play equipment support posts will help you to see when the material has settled and needs to be raked and or replenished. Be sure to rake and evenly redistribute the surfacing in heavily used areas.
- Do not install loose fill surfacing over hard surfaces such as concrete or asphalt.


Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles


You may be interested in using surfacing other than loose-fill materials - like rubber tiles or poured-in-place surfaces.

- Installations of these surfaces generally require a professional and are not "do-it yourself" projects.
- Review surface specifications before purchasing this type of surfacing. Ask the installer/manufacturer for a report showing that the product has been tested to the following safety standard: ASTM F1292 Standard Specification for Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment. This report should show the specific height for which the surface is intended to protect against serious head injury. This height should be equal to or greater than the fall height - vertical distance between a designated play surface (elevated surface for standing, sitting, or climbing) and the protective surfacing below - of your play equipment.
- Check the protective surfacing frequently for wear.

Proper placement and maintenance of protective surfacing is essential. Refer to diagram on front cover. Be sure to;

- Extend surfacing at least 6 feet (1.8 m) from the equipment in all directions.
- For to-fro swings, extend protective surfacing in front of and behind the swing to a distance equal to twice the height of the top bar from which the swing is suspended.
- For tire swings, extend surfacing in a circle whose radius is equal to the height of the suspending chain or rope, plus 6 feet (1.8 m) in all directions.





From the CPSC Outdoor Home Playground Safety Handbook. At http://www.playgroundregs.com/resources/CPSC%20324.pdf




Instructions for Proper Maintenance

Your KidKraft Play System is designed and constructed of quality materials with your child's safety in mind. As with all outdoor products used by children, it will weather and wear. To maximize the enjoyment, safety and life of your Play Set, it is important that you, the owner, properly maintain it. Failure to follow maintenance directions below can cause the swing set to overturn or otherwise become a hazard to children.


Check the following at the beginning of the play season:

HARDWARE:

- ✓ Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303.
- ✓ Inspect and tighten all hardware. On wood assemblies DO NOT OVER-TIGHTEN as to cause crushing and splintering of wood.



✓ Check for sharp edges or protruding screw threads, add washers if required.



SHOCK ABSORBING SURFACING:

✓ Check for foreign objects. Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 4)

GROUND STAKES (ANCHORS):

✓ Check for looseness, damage or deterioration. Should firmly anchor unit to ground during use. Re-secure and or replace, if necessary.

SWING HANGERS:

- ✓ Check that bolts are secure and tight. Quick clips should be completely closed and threaded clips screwed tight.
- ✓ If squeaking occurs lubricate bushings with oil or WD-40®. SWINGS, ROPES AND RIDES:
- ✓ Reinstall if removed during cold season. Check all moving parts including swing seats, ropes, chains and attachments for wear, rust and other deterioration. Replace as needed.
- ✓ Check that ropes are tight, secure at both ends and cannot loop back as to create an entrapment.

WOOD PARTS:

- ✓ Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal.
- ✓ Applying a water repellent or stain (water-based) on a yearly basis is important maintenance to maintain maximum life and performance of the product.

Check twice a month during play season:

HARDWARE:

- ✓ Inspect for tightness. Must be firmly against, but not crushing the wood. DO NOT OVER-TIGHTEN. This will cause splintering of wood.
- ✓ Check for sharp edges or protruding screw threads. Add washers if required.

SHOCK ABSORBING SURFACING:

✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 4)

Check once a month during play season:

SWING HANGERS:

- ✓ Check that they are secure and orientated correctly. Hook should rotate freely and perpendicular to support beam.
- ✓ If squeaking occurs lubricate bushings with oil or WD-40®.

SWINGS AND RIDES:

✓ Check swing seats, all ropes, chains and attachments for fraying, wear, excessive corrosion or damage.

Replace if structurally damaged or deteriorated.

Check at the end of the play season:

SWINGS AND RIDES:

✓ To prolong their life, remove swings and store inside when outside temperature is below 32°F/0°C. Below freezing, plastic parts may become more brittle.

SHOCK ABSORBING SURFACING:

✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 4)

If you dispose of your play set: Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.



About Our Wood

KidKraft Premium Play Systems uses only premium playset lumber, ensuring the safest product for your children's use. Although we take great care in selecting the best quality lumber available, wood is still a product of nature and susceptible to weathering which can change the appearance of your set.

What causes weathering? Does it affect the strength of my Play System?

One of the main reasons for weathering is the effects of water (moisture); the moisture content of the wood at the surface is different than the interior of the wood. As the climate changes, moisture moves in or out of the wood, causing tension which can result in checking and or warping. You can expect the following due to weathering. These changes will not affect the strength of the product:

- 1. **Checking** is surface cracks in the wood along the grain. A post 4" x 4" (101mm x 101mm) will experience more checking than a board 1" x 4" (25mm x 101mm) because the surface and interior moisture content will vary more widely than in thinner wood.
- 2. **Warping** results from any distortion (twisting, cupping) from the original plane of the board and often happens from rapid wetting and drying of the wood.
- 3. **Fading** happens as a natural change in the wood color as it is exposed to sun-light and will turn a grey over time.

How can I reduce the amount of weathering to my Play System?

At the factory we have coated the wood with a water repellent or stain. This coating decreases the amount of water absorption during rain or snow thus decreasing the tension in the wood. Sunlight will break down the coating, so we recommend applying a water repellent or stain on a yearly basis (see your local stain and paint supplier for a recommended product).

Most weathering is just the normal result of nature and will not affect safe play and enjoyment for your child. However if you are concerned that a part has experienced a severe weathering problem please call our consumer relations department for further assistance.

Complete and mail registration card to receive important product notifications and assure prompt warranty service.



KidKraft Limited Warranty

MISSING OR DAMAGED PARTS:

KidKraft will replace any parts within 90 days from date of delivery found to be missing from or damaged in the original packaging. See Fig.1

Fig. 1 Product Age (All Parts) Consumer Pays

0-90 Days from date of delivery \$0 for Part + Free Shipping

DEFECTS IN MATERIAL AND WORKMANSHIP:

KidKraft warrants that this product is free from defects in materials and workmanship for a period of one (1) year from the original date of delivery (dated sales receipt and/or product registration is required). This one (1) year warranty covers all parts including wood, hardware, and all accessories (Such as swings, rides, and slides). See Fig. 2

Fig. 2 Product Age (All Parts) Consumer Pays

91 Days to 1 Year \$0 for Part + Free Shipping

WOOD ROT, DECAY, AND INSECT DAMAGE:

All wood carries a five (5) year warranty against rot, decay, and insect damage (dated sales receipt and/or product registration is required). Refer to the schedule below for charges associated with replacement of wood parts under this **Limited Warranty.** See Fig. 3

Fig. 3 Product Age (Wood Parts) Consumer Pays

0 Days to 1 Year \$0 for Part + Free Shipping

After 1 Year to 5 Year \$0 for Part + Shipping & Handling

Over 5 Years 100% for Part (if available) + Shipping & Handling

This warranty applies to the original owner and registrant and is non-transferable. Regular maintenance is required to ensure the integrity of this product. Failure by the owner to maintain the product according to the maintenance requirements may void this warranty.

This Limited Warranty does NOT cover:

- Any inspection cost
- Labor and/or costs for replacement of any defective item(s), including but not limited to, professional installer costs
- Incidental or consequential damages, including but not limited to, as a result of set relocation, move and/or reinstall
- Cosmetic defects which do not affect performance or integrity of a part or the entire product
- Vandalism, improper use or installation, or acts of nature, including but not limited to, high winds, fire, and flood
- Minor twisting, warping, checking, or any natural occurring properties of wood that do not affect performance or integrity.
- Any KidKraft product purchased, including but not limited to, a non-approved retailer, auction houses, second-hand, and as-is clearance items.

KidKraft products have been designed for safety and quality. Modifications made to the original product may damage the structural integrity of the unit leading to failure and possible injury. KidKraft cannot assume any responsibility for the modified products. Furthermore, modifications void all warranties.

This product is warranted for **RESIDENTIAL USE ONLY**. Under no circumstance should a KidKraft product be used in public settings such as schools, churches, playgrounds, parks, home and professional day cares and the like. Such use may lead to product failure and failure and potential injury. Public use will void this warranty. KidKraft disclaims all other representations and warranties of any kind, express of implied.




Keys to Assembly Success

Tools Required

- Tape Measure
- Carpenter's Level
- Carpenter's Square
- Claw Hammer
- Standard or Cordless Drill
- Rubber Mallet
- #1 Phillips and #2 Robertson Screwdrivers
- Ratchet with Extension 1/2" (13mm) & 7/16" (11mm)
- · Open-End Wrench 1/2" (13mm) & 7/16" (11mm)
- · Adjustable Wrench
- 1/8" (3mm) Drill Bit
- 3/16" (5mm) Hex Key
- 8' (2.4m) Step Ladder
- · Safety Glasses
- Adult Helpers
- Pencil

Part Identification Key

Listed on each page are the parts and quantities required to complete the assembly step illustrated on that page.



Symbols

Throughout these instructions, symbols are provided as important reminders for proper and safe assembly.


This identifies information that requires special attention. Improper assembly could lead to an unsafe or dangerous condition.

Use





Where this is shown, 2 or 3 people



Use

Distance

are required to safely complete the step. To avoid injury or damage to the assembly, make sure to get help!

Check that assembly is square



before tightening bolts.

Use a measuring tape to ensure



before proceeding.

Use Leve1

Pre-drill 1/8" (3mm) Bit



Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.

Check that the set or assembly is properly level



This indicates time to tighten bolts, but not too tight! Do not crush the wood. This may create splinters and cause structural damage.






CAUTION – Protrusion Hazard

Once the assembly is tightened, watch for exposed threads. If a thread protrudes from the T-nut, remove the bolt and add washers to eliminate this condition. Extra washers have been provided for this purpose.

proper location.





Proper Hardware Assembly

Lag screws require drilling pilot holes to avoid splitting wood. Only a flat washer is required. For ease of installation, liquid soap can be used on all lag-type screws.

For bolts, tap T-nut into hole with hammer. Insert the hex bolt through lock washer first, then flat washer, then hole. Because the assemblies need to be squared, do not completely tighten until instructed. Pay close attention to diameter of the bolts. 5/16" (8mm) is slightly larger than 1/4" (6.4mm)

Note: Wafer head bolts with blue lock tight or a bolt with a Nylock® nut do NOT require a lock washer.








(Hammer into place) Do not crush wood!



parts.kidkraft.com





4x - 11764 - 31.8 mm x 76.2 mm x 304.8 mm - 37311764				
0 1-1/4" x 3" x 12"				
1x - 11765 - 25.4 mm x 76.2 mm x 914.4 mm - 37311765				
° 1" x 3" x 36"				
1x - 11766 - 25.4 mm x 76.2 mm x 614.3 mm - 37311766				
° 1" x 3" x 24-3/16"				
4x - 11767 - 15.9 mm x 76.2 mm x 625.5 mm - 37311767				
. 5/8" x 3" x 24-5/8"				
2x - 11770 - 15.9 mm x 114.3 mm x 467 mm - 35811770				
5/8" x 4-1/2" x 18-3/8"				
1x - 11772 - 50.8 mm x 133.4 mm x 2235.2 mm - 37311772			2" x 5-1/4	l" x 88"
OTT TT	11 	7 / 	17 	0
3x - 11780 - 31.8 mm x 63.5 mm x 180.9 mm - 37311780				
1-1/4" x 2-1/2" x 7-1/8"				
2x - 11781 - 15.9 mm x 114.3 mm x 468.31 mm - 35811781				
• • • 5/8" x 4-1/2" x 18-7/16"				
• •				
2x - 11782 - 31.8 mm x 63.5 mm x 241.3 mm - 37311782				
1-1/4" x 2-1/2" x 9-1/2"				
4x - 11784 - 34.9 mm x 85.7 mm x 236.6 mm - 37311784				
1-3/8" x 3-3/8" x 9-5/16"				
1x - 11788 - 25.4 mm x 76.2 mm x 1409.7 mm - 37311788				
• • •	•]	1" x 3" x 55-1/2"		
3x - 11789 - 31.8 mm x 76.2 mm x 304.8 mm - 37311789				
1-1/4" x 3" x 12"				
4x - 11802 - 31.8 mm x 88.9 mm x 794.7 mm - 35811802				
• • 1-1/4" x 3-1/2" x 31-5/1	6"			
<u></u>				



· · · · · · · · · · · · · · · · · · ·	
1x - 11804 - 31.8 mm x 76.2 mm x 589 mm - 37311804	
° 1-1/4" x 3" x 23-3/16"	
1x - 11806 - 25.4 mm x 63.5 mm x 152.4 mm - 37311806	
1" x 2-1/2" x 6"	
1x - 11816 - 50.8 mm x 133.4 mm x 1955.8 mm - 37311816 2" x	5-1/4" x 77"
	0
2x - 11817 - 15.9 mm x 63.5 mm x 468.3 mm - 37311817	
5/8" x 2-1/2" x 18-7/16"	
1x - 11818 - 31.8 mm x 133.4 mm x 914.4 mm - 37311818	
° ° 1-1/4" x 5-1/4" x 36"	
2x - 11819 - 34.9 mm x 85.7 mm x 2298.7 mm - 37311819	1-3/8" x 3-3/8" x 90-1/2"
o	
1x - 11820 - 31.8 mm x 88.9 mm x 1117.6 mm - 37311820	
: 1-1/4" x 3-1/2" x 44"	
1x - 11822 - 34.9 mm x 85.7 mm x 2298.7 mm - 37311822	1-3/8" x 3-3/8" x 90-1/2"
· · · ·	0 0
1x - 11823 - 34.9 mm x 85.7 mm x 1974.9 mm - 37311823 1-3/8" x 3-3,	/8" x 77-3/4"
0 0	0
2x - 11824 - 34.9 mm x 85.7 mm x 2298.7 mm - 37311824	1-3/8" x 3-3/8" x 90-1/2"
	0 0 0
2x - 11826 - 25.4 mm x 50.8 mm x 914.4 mm - 37311826	
○ 1″ x 2″ x 36″	
2x - 11827 - 25.4 mm x 50.8 mm x 589 mm - 37311827	
4" 0" 00 0/46"	
<u> </u>	
1x - 11828 - 15.9 mm x 82.6 mm x 762 mm - 37311828	
1x - 11828 - 15.9 mm x 82.6 mm x 762 mm - 37311828	




14x - 11830 - 15.9 mm x 76.2 mm x 762 mm - 37311830
1x - 11831 - 15.9 mm x 50.8 mm x 762 mm - 37311831 5/8" x 2" x 30"
1x - 11834 - 25.4 mm x 76.2 mm x 1377.5 mm - 37311834 • • • 1" x 3" x 54-1/4"
1x - 11835 - 31.8 mm x 76.2 mm x 1905 mm - 37311835
· · · · · · · · · · · · · · · · · · ·
3x - 11836 - 31.8 mm x 63.5 mm x 276.2 mm - 37311836 1-1/4" x 2-1/2" x 10-7/8"
2x - 11837 - 31.8 mm x 63.5 mm x 533.3 - 37311837 · 1-1/4" x 2-1/2" x 21"
1x - 11838 - 31.8 mm x 76.2 mm x 1143 mm - 37311838 1-1/4" x 3" x 45"
1x - 11839 - 25.4 mm x 50.8 mm x 993.8 mm - 37311839 1" x 2" x 39-1/8"
1x - 11840 - 25.4 mm x 88.9 mm x 571.5 mm - 37311840 : 1" x 3-1/2" x 22-1/2"
4x - 11841 - 15.9 mm x 114.3 mm x 596.9 mm - 35811841 5/8" x 4-1/2" x 23-1/2"
2x - 11842 - 31.8 mm x 63.5 mm x 165.1 mm - 37311842 1-1/4" x 2-1/2" x 6-1/2"
2x - 11843 - 31.8 mm x 76.2 mm x 330.2 mm - 37311843 o 1-1/4" x 3" x 13"
2x - 11844 - 31.8 mm x 63.5 mm x 596.9 mm - 37311844 : 1-1/4" x 2-1/2" x 23-1/2"
1x - 11846 - 25.4 mm x 76.2 mm x 1092.2 mm - 37311846 1" x 3" x 43"




1x - 11847 - 31.8 mm x 76.2 mm x 76.2 mm - 37311847 1-1/4" x 3" x 3" **1x - 11848** - 31.8 mm x 76.2 mm x 273 mm - 37311848 1-1/4" x 3" x 10-3/4" **1x - 11849** - 34.9 mm x 85.7 mm x 1085.9 mm - 37311849 1-3/8" x 3-3/8" x 42-3/4" **5x - 11850** - 15.9 mm x 76.2 mm x 609.6 mm - 37311850 5/8" x 3" x 24" **1x - 11851** - 25.4 mm x 63.5 mm x 203.2 mm - 37311851 1" x 2-1/2" x 8" **1x - 11853** - 15.9 mm x 50.8 mm x 609.6 mm - 37311853 5/8" x 2" x 24" **1x - 11854** - 25.4 mm x 50.8 mm x 417.4 mm - 37311854 1" x 2" x 16-7/16" **1x - 11855** - 25.4 mm x 76.2 mm x 895.4 mm - 37311855 1" x 3" x 35-1/4" **3x - 11856** - 15.9 mm x 76.2 mm x 889 mm - 37311856 5/8" x 3" x 35" **1x - 11857** - 31.8 mm x 76.2 mm x 381 mm - 37311857 1-1/4" x 3" x 15"


1x - 9518 - 31 mm x 429.3 mm x 1155.7 mm - 37549518 1-1/4" x 16-7/8" x 45-1/2" 1x - 9519 - 31 mm x 422.9 mm x 1155.7 mm - 37549519 1-1/4" x 16-7/8" x 45-1/2"



2x - 9520 - 31 mm x 422.9 mm x 1155.7 mm - 37549520 1-1/4" x 16-7/8" x 45-1/2" 1x - 9521 - 31.8 mm x 574.7 mm x 433.4 mm - 37589521 1-1/4" x 22-5/8" x 17-1/16"











parts.kidkraft.com






parts.kidkraft.com

Hardware Identification (Actual Size)






6 x (FW0) - 3/16" - 51103100 4.8mm




60 x TN2 - 5/16" - 54503300 7.9mm



78 x (**LW2**) - 5/16" - 51303300 7.9mm



159 x (FW2) - 5/16" - 51103300 7.9mm



43 x (**LN2**) - 5/16" - 54303300 7.9mm



6 x BN1 - 1/4" - 54803200 6.4mm



14 x (**S0**) - #8 x 7/8" - 52933505 22.2mm




6 x (**S5**) - #8 x 1/2" - 52433502 12.7mm




42 x (**S3**) - #8 x 2-1/2" - 52043522 63.5mm




27 x (\$4) - #8 x 3" - 52043530 76.2mm







6 x (\$10) - #8x 1" - 52433510





8 x (**S13**) - #6 x 5/8" - 52413908 16mm


209 x (\$20) - #8 x 1-3/8" - 52043516 34.9mm

















parts.kidkraft.com


Hardware Identification (Actual Size)






parts.kidkraft.com

Inventory Parts - Read This Before Starting Assembly



Inventory should be completed before starting installation. KidKraft will not cover costs of any additional installation trip due to missing or damaged pieces.

- **A.** Referencing the parts identification sheets, inventory all hardware, wood and accessories. This will assist you with your assembly.
 - The wood pieces will have the key number stamped on the ends of the boards. Organize the wood pieces by step, as per the key numbering system below.



B. Read the assembly manual completely, paying special attention to EN71 and ASTM warnings, notes and safety/maintenance information on pages 1 - 8.

If there are missing or damaged pieces, please contact the KidKraft Consumer Engagement Team before going back to the retailer.

Request Replacement Parts 24/7

You can request replacement parts for this product 24 hours a day / 7 days a week:


Outdoor Swing Set and Playhouse Parts Ordering https://parts.kidkraft.com/partsorderemail

If you have assembly or product questions, please refer to the front cover for direct contact information for our Consumer Engagement Team OR you can also use this QR code with your smartphone for common questions and contact information.



KidKraft Help Center https://kidkraft.zendesk.com/hc/en-us/





2 x 11824 34.9 x 85.7 x 2298.7 mm (1-3/8" x 3-3/8" x 90-1/2")

1 x 11754 25.4 x 76.2 x 914.4 mm (1" x 3" x 36")


1 x 11788 25.4 x 76.2 x 1409.7 mm (1" x 3" x 55-1/2")


<u>Hardware</u>

4 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2")(FW2, LW2, TN2)



parts.kidkraft.com






<u>Hardware</u>

4 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com



2 x 11819 34.9 x 85.7 x 2298.7 mm (1-3/8" x 3-3/8" x 90-1/2")

1 x 11754 25.4 x 76.2 x 914.4 mm (1" x 3" x 36")

1 x 11834 25.4 x 76.2 x 1377.5 mm (1" x 3" x 54-1/4")

<u>Hardware</u>


4 x G9 7.9mm x 63.5mm (5/16" x 2-1/2") (LW2, FW2, TN2)




parts.kidkraft.com










<u>Hardware</u>

4 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com


















Rotated View





Wood Parts

1 x 11846 25.4 x 76.2 x 1092.2 mm (1" x 3" x 43")

1 x 11835 31.8 x 76.2 x 1905 mm (1-1/4" x 3" x 75")

<u>Hardware</u>

2 x (G5) 7.9mm x 114.3mm (5/16 x 4-1/2") (LW2, FW2, TN2)

2 x (G6) 7.9mm x 120.6 mm (5/16 x 4-3/4") (LW2, FW2, TN2)





parts.kidkraft.com















<u>Hardware</u>

4 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com




2 x 11748 31.8 x 76.2 x 1143 mm (1-1/4" x 3" x 45")

<u>Hardware</u>

4 x (G6) 7.9mm x 120.6 mm (5/16 x 4-3/4") (LW2, FW2, TN2)



parts.kidkraft.com




<u>Hardware</u>

4 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com



1 x 11857 31.8 x 76.2 x 381 mm (1-1/4" x 3" x 15")


Hardware

1 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2") (FW2, TN2)

1 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2") (FW2)



parts.kidkraft.com



1 x 11822 34.9 x 85.7 x 2298.7 mm (1-3/8" x 3-3/8" x 90-1/2")

1 x 11823 34.9 x 85.7 x 1974.9 mm (1-3/8" x 3-3/8" x 77-3/4")


Hardware

3 x G₃₆ 7.9mm x 69.9 mm (5/16 x 2-3/4") (LW2, FW2, TN2)

1 x $\langle G9 \rangle$ 7.9mm x 63.5mm (5/16" x 2-1/2") (LW2, FW2, TN2)



parts.kidkraft.com




$\underline{\text{Hardware}}$

8 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com



1 x 11765 25.4 x 76.2 x 914.4 mm (1" x 3" x 36")

<u>Hardware</u>


2 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2")(FW2, LW2, TN2)



parts.kidkraft.com









<u>Hardware</u>

2 x (S11) #8 x 50.8mm (#8 x 2")







1 x 11766 25.4 x 76.2 x 614.3 mm (1" x 3" x 24-3/16")

Hardware

- 1 x $\langle \overline{G5} \rangle$ 7.9mm x 114.3mm (5/16 x 4-1/2")(LW2, FW2, TN2)
- 1 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2")(FW2, LW2, TN2)




parts.kidkraft.com









4 x 11767 15.9 x 76.2 x 625.5 mm (5/8" x 3" x 24-5/8")


 $\underline{\text{Hardware}}$

16 x (\$20) #8 x 34.9mm (#8 x 1-3/8")









1 x 11817 15.9 x 63.5 x 468.3 mm (5/8" x 2-1/2" x 18-7/16") 3 x 11780 31.8 x 63.5 x 180.9 mm (1-1/4" x 2-1/2" x 7-1/8")

<u>Hardware</u>

6 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com















$\underline{\text{Hardware}}$

4 x (S11) #8 x 50.8mm (#8 x 2")









1 x 11817 15.9 x 63.5 x 468.3 mm (5/8" x 2-1/2" x 18-7/16")


Hardware

6 x (S11) #8 x 50.8mm (#8 x 2")









2 x 11781 15.9 x 114.3 x 468.31 mm (5/8" x 4-1/2" x 18-7/16")

Hardware

12 x (S20) #8 x 34.9mm (#8 x 1-3/8")




parts.kidkraft.com





Underneath View



Wood Parts

2 x 11782 31.8 x 63.5 x 241.3 mm (1-1/4" x 2-1/2" x 9-1/2")

<u>Hardware</u>

2 x (S4) #8 x 76.2mm (#8 x 3")

1 x (\$7) #12 x 50.8mm (#12 x 2")




parts.kidkraft.com





Underneath View




<u>Hardware</u>

3 x (S6) #12 x 25.4mm (#12 x 1")

Other Parts
1 x 9205970



parts. kidkraft.com





4 x 11758 38.1 x 38.1 x 463.6 mm (1-1/2" x 1-1/2" x 18-1/4")

Hardware

8 x (G36) 7.9mm x 69.9 mm (5/16 x 2-3/4") (FW2, TN2)





parts.kidkraft.com



Underneath View







<u>Hardware</u>

4 x (S3) #8 x 63.5mm (#8 x 2-1/2")





parts.kidkraft.com



Note: Structure partly removed for clarity







Wood Parts


2 x 11759 38.1 x 38.1 x 85.7 mm (1-1/2" x 1-1/2" x 3-3/8")


Hardware

4 x (s₃) #8 x 63.5mm (#8 x 2-1/2")



parts.kidkraft.com





1 x 11760 31.8 x 76.2 x 1092.2 mm (1-1/4" x 3" x 43")

Hardware


4 x (S4) #8 x 76.2mm (#8 x 3")



parts.kidkraft.com







Note: Structure partly removed for clarity

Wood Parts

6 x 11761 15.9 x 114.3 x 911.2 mm (5/8" x 4-1/2" x 35-7/8")

2 x 11762 15.9 x 101.6 x 911.2 mm (5/8" x 4" x 35-7/8")


2 x 11763 15.9 x 101.6 x 911.2 mm (5/8" x 4" x 35-7/8")

<u>Hardware</u>

48 x (\$20) #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com




4 x 11764 31.8 x 76.2 x 304.8 mm (1-1/4" x 3" x 12")

Hardware 4 x (G36) 7.9mm x 69.9 mm (5/16 x 2-3/4") (FW2 x 2, LN2)



parts.kidkraft.com




Hardware



4 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2") (FW2)



parts.kidkraft.com



3 x 11789 31.8 x 76.2 x 304.8 mm (1-1/4" x 3" x 12")

Hardware
6 x (WL5) 6.4mm x 63.5 mm (1/4 x 2-1/2") (FW2)



parts.kidkraft.com










Top View



2 x 11755 34.9 x 63.5 x 1290 mm (1-3/8" x 2-1/2" x 50-13/16")

6 x 11756 15.9 x 114.3 x 527 mm (5/8" x 4-1/2" x 20-3/4")


1 x 11757 15.9 x 114.3 x 527 mm (5/8" x 4-1/2" x 20-3/4")

Hardware

28 x (S7) #12 x 50.8mm (#12 x 2")




parts.kidkraft.com





parts.kidkraft.com



Hardware

1 x (G9) 7.9mm x 63.5mm (5/16 x 2-1/2") (LW2, FW2, TN2)




parts.kidkraft.com









<u>Hardware</u>

2 x (WL5) 6.4 x 63.5 mm (1/4 x 2-1/2") (FW2)






Pre-drill S7 holes using a 1/8" drill bit








Wood Parts

1 x 11757 15.9 x 114.3 x 527 mm (5/8" x 4-1/2" x 20-3/4")

Hardware

4 x (\$7) #12 x 50.8mm (#12 x 2")





1 x 11820 31.8 x 88.9 x 1117.6 mm (1-1/4" x 3-1/2" x 44")

<u>Hardware</u>

- 2 x (G₆) 7.9mm x 120.6 mm (5/16 x 4-3/4") (LW2, FW2, TN2)
- 1 x \(\biggre{G36} \) 7.9mm x 69.9 mm (5/16 x 2-3/4") (LW2, FW2, TN2)





parts.kidkraft.com











<u>Hardware</u>

3 x (S11) #8 x 50.8mm (#8 x 2")




parts.kidkraft.com











1 x 11816 50.8 x 133.4 x 1955.8 mm (2" x 5-1/4" x 77")

<u>Hardware</u>

1 x $\langle G9 \rangle$ 7.9mm x 63.5mm (5/16" x 2-1/2") (LW2, FW2 x 2, LN2)


Other Parts

1 x 9201563

1 x 9201682



parts.kidkraft.com




2 x 11784 34.9 x 85.7 x 236.6 mm (1-3/8" x 3-3/8" x 9-5/16")

Hardware

- 1 x (G11) 7.9mm x 88.9 mm (5/16 x 3-1/2") (LW2, FW2, TN2)
- 4 x $\langle z \rangle$ 7.9 x 152.4 mm (5/16 x 6") (LW2, FW2 x 2, LN2)



parts.kidkraft.com




<u>Hardware</u>

- 1 x (Ls1) 6.4mm x 38.1mm (1/4" x 1-1/2") (FW1)
- 2 x (S3) #8 x 63.5mm (#8 x 2-1/2")



parts.kidkraft.com



1 x 11849 34.9 x 85.7 x 1085.9 mm (1-3/8" x 3-3/8" x 42-3/4")

1 x 11829 31.8 x 76.2 x 914.4 mm (1-1/4" x 3" x 36")

<u>Hardware</u>

1 x \(\biggre{G4} \rightarrow 7.9mm x 101.5mm (5/16 x 4") (LW2, FW2, TN2)

2 x (G36) 7.9mm x 69.9 mm (5/16 x 2-3/4") (LW2, FW2, TN2)




parts.kidkraft.com










2 x 11826 25.4 x 50.8 x 914.4 mm (1" x 2" x 36")


 $\underline{\text{Hardware}}$


4 x G9 7.9mm x 63.5mm (5/16" x 2-1/2") (FW2, LW2, TN2)











1 x 11818 31.8 x 133.4 x 914.4 mm (1-1/4" x 5-1/4" x 36")

 $\underline{\text{Hardware}}$

4 x (G35) 7.9mm x 82.6 mm (5/16 x 3-1/4") (LW2, FW2 x 2, LN2)




parts.kidkraft.com







Inside View



Hardware 3 x (so) #8 x 22.2mm (#8 x 7/8") Other Parts


1 x 33210039



parts.kidkraft.com







1 x 11804 31.8 x 76.2 x 589 mm (1-1/4" x 3" x 23-3/16")


<u>Hardware</u>


3 x (so) #8 x 22.2mm (#8 x 7/8")




parts.kidkraft.com










Hardware

- 1 x (G36) 7.9mm x 69.9 mm (5/16 x 2-3/4") (LW2, FW2, TN2)
- 1 x (G6) 7.9mm x 120.6 mm (5/16 x 4-3/4") (LW2, FW2, TN2)



parts.kidkraft.com



1 x 11827 25.4 x 50.8 x 589 mm (1" x 2" x 23-3/16")

Hardware

4 x (S4) #8 x 76.2mm (#8 x 3")

4 x (S11) #8 x 50.8mm (#8 x 2")





parts.kidkraft.com











5 x 11850 15.9 x 76.2 x 609.6 mm (5/8" x 3" x 24")


1 x 11853 15.9 x 50.8 x 609.6 mm (5/8" x 2" x 24")

<u>Hardware</u>

22 x (\$20) #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com



1 x 11772 50.8 x 133.4 x 2235.2 mm (2" x 5-1/4" x 88")

Other Parts 4 x 9201563




parts.kidkraft.com











Hardware

4 x (\$20) #8 x 34.9mm (#8 x 1-3/8")

Other Parts
1 x 3320353



parts.kidkraft.com















<u>Hardware</u>

4 x $\langle G7 \rangle$ 7.9mm x 139.7 mm (5/16 x 5-1/2") (FW2 x 2, LN2)

Other Parts 2 x 9210167



parts.kidkraft.com



Hardware

2 x $\langle G36 \rangle$ 7.9mm x 69.9 mm (5/16 x 2-3/4") (LW2, FW2 x 2, LN2)

Other Parts 2 x 9201645



parts.kidkraft.com
















Wood Parts
1 x 10916 50.8 x 76.2 x 1294.3 mm (2" x 3" x 50-15/16")

2 x 10917 50.8 x 76.2 x 2100 mm (2" x 3" x 86-11/16")

<u>Hardware</u>

2 x (G22) 7.9mm x 127 mm (5/16 x 5") (LW2, FW2 x 2, LN2)



parts.kidkraft.com

















Wood Parts
1 x 2616 23.8 x 82.6 x 1181.1 mm (15/16" x 3-1/4" x 46-1/2")

<u>Hardware</u>

3 x (G5) 7.9mm x 114.3mm (5/16 x 4-1/2") (LW2, FW2 x 2, LN2)



parts.kidkraft.com



Hardware

5 x G36 7.9mm x 69.9 mm (5/16 x 2-3/4") (LW2, FW2 x 2, LN2)


Other Parts

1 x 9201644

1 x 9201643



parts.kidkraft.com




<u>Hardware</u>

4 x (G8) 7.9mm x 50.8mm (5/16" x 2") (LW2, FW2 x 2, LN2)



parts.kidkraft.com



9 x 11830 15.9 x 76.2 x 762 mm (5/8" x 3" x 30")


1 x 11831 15.9 x 50.8 x 762 mm (5/8" x 2" x 30")

$\underline{\text{Hardware}}$

38 x (\$20) #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com





๊⊚ଐ



Flush


G8

11855

TN2

G9

11854



Wood Parts

1 x 11854 25.4 x 50.8 x 417.4 mm (1" x 2" x 16-7/16")

1 x 11855 25.4 x 76.2 x 895.4 mm (1" x 3" x 35-1/4")

<u>Hardware</u>

1 x \(\lambda 8 \rangle 7.9 \text{mm x 50.8 mm (5/16" x 2") (LW2, FW2, TN2)}

1 x \(\langle G9 \rangle \) 7.9mm x 63.5mm (5/16" x 2-1/2") (LW2, FW2, TN2)

1 x \langle WBs \rangle 7.9mm x 60.3 mm (5/16 x 2-3/8") (LW2, FW2, TN2)


2 x (s4) #8 x 76.2mm (#8 x 3")




parts.kidkraft.com









 $\underline{\text{Hardware}}$

3 x (S5) #8 x 12.7mm (#8 x 1/2")

Other Parts

1 x 9205970





parts.kidkraft.com











3 x 11856 15.9 x 76.2 x 889 mm (5/8" x 3" x 35")


Hardware

12 x (\$20) #8 x 34.9mm (#8 x 1-3/8")




parts.kidkraft.com









1 x 11827 25.4 x 50.8 x 589 mm (1" x 2" x 23-3/16")

Hardware

4 x (S4) #8 x 76.2mm (#8 x 3")


3 x (S11) #8 x 50.8mm (#8 x 2")




parts.kidkraft.com









1 x 11828 15.9 x 82.6 x 762 mm (5/8" x 3-1/4" x 30")

5 x 11830 15.9 x 76.2 x 762 mm (5/8" x 3" x 30")


Hardware


24 x (S20) #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com







2 x 11784 34.9 x 85.7 x 236.6 mm (1-3/8" x 3-3/8" x 9-5/16")

<u>Hardware</u>


4 x (G11) 7.9mm x 88.9 mm (5/16 x 3-1/2") (LW2, FW2, TN2)



parts.kidkraft.com







4 x 11802 31.8 x 88.9 x 794.7 mm (1" x 3-1/2" x 41-1/2")


Hardware


2 x (\$4) #8 x 76.2mm (#8 x 3")











2 x 11770 15.9 x 114.3 x 467 mm (5/8" x 4-1/2" x 18-3/8")

Hardware


8 x (\$20) #8 x 34.9mm (#8 x 1-3/8")











1 x 9518 31 x 429.3 x 1155.7 mm (1-1/4" x 16-7/8" x 45-1/2")

1 x 9519 31 x 422.9 x 1155.7 mm (1-1/4" x 16-7/8" x 45-1/2")

<u>Hardware</u>


8 x (S3) #8 x 63.5mm (#8 x 2-1/2")




parts.kidkraft.com









<u>Hardware</u>

2 x (so) #8 x 22.2mm (#8 x 7/8")

Other Parts

1 x 9205932




parts.kidkraft.com









2 x 9520 31 x 422.9 x 1155.7 mm (1-1/4" x 16-7/8" x 45-1/2")

Hardware


8 x (S3) #8 x 63.5mm (#8 x 2-1/2")




parts.kidkraft.com









<u>Hardware</u>


4 x (so) #8 x 22.2mm (#8 x 7/8")


Other Parts


2 x 9205947



parts.kidkraft.com








Hardware

4 x (G35) 7.9mm x 82.6 mm (5/16 x 3-1/4") (LW2, FW2 x 2, LN2)



parts.kidkraft.com



1 x 11838 31.8 x 76.2 x 1143 mm (1-1/4" x 3" x 45")

<u>Hardware</u>

2 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2") (LW2, FW2, TN2)

2 x (S11) #8 x 50.8mm (#8 x 2")





parts.kidkraft.com














1 x 11837 31.8 x 63.5 x 533.3 mm (1-1/4" x 2-1/2" x 21")

<u>Hardware</u>

2 x (S3) #8 x 63.5mm (#8 x 2-1/2")

2 x (S11) #8 x 50.8mm (#8 x 2")




parts.kidkraft.com









1 x 11837 31.8 x 63.5 x 533.3 mm (1-1/4" x 2-1/2" x 21")

1 x 11848 31.8 x 76.2 x 273 mm (1-1/4" x 3" x 10-3/4")

Hardware

2 x (S3) #8 x 63.5mm (#8 x 2-1/2")





parts.kidkraft.com











<u>Hardware</u>

4 x (S3) #8 x 63.5mm (#8 x 2-1/2")


1 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com







2 x 11841 15.9 x 114.3 x 596.9 mm (5/8" x 4-1/2" x 23-1/2")

<u>Hardware</u>


12 x (\$20) #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com







1 x 11851 25.4 x 63.5 x 203.2 mm (1" x 2-1/2" x 8")


<u>Hardware</u>

2 x (S11) #8 x 50.8mm (#8 x 2")

1 x (S20) #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com



2 x 11836 31.8 x 63.5 x 276.2 mm (1-1/4" x 2-1/2" x 10-7/8")

<u>Hardware</u>

3 x (s₄) #8 x 76.2mm (#8 x 3")


1 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com







2 x 11842 31.8 x 63.5 x 165.1 mm (1-1/4" x 2-1/2" x 6-1/2")

2 x 11844 31.8 x 63.5 x 596.9 mm (1-1/4" x 2-1/2" x 23-1/2")

Hardware


8 x (S3) #8 x 63.5mm (#8 x 2-1/2")



parts.kidkraft.com








2 x 11841 15.9 x 114.3 x 596.9 mm (5/8" x 4-1/2" x 23-1/2")

Hardware

12 x (\$20) #8 x 34.9mm (#8 x 1-3/8")


















2 x 11843 31.8 x 76.2 x 330.2 mm (1-1/4" x 3" x 13")

Hardware

2 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2") (FW2, TN2)


#8 x 50.8mm (#8 x 2")



customer service @kidkraft.com

1.800.933.0771 972.385.0100

parts.kidkraft.com



1 x 11847 31.8 x 76.2 x 76.2 mm (1-1/4" x 3" x 3")

TN2

<u>Hardware</u>

1 x (G4) 7.9mm x 101.5mm (5/16 x 4") (LW2, FW2, TN2)

1 x (G9) 7.9mm x 63.5mm (5/16" x 2-1/2") (LW2, FW2, TN2)




parts.kidkraft.com

customerservice@kidkraft.com 1.800.933.0771 972.385.0100

Flush







<u>Hardware</u>

3 x (S5) #8 x 12.7mm (#8 x 1/2")


<u>Other Parts</u> 1 x 9205970



parts.kidkraft.com







1 x 11836 31.8 x 63.5 x 276.2 mm (1-1/4" x 2-1/2" x 10-7/8")

Hardware

1 x (\$4) #8 x 76.2mm (#8 x 3")


1 x (S11) #8 x 50.8mm (#8 x 2")




parts.kidkraft.com









1 x 11840 25.4 x 88.9 x 571.5 mm (1" x 3-1/2" x 22-1/2")

Hardware


4 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com







1 x 11839 25.4 x 50.8 x 993.8 mm (1" x 2" x 39-1/8")

Hardware

5 x (S4) #8 x 76.2mm (#8 x 3")

2 x (S11) #8 x 50.8mm (#8 x 2")




parts.kidkraft.com









1 x 9521 31.8 x 574.7 x 433.4 mm (1-1/4" x 22-5/8" x 17-1/16")

Hardware

4 x (S37) #7 x 15.9mm (#7 x 5/8")

Other Parts

1 x 9207713

1 x 9207711




parts.kidkraft.com









<u>Hardware</u> 2 x (S37) #7 x 15.9mm (#7 x 5/8")

Other Parts
1 x 9207711




parts.kidkraft.com










<u>Hardware</u> 6 x (S37) #7 x 15.9mm (#7 x 5/8")

Other Parts
2 x 9207712



parts.kidkraft.com




Hardware

6 x (S37) #7 x 15.9mm (#7 x 5/8")




parts.kidkraft.com










1 x 11806 25.4 x 63.5 x 152.4 mm (1" x 2-1/2" x 6")

Hardware

2 x (S13) #6 x 15.9mm (#6 x 5/8")





<u>Hardware</u>

3 x (S11) #8 x 50.8mm (#8 x 2")



parts.kidkraft.com





Important: Use a hand held screw driver and DO NOT over tighten.






















Hardware

6 x (S13) #6 x 16mm (#6 x 5/8")

Other Parts

1 x 9320881 9331708

2 x 52040302

9320382


9322282

3331709




parts.kidkraft.com







Underneath View



Underneath View

Hardware

2 x (so) #8 x 22.2mm (#8 x 7/8")

Other Parts

1 x 9321691

1 x 9320888STGY

1x 9320889STGY

1 x 9320889TG




parts.kidkraft.com

















<u>Hardware</u>

4 x (WL3) 6.4mm x 34.9mm (1/4 x 1-3/8") (FW1)

Other Parts 2 x 9321740



parts.kidkraft.com















Hardware

2 x (WL3) 6.4mm x 34.9mm (1/4 x 1-3/8") (FW1)


Other Parts
1 x 9321740




parts.kidkraft.com









<u>Hardware</u>

3 x (S7) #12 x 50.8 mm (#12 x 2")

Other Parts
1 x 7310848-1



parts.kidkraft.com



MOVE FORT TO FINAL LOCATION PRIOR TO STAKING FINAL LOCATION MUST BE LEVEL GROUND











Warning! To prevent tipping and avoid potential injury, stakes must be driven 13" (33 cm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.

SEE COVER PAGE FOR SAFETY CLEARANCE

9290318] 13" In Ground (33 cm) Rotated View Rotated View





Hardware

1 x (S6) #12 x 25.4mm (#12 x 1")


) #12 x 50.8mm (#12 x 2")


Other Parts 6 x 9200318

KidKraft
MADE FOR MAKE BELIEVE

parts.kidkraft.com







Other Parts

1 x 07-0041-G/Y

1 x FS 2250

1 x FS 2420



parts.kidkraft.com







Safety Use Zone 72" Minimum

9700003



View 1





Caution: Threaded Quick Links must be installed with the gate completely down covering the threads and tighten as instructed.

View 2

Other Parts
1 x 9700003



parts.kidkraft.com




Place two rope staples FS 2022 as indicated.






Thread the Rope through the holes of the base and loop through the staples as shown. Pull tight and secure by pounding staples tight against the base.


Cut off the excess ropes after assembly if needed.





Front View

Back View



Other Parts

6 x FS 2022





parts.kidkraft.com




Insert Hole Plugs into all unused holes.










Other Parts
3 x 9329900



parts.kidkraft.com



5 x 9329900




parts.kidkraft.com



ATTACH THIS WARNING & I.D. PLAQUE TO THIS LOCATION ON YOUR PLAY EQUIPMENT!



This provides warnings concerning safety and important contact information. A Tracking Number is provided to allow you to get critical information or order replacement parts for this specific model.



Hardware 4 x (\$37) #7 x 15.9mm (#7 x 5/8") Other Parts

1 x 9320374




parts.kidkraft.com




Repeat this step for another side







▲WARNING:Bolt must not exceed 1/2 thread past the nut



Hardware

4 x (LN2)

2 x (G25) 7.9mm x 184.1 mm (5/16 x 7-1/4") (FW2 x 2, LN2)

Other Parts 1 x 3320168

3320177


1 x 3533860 (4pk)




parts.kidkraft.com



AWARNING: Check entire playset for bolts protruding beyond T-Nuts. Use extra washers to eliminate this condition.



- A: Attach 2 Belt Swings to the Bolt-Thru Swing Hangers. (fig. 1)
- B: Insert flexible Swing Hanger Cover (9300000) over hook. (fig. 2)
- C: Slide Swing Hanger Cover around hook until at top. (fig. 3)
- **D:** Hook swing rope onto hook. (fig. 4)
- E: Twist and flex Swing Hanger Cover onto open end of hook. (fig. 5)



Other Parts

2 x 3724950

4 x 9300000



parts.kidkraft.com

NOTES	



NOTES	



3 EASY WAYS TO REGISTER YOUR PRODUCT 24/7

- 1) Scan this QR Code with your smartphone to complete your product registration directly from your phone:
- 2) Complete the registration online at: https://www.kidkraft.com/us_en/warranty/
- 3) Mail this completed form to: Backyard Kids, LLC DBA KidKraft
 317 S. Main St. Ann Arbor, MI 48104
 Make sure to include a copy of your proof of purchase



KIDKRAFT Consumer Registration Card

Fir	st N	lan	ne																Ini	tia	 	9-	La	st	Naı	me			-																							
Stı	eet																																	A	ot.	No	0.															
																																						l														
Cit	у											'											_							- (Sta	te/	- Pro	vin	се		ZII	P/P	'05	stal	Co	de										
																										-												I														
Country																								Telephone Number																												
E-I	Mail	ΙA	ddr	ess	S		•										•		•				•						•					•									•									
Mo	odel	l Nı	um	beı	r			IV	lod	el	Na	me)																				N/1-	اماما	NI.		- -	0 1														
																																									exaı SYS											
Pu	rch	ase	ed I	ro	m																								D	ate	e P	urc	has	se						ſ	A W	ARNING RTISSEMEN										
										١							ı									1								I							point, ration, observe or paged a tra delicer in case and other children in case and other children in case and other children in case the children in case to ping set. Tellum in produkt in case to ping set. Tellum in produkt in case to ping set. Tellum in produkt in case to ping set. Tellum in case in case the children in case the children in case in case and case of the children and case of the children and case of the children and case of the children to the common of the children to the children of the children to the common of the children to the children of the children to the children of the children to the children of the childre	contille demonstrate unity is month political in toward bloop distribute, present demonstrate demonstrate to play out to be a provided to the control to the control towards to the control towards of the control tow										
Se	rial	Nu	ımk	 ber	(0	n I	D F	Plac	aue)																		J	_				MM /	/ DD /	YYY				_		Bulli Villa. Lai. O Salout. Suppose d'illimengle-ment à parende laineur les evides à parende laineur les evides per de la sense parende la laineur en d'artheis personnel laineur en de la sense la laineur en d'artheis personnel laineur à parende, de la liment à parende, de la liment en parende, de la liment paren parende la liment paren parende la liment à la parende la liment à la parende la liment à liment	INCO COMMITMATE THE REQUISION In salies, years day poplar, in the salies, due to poplar, in the salies, due obtained to the salies, due obtained to the salies, due obtained to the salies of the salies to perfor or control from the performance of the topic of the to	ue exar									
					`				· 																															741128	melafishers i, imalahira serimi seleti hirajah adams sen manari alia Bin pasan serimi Barat Sangara Sangara Sangara Bila Tio Tio, sengari besa di Bila Tio Tio, sengari besa di Bila Bila Sangara Sangara Jamas Sangara separanana Jamas Sangara separanananan Jamas Sangara separanananan Jamas Sangara separanananan Jamas Sangara separananananan Jamas Sangara Sangara Sangara Ti Jabi	or de laterio, de l'ampliale, son de laterio accesso de l'ampliale son de la considera accesso de la chaixe son de la considera accesso de la considera accesso de la considera de la considera de la considera accesso del la considera accesso de la considera accesso de la considera accesso del la considera accesso de la considera accesso de la considera accesso del la considera	DESCRIPTION OF THE PROPERTY OF									
	Во	x #	<u>+: _</u>						1 of				_				Bo	x 7	#: _						_ 4	of				_			Вс	X Ŧ	# (Ex	(: E	329	<u> </u>	10	10	f 6)									
	Во	x #	<u> </u>	2 of									_	Box #:									5 of											1	OI DE		4			ITEM# ARTICLE N.* DE AR	N.	$\overline{\ \ }$										
	Во	x #	<u> </u>					_ (3 of	_							Во	X 7	#: _						_ 6	of				_					יט	= (_ 	BZ2	9410		NING SEMENT DESCRIPTION OF THE PROPERTY OF THE									

For common questions or for information on ordering replacement parts:

