

F29825

ACADIA MANOR SWING SET






OBSTACLE FREE SAFETY ZONE - 31' 2" L x 24' 7-1/4" D x 17' 4-5/8" H (9.5 x 7.5 x 5.3 m) area requires Protective Surfacing. See page 4.

MAXIMUM VERTICAL FALL HEIGHT - 6' 8-3/4" (2.05m).

CAPACITY - 9 Users Maximum, Ages 3 - 10; Weight Limit 110 lbs. (50 kg) per child.

RESIDENTIAL HOME USE ONLY. Not intended for public areas such as multi-unit residences, schools, churches, nurseries, day cares or parks.



INSTALLATION AND OPERATING INSTRUCTIONS

FOR 24/7 ONLINE PARTS REPLACEMENT

parts.kidkraft.com

Backyard Kids, LLC DBA KidKraft
317 S. Main St.
Ann Arbor, MI 48104

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

9409825

Rev 02/07/2025

WARNING

To reduce the risk of serious injury or death, please read and follow these instructions. Keep and refer to instructions as needed and pass along to any future owners of this item.

Congratulations on purchasing a KidKraft product!

**Our items are made of high-quality,
durable Cunninghamia Lanceolata wood
from the cypress family.**

**Lumber from these trees are known for
their light weight and excellent strength.
The porosity of this wood allows the
moisture to absorb and evaporate in the
fibers, resisting rot and bugs.**

**Engineered for great play, our products
also go through extensive testing for safety.**

**Plus, our team has developed a series of
proprietary methods for a simpler, more
organized assembly. Less build time and
more play time is our motto!**

**However, during assembly if you have any
questions or concerns, please reach out.
Our Customer Service can help with missing
parts, instructions or maintenance.**



Warnings and Safe Play Instructions



CONTINUOUS ADULT SUPERVISION REQUIRED. Most serious injuries and deaths on playground equipment have occurred while children were unsupervised! Our products are designed to meet mandatory and voluntary safety standards. Complying with all warnings and recommendations in these instructions will reduce the risk of serious or fatal injury to children using this play system. Go over the warnings and safe play instructions regularly with your children and make certain that they understand and follow them. Remember on-site adult supervision is required for children of all ages.



WARNING

SERIOUS HEAD INJURY HAZARD

Installation over concrete, asphalt, dirt, grass, carpet and other hard surface creates a risk of serious injury or death from falls to the ground. Install and maintain shock absorbing material under and around play-set as recommended on page 4 of these instructions.

COLLISION HAZARD

Place play-set on level ground at least 2m from any obstruction such as a garage or house, fences, poles, trees, sidewalks, walls, landscape timbers, rocks, pavement, planters, garden borders, overhanging branches, laundry lines, and electrical wires. (See OBSTACLE FREE SAFETY ZONE on cover)

CHOKING HAZARD/SHARP EDGES & POINTS

Adult assembly required. This product contains small parts and parts with sharp edges and points. Keep parts away from children until fully assembled.

WARNING LABEL

Owners shall be responsible for maintaining the legibility of the warning labels.

STRANGULATION HAZARD

- NEVER allow children to play with ropes, clotheslines, pet leashes, cables, chains or cord-like items when using this play-set or to attach these items to play-set.
- NEVER allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, necklaces, items with draw-strings, cords or ties when using this play-set.
- NEVER allow children to wear bike or sport helmets when using this play-set.

Failure to prohibit these items, even helmets with chin straps, increases the risk of serious injury and death to children from entanglement and strangulation.

TIP OVER HAZARD

Choose a level location for the equipment. This can reduce the likelihood of the play set tipping over and loose-fill surfacing materials washing away during heavy rains.

DO NOT allow children to play on the play-set until the assembly is complete and the unit is properly anchored.

Never add extra length to chain or rope. The chains or ropes provided are the maximum length designed for the swinging element(s).



WARNING – Safe Play Instructions

- ✓ Observe capacity limitations of your play-set. See front cover.
- ✓ Dress children with well fitting and full foot enclosing footwear.
- ✓ Teach children to sit with their full weight in the center of the swing seat to prevent erratic swing motion or falling off.
- ✓ Check for splintered, broken or cracked wood; missing, loose, or sharp edged hardware. Replace, tighten and or sand smooth as required prior to playing.
- ✓ Verify that suspended climbing ropes, rope ladders, chain or cable are secured at both ends and cannot be looped back on itself as to create an entanglement hazard.
- ✓ On sunny and or hot days, check the slide and other plastic rides to assure that they are not very hot as to cause burns. Cool hot slide and rides with water and wipe dry prior to using.
- ✓ Orientate slide such that it gets the least amount of exposure to the sun.
- ✗ Do not allow children to wear open toe or heel footwear like sandals, flip-flops or clogs.
- ✗ Do not allow children to walk, in front, between, behind or close to moving rides.
- ✗ Do not let children twist swing chains or ropes or loop them over the top support bar. This may reduce the strength of the chain or rope and cause premature failure.
- ✗ Do not let children get off rides while they are in motion.
- ✗ Do not permit climbing on equipment when it is wet.
- ✗ Do not permit rough play or use of equipment in a manner for which it was not intended. Standing on or jumping from the roof, elevated platforms, swings, climbers, ladders or slide can be dangerous.
- ✗ Do not allow children to swing empty rides or seats.
- ✗ Do not allow children to go down slide head first or run up slide.



KidKraft
MADE FOR MAKE BELIEVE™

parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

⚠ Protective Surfacing - Reducing Risk of Serious Head Injury From Falls

One of the most important things you can do to reduce the likelihood of serious head injuries is to install shock-absorbing protective surfacing under and around your play equipment. The protective surfacing should be applied to a depth that is suitable for the equipment height in accordance with ASTM F1292. There are different types of surfacing to choose from; whichever product you select, follow these guidelines:

Loose-Fill Materials

- Maintain a minimum depth of 9 inches (23 cm) of loose-fill materials such as wood mulch/chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for equipment up to 8 feet (2.45 m) high; and 9 inches (23 cm) of sand or pea gravel for equipment up to 5 feet (1.5 m) high. NOTE: An initial fill level of 12 inches (31 cm) will compress to about a 9-inch (23 cm) depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically raked and refilled to maintain at least a 9-inch (23 cm) depth.
- Use a minimum of 6 inches (16 cm) of protective surfacing for play equipment less than 4 feet (1.22 m) in height. If maintained properly, this should be adequate. (At depths less than 6 inches (16 cm), the protective material is too easily displaced or compacted.)

NOTE: Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are not adequate protective surfacing. Ground level equipment -- such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface -- does not need any protective surfacing.

- Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.
- Periodically rake, check and maintain the depth of the loose-fill surfacing material. Marking the correct depth on the play equipment support posts will help you to see when the material has settled and needs to be raked and or replenished. Be sure to rake and evenly redistribute the surfacing in heavily used areas.
- Do not install loose fill surfacing over hard surfaces such as concrete or asphalt.

Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles


You may be interested in using surfacing other than loose-fill materials - like rubber tiles or poured-in-place surfaces.

- Installations of these surfaces generally require a professional and are not "do-it yourself" projects.
- Review surface specifications before purchasing this type of surfacing. Ask the installer/manufacturer for a report showing that the product has been tested to the following safety standard: ASTM F1292 *Standard Specification for Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment*. This report should show the specific height for which the surface is intended to protect against serious head injury. This height should be equal to or greater than the fall height - vertical distance between a designated play surface (*elevated surface for standing, sitting, or climbing*) and the protective surfacing below - of your play equipment.
- Check the protective surfacing frequently for wear.

Placement

Proper placement and maintenance of protective surfacing is essential. Refer to diagram on front cover. Be sure to;

- Extend surfacing at least 6 feet (1.8 m) from the equipment in all directions.
- For to-fro swings, extend protective surfacing in front of and behind the swing to a distance equal to twice the height of the top bar from which the swing is suspended.
- For tire swings, extend surfacing in a circle whose radius is equal to the height of the suspending chain or rope, plus 6 feet (1.8 m) in all directions.





From the CPSC Outdoor Home Playground Safety Handbook. At <http://www.playgroundregs.com/resources/CPSC%20324.pdf>

Instructions for Proper Maintenance

Your KidKraft Play System is designed and constructed of quality materials with your child's safety in mind. As with all outdoor products used by children, it will weather and wear. To maximize the enjoyment, safety and life of your Play Set, it is important that you, the owner, properly maintain it. Failure to follow maintenance directions below can cause the swing set to overturn or otherwise become a hazard to children.

Check the following at the beginning of the play season:

<p>HARDWARE:</p> <ul style="list-style-type: none"> ✓ Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303. ✓ Inspect and tighten all hardware. On wood assemblies DO NOT OVER-TIGHTEN as to cause crushing and splintering of wood. ✓ Check for sharp edges or protruding screw threads, add washers if required.   <p>SHOCK ABSORBING SURFACING:</p> <ul style="list-style-type: none"> ✓ Check for foreign objects. Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 4) 	<p>GROUND STAKES (ANCHORS):</p> <ul style="list-style-type: none"> ✓ Check for looseness, damage or deterioration. Should firmly anchor unit to ground during use. Re-secure and or replace, if necessary. <p>SWING HANGERS:</p> <ul style="list-style-type: none"> ✓ Check that bolts are secure and tight. Quick clips should be completely closed and threaded clips screwed tight. ✓ If squeaking occurs lubricate bushings with oil or WD-40®. <p>SWINGS, ROPES AND RIDES:</p> <ul style="list-style-type: none"> ✓ Reinstall if removed during cold season. Check all moving parts including swing seats, ropes, chains and attachments for wear, rust and other deterioration. Replace as needed. ✓ Check that ropes are tight, secure at both ends and cannot loop back as to create an entrapment. <p>WOOD PARTS:</p> <ul style="list-style-type: none"> ✓ Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal. ✓ Applying a water repellent or stain (water-based) on a yearly basis is important maintenance to maintain maximum life and performance of the product.
--	---

Check twice a month during play season:

<p>HARDWARE:</p> <ul style="list-style-type: none"> ✓ Inspect for tightness. Must be firmly against, but not crushing the wood. DO NOT OVER-TIGHTEN. This will cause splintering of wood. ✓ Check for sharp edges or protruding screw threads. Add washers if required. 	<p>SHOCK ABSORBING SURFACING:</p> <ul style="list-style-type: none"> ✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 4)
---	---

Check once a month during play season:

<p>SWING HANGERS:</p> <ul style="list-style-type: none"> ✓ Check that they are secure and orientated correctly. Hook should rotate freely and perpendicular to support beam. ✓ If squeaking occurs lubricate bushings with oil or WD-40®. 	<p>SWINGS AND RIDES:</p> <ul style="list-style-type: none"> ✓ Check swing seats, all ropes, chains and attachments for fraying, wear, excessive corrosion or damage. Replace if structurally damaged or deteriorated.
--	---

Check at the end of the play season:

<p>SWINGS AND RIDES:</p> <ul style="list-style-type: none"> ✓ To prolong their life, remove swings and store inside when outside temperature is below 32°F/0°C. Below freezing, plastic parts may become more brittle. 	<p>SHOCK ABSORBING SURFACING:</p> <ul style="list-style-type: none"> ✓ Rake and check depth of loose fill protective surfacing materials to prevent compaction and maintain appropriate depth. Replace as necessary. (See Protective Surfacing, page 4)
--	---

If you dispose of your play set: Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.

About Our Wood

KidKraft Premium Play Systems uses only premium playset lumber, ensuring the safest product for your children's use. Although we take great care in selecting the best quality lumber available, wood is still a product of nature and susceptible to weathering which can change the appearance of your set.

What causes weathering? Does it affect the strength of my Play System?

One of the main reasons for weathering is the effects of water (moisture); the moisture content of the wood at the surface is different than the interior of the wood. As the climate changes, moisture moves in or out of the wood, causing tension which can result in checking and or warping. You can expect the following due to weathering. These changes will not affect the strength of the product:

1. **Checking** is surface cracks in the wood along the grain. A post 4" x 4" (101mm x 101mm) will experience more checking than a board 1" x 4" (25mm x 101mm) because the surface and interior moisture content will vary more widely than in thinner wood.
2. **Warping** results from any distortion (twisting, cupping) from the original plane of the board and often happens from rapid wetting and drying of the wood.
3. **Fading** happens as a natural change in the wood color as it is exposed to sun-light and will turn a grey over time.

How can I reduce the amount of weathering to my Play System?

At the factory we have coated the wood with a water repellent or stain. This coating decreases the amount of water absorption during rain or snow thus decreasing the tension in the wood. Sunlight will break down the coating, so we recommend applying a water repellent or stain on a yearly basis (see your local stain and paint supplier for a recommended product).

Most weathering is just the normal result of nature and will not affect safe play and enjoyment for your child. However if you are concerned that a part has experienced a severe weathering problem please call our consumer relations department for further assistance.

Complete and mail registration card to receive important product notifications and assure prompt warranty service.

KidKraft Limited Warranty

MISSING OR DAMAGED PARTS:

KidKraft will replace any parts within 90 days from date of purchase found to be missing from or damaged in the original packaging. See Fig. 1

Fig. 1	<u>Product Age (All Parts)</u> 0-90 Days from date of purchase	<u>Consumer Pays</u> \$0 for Part + Free Shipping
--------	---	--

DEFECTS IN MATERIAL AND WORKMANSHIP:

KidKraft warrants that this product is free from defects in materials and workmanship for a period of one (1) year from the original date of purchase (dated sales receipt and/or product registration is required). This one (1) year warranty covers all parts including wood, hardware, and all accessories (Such as swings, rides, and slides). See Fig. 2

Fig. 2	<u>Product Age (All Parts)</u> 91 Days to 1 Year	<u>Consumer Pays</u> \$0 for Part + Free Shipping
--------	---	--

WOOD ROT, DECAY, AND INSECT DAMAGE:

All wood carries a five (5) year warranty against rot, decay, and insect damage (dated sales receipt and/or product registration is required). Refer to the schedule below for charges associated with replacement of wood parts under this **Limited Warranty**. See Fig. 3

Fig. 3	<u>Product Age (Wood Parts)</u> 0 Days to 1 Year After 1 Year to 5 Year Over 5 Years	<u>Consumer Pays</u> \$0 for Part + Free Shipping \$0 for Part + Shipping & Handling 100% for Part (if available) + Shipping & Handling
--------	---	--

This warranty applies to the original owner and registrant and is non-transferable. Regular maintenance is required to ensure the integrity of this product. Failure by the owner to maintain the product according to the maintenance requirements may void this warranty.

This Limited Warranty does NOT cover:

- Any inspection cost
- Labor and/or costs for replacement of any defective item(s), including but not limited to, professional installer costs
- Incidental or consequential damages, including but not limited to, as a result of set relocation, move and/or reinstall
- Cosmetic defects which do not affect performance or integrity of a part or the entire product
- Vandalism, improper use or installation, or acts of nature, including but not limited to, high winds, fire, and flood
- Minor twisting, warping, checking, or any natural occurring properties of wood that do not affect performance or integrity.
- Any KidKraft product purchased, including but not limited to, a non-approved retailer, auction houses, second-hand, and as-is clearance items.

KidKraft products have been designed for safety and quality. Modifications made to the original product may damage the structural integrity of the unit leading to failure and possible injury. KidKraft cannot assume any responsibility for the modified products. Furthermore, modifications void all warranties.

This product is warranted for **RESIDENTIAL USE ONLY**. Under no circumstance should a KidKraft product be used in public settings such as schools, churches, playgrounds, parks, home and professional day cares and the like. Such use may lead to product failure and failure and potential injury. Public use will void this warranty. KidKraft disclaims all other representations and warranties of any kind, express or implied.



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Keys to Assembly Success


Tools Required

<ul style="list-style-type: none"> • Tape Measure • Carpenter's Level • Carpenter's Square • Claw Hammer • Standard or Cordless Drill • Rubber Mallet 	<ul style="list-style-type: none"> • #1 Phillips and #2 Robertson Screwdrivers • Ratchet with Extension 1/2" (13mm) & 7/16" (11mm) Sockets 	<ul style="list-style-type: none"> • Open-End Wrench 1/2" (13mm) & 7/16" (11mm) • Adjustable Wrench • 1/8" (3mm) Drill Bit 	<ul style="list-style-type: none"> • 3/16" (5mm) Hex Key • 8' (2.4m) Step Ladder • Safety Glasses • Adult Helpers • Pencil
---	---	--	---

Part Identification Key

Listed on each page are the parts and quantities required to complete the assembly step illustrated on that page.

EXAMPLE




Symbols

Throughout these instructions, symbols are provided as important reminders for proper and safe assembly.

<p>This identifies information that requires special attention. Improper assembly could lead to an unsafe or dangerous condition.</p>	<p>Check that the set or assembly is properly level before proceeding.</p> <p>Use Level</p>
<p>Use Help</p> <p>Where this is shown, 2 or 3 people are required to safely complete the step. To avoid injury or damage to the assembly, make sure to get help!</p>	<p>Pre-drill 1/8" (3mm) Bit</p> <p>Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.</p> <p>3mm</p>
<p>Measure Distance</p> <p>Check that assembly is square before tightening bolts.</p> <p>Use a measuring tape to ensure proper location.</p>	<p>Tighten Bolts</p> <p>This indicates time to tighten bolts, but not too tight! Do not crush the wood. This may create splinters and cause structural damage.</p>
<p>Square Assembly</p>	

CAUTION – Protrusion Hazard

Once the assembly is tightened, watch for exposed threads. If a thread protrudes from the T-nut, remove the bolt and add washers to eliminate this condition. Extra washers have been provided for this purpose.




Proper Hardware Assembly

Lag screws require drilling pilot holes to avoid splitting wood. Only a flat washer is required. For ease of installation, liquid soap can be used on all lag-type screws.


For bolts, tap T-nut into hole with hammer. Insert the hex bolt through lock washer first, then flat washer, then hole. Because the assemblies need to be squared, do not completely tighten until instructed. Pay close attention to diameter of the bolts. 5/16" (8mm) is slightly larger than 1/4" (6.4mm)

Note: Wafer head bolts with blue lock tight or a bolt with a Nylock® nut do NOT require a lock washer.



Part Identification (Reduced Size)

2x - **2606** - 23.8 x 82.6 x 362 mm - 3732606




2x - **2607** - 31.8 x 76.2 x 558.8 mm - 3732607



1x - **2614** - 76.2 x 133.4 x 2235.2 mm - 3732614


3" x 5-1/4" x 88"




1x - **2616** - 23.8 x 82.6 x 1181.1 mm - 3732616




1x - **8965** - 31.8 x 76.2 x 514.4 mm - 3738965



3x - **9998** - 31.8 x 63.5 x 127 mm - 3739998




1x - **11576** - 31.8 x 76.2 x 908.1 mm - 37311576




2x - **10917** - 50.8 x 76.2 x 2100 mm - 37310917

2" x 3" x 82-11/16"




2x - **11543** - 31.8 x 76.2 x 605 mm - 37311543



2x - **11544** - 31.8 x 76.2 x 2197.1 mm - 37311544

1-1/4" x 3" x 86-1/2"




1x - **11545** - 31.8 x 104.8 x 395 mm - 37311545



2x - **11546** - 31.8 x 76.2 x 605 mm - 37311546



1x - **11547** - 31.8 x 101.6 x 927.1 mm - 37311547




2x - **11548** - 31.8 x 76.2 x 2197.1 mm - 37311548

1-1/4" x 3" x 86-1/2"




Part Identification (Reduced Size)


1x - **11549** - 31.8 x 104.8 x 395 mm - 37311549



1x - **11550** - 31.8 x 76.2 x 395 mm - 37311550



1x - **11551** - 31.8 x 101.6 x 927.1 mm - 37311551



2x - **11552** - 31.8 x 76.2 x 923.9 mm - 37311552




1x - **11553** - 31.8 x 82.6 x 807.4 mm - 37311553



2x - **11554** - 31.8 x 76.2 x 925 mm - 37311554




2x - **11555** - 31.8 x 76.2 x 807.4 mm - 37311555



6x - **11556** - 31.8 x 76.2 x 807.4 mm - 37311556



4x - **11557** - 34.9 x 76.2 x 1033 mm - 37711557



4x - **11558** - 34.9 x 76.2 x 1033 mm - 37711558



11x - **11559** - 15.9 x 114.3 x 805.4 mm - 37711559



1x - **11560** - 15.9 x 82.6 x 805.4 mm - 37711560




1x - **11561** - 31.8 x 76.2 x 541.5 mm - 37311561




Part Identification (Reduced Size)

2x - **11562** - 15.9 x 114.3 x 805.4 mm - 37711562




5/8" x 4-1/2" x 31-11/16"

1x - **11563** - 31.8 x 123 x 807.4 mm - 37311563



1-1/4" x 4-7/8" x 31-13/16"

1x - **11564** - 15.9 x 88.9 x 805.4 mm - 37711564




5/8" x 3-1/2" x 31-11/16"

4x - **11565** - 31.8 x 76.2 x 355 mm - 37311565




1-1/4" x 3" x 14"

2x - **11566** - 38.1 x 38.1 x 536.6 mm - 37311566



1-1/2" x 1-1/2" x 21-1/8"

2x - **11567** - 31.8 x 44.5 x 285 mm - 37311567




1-1/4" x 1-3/4" x 11-1/4"

1x - **11568** - 31.8 x 50.8 x 285 mm - 37311568



1-1/4" x 2" x 11-1/4"

2x - **11569** - 15.9 x 101.6 x 923.9 mm - 37711569



5/8" x 4" x 36-3/8"

8x - **11570** - 31.8 x 50.8 x 854.1 mm - 37711570




1-1/4" x 2" x 33-5/8"

2x - **11571** - 25.4 x 76.2 x 508 mm - 37311571



1" x 3" x 20"

1x - **11572** - 31.8 x 76.2 x 395 mm - 37311572



1-1/4" x 3" x 15-9/16"

6x - **11573** - 9.5 x 76.2 x 188.5 mm - 37311573




3/8" x 3" x 7-7/16"

1x - **11574** - 15.9 x 63.5 x 183.6 mm - 37311574



5/8" x 2-1/2" x 7-1/4"

1x - **11575** - 25.4 x 63.5 x 152.4 mm - 37311575



1" x 2-1/2" x 6"




KidKraft
MADE FOR MAKE BELIEVE™

parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Part Identification (Reduced Size)

4x - **11578** - 31.8 x 76.2 x 369.9 mm - 37311578



1x - **11579** - 31.8 x 76.2 x 2336.8 mm - 37311579


1-1/4" x 3" x 92"



3x - **11580** - 31.8 x 76.2 x 923.9 mm - 37311580



2x - **11581** - 31.8 x 76.2 x 923.9 mm - 37311581



3x - **11582** - 9.5 x 76.2 x 409.6 mm - 37311582



1x - **11583** - 31.8 x 76.2 x 1143 mm - 37311583



1x - **11584** - 31.8 x 76.2 x 2336.8 mm - 37311584

1-1/4" x 3" x 92"



1x - **11585** - 15.9 x 136.5 x 539.8 mm - 37311585



1x - **11586** - 31.8 x 76.2 x 2336.8 mm - 37311586

1-1/4" x 3" x 92"




1x - **11587** - 31.8 x 76.2 x 923.9 mm - 37311587



1x - **11588** - 31.8 x 76.2 x 2336.8 mm - 37311588

1-1/4" x 3" x 92"



Part Identification (Reduced Size)

2x - **11589** - 31.8 x 76.2 x 807.4 mm - 37311589




1-1/4" x 3" x 31-13/16"

1x - **11590** - 15.9 x 56 x 805.4 mm - 37711590




5/8" x 2-3/16" x 31-11/16"

4x - **11591** - 31.8 x 76.2 x 355 mm - 37311591




1-1/4" x 3" x 14"

2x - **11592** - 38.1 x 38.1 x 857.2 mm - 37311592



1-1/2" x 1-1/2" x 33-3/4"

1x - **11593** - 31.8 x 76.2 x 923.9 mm - 37311593



1-1/4" x 3" x 36-3/8"

1x - **11594** - 31.8 x 76.2 x 923.9 mm - 37311594




1-1/4" x 3" x 36-3/8"

2x - **11595** - 31.8 x 76.2 x 807.4 mm - 37311595



1-1/4" x 3" x 31-13/16"

1x - **11596** - 31.8 x 133.4 x 807.4 mm - 37311596




1-1/4" x 5-1/4" x 31-13/16"

7x - **11597** - 15.9 x 76.2 x 495.3 mm - 37311597




5/8" x 3" x 19-1/2"

2x - **11598** - 31.8 x 76.2 x 990.5 mm - 37311598



1-1/4" x 3" x 39"

1x - **11599** - 31.8 x 76.2 x 630.3 mm - 37311599



1-1/4" x 3" x 24-13/16"

15x - **11600** - 15.9 x 76.2 x 527.1 mm - 37311600



5/8" x 3" x 20-3/4"

5x - **11601** - 15.9 x 76.2 x 679.5 mm - 37311601



5/8" x 3" x 26-3/4"



parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Part Identification (Reduced Size)

1x - **11602** - 31.8 x 76.2 x 1346.2 mm - 37311602




2x - **11603** - 31.8 x 76.2 x 215.9 mm - 37311603




2x - **11604** - 15.9 x 57.2 x 554.8 mm - 37311604



3x - **11605** - 9.5 x 76.2 x 356.8 mm - 37311605



4x - **11607** - 15.9 x 76.2 x 152.4 mm - 37311607



1x - **11608** - 76.2 x 76.2 x 1515.7 mm - 37311608




1x - **11609** - 15.9 x 114.3 x 431.8 mm - 37711609



2x - **11610** - 34.9 x 63.5 x 1292.5 mm - 37311610



4x - **11611** - 15.9 x 136.5 x 431.8 mm - 37711611



4x - **11612** - 15.9 x 136.5 x 431.8 mm - 37711612




1x - **11613** - 15.9 x 76.2 x 431.8 mm - 37711613



1x - **11614** - 31.8 x 76.2 x 460.2 mm - 37311614



1x - **9511** - 25.4 x 172.4 x 923.9 mm - 37779511
1 x 6-13/16\"/>



Part Identification (Reduced Size)

1x - **11615** - 31.8 x 76.2 x 807 mm - 37311615



1x - **11616** - 31.8 x 76.2 x 452.7 mm - 37311616



1x - **11617** - 15.9 x 88.9 x 923.9 mm - 37311617



1x - **11618** - 23.8 x 108 x 605.1 mm - 37711618



2x - **11619** - 25.4 x 50.8 x 1168.4 mm - 37311619




1x - **11620** - 31.8 x 76.2 x 860.4 mm - 37311620




2x - **11621** - 15.9 x 63.5 x 831.8 mm - 37711621




2x - **11622** - 38.1 x 38.1 x 337 mm - 37711622



4x - **11623** - 15.9 x 101.6 x 228.6 mm - 37711623




2x - **11624** - 31.8 x 63.5 x 871 mm - 37311624




2x - **11625** - 15.9 x 76.2 x 889 mm - 37311625



2x - **11626** - 15.9 x 101.6 x 923.9 mm - 37711626



1x - **9510** - 31.8 x 441.3 x 1152.6 mm - 37539510
1-1/4\"/>




Part Identification (Reduced Part Size)

1x - 3320353




1x - 9200131




1x - 9320374




1x - 9200144




1x - 9200143



2x - 9320130



2x - 9200133



2x - 9200145





2x - 9201225 - 25"

4x - 9201254 - 54"



1x - 3200157

1x - 9200166



7x - 9290318



6x - 9200025




6x - 9200020



6x - 9210010



1x - 33210023




1x - 9200186



10x - 9300130



9x - 3310121




2x - 9200087




1x - 9320040



1x - 3310122




1x - 3310123



2x - 9200157




31x - 54902200




1x - 9200156



1x - 3310124



1x - 3310132



30x - 53453202



1x - 53452209

Part Identification (Reduced Part Size)

1x - 9320197BL

1x - 9320197LG



1x - 9320296

1x - 9320297RD



1x - 9320889STGY

1x - 9320888STGY

1x - 9320889RD




1x - 9321691



4x - 9340500



1x - 3318115




1x - 9320881

1x - 9320382

1x - 9322282

1x - 9332608


2x - 52040302




1x - 3332609



8x - 9347701



1x - 3320161




Included in hardware kit



1x - 1/8" x 3"
(3.2 x 76.2mm)
(9300183)


1x - D1 (9200015)



2x - 9207711



2x - 9207712



1x - 9207713



4x - 9205933



4x - 9205970



3x - 9205975




Hardware Identification (Actual Size)

5 x **(LW1)** - 1/4" - 51303200
6.4mm




4 x **(FW1)** - 1/4" - 51103200
6.4mm




61 x **(LN1)** - 1/4" - 54303200
6.4mm




1 x **(TN1)** - 1/4" - 54503200
6.4mm




25 x **(LW2)** - 5/16" - 51303300
7.9mm




161 x **(FW2)** - 5/16" - 51103300
7.9mm




35 x **(LN2)** - 5/16" - 54303300
7.9mm




83 x **(TN2)** - 5/16" - 54503300
7.9mm




8 x **(FW6)** - #12 - 9299500




4 x **(FW0)** - 3/16" - 51103100
4.8mm



4 x **(BN1)** - 1/4" - 54803200
6.4mm




12 x **(S5)** - #8 x 1/2" - 52433502
12.7mm



3 x **(S2)** - #8 x 1-1/2" - 52043512
38.1mm




22 x **(S3)** - #8 x 2-1/2" - 52043522
63.5mm




94 x **(S4)** - #8 x 3" - 52043530
76.2mm



22 x **(S6)** - #12 x 1" - 52433610
25.4mm




78 x **(S7)** - #12 x 2" - 52433620
50.8mm




18 x **(S10)** - #8 x 1" - 52433510
25.4mm




28 x **(S11)** - #8 x 2" - 52043520
50.8mm



2 x **(S13)** - #6 x 5/8" - 52413908
16mm




126 x **(S0)** - #8 x 7/8" - 52933505
22.2mm




267 x **(S20)** - #8 x 1-3/8" - 52043516
34.9mm




19 x **(S37)** - #7 x 5/8" - 52433009
15.9mm




16 x **(S24)** - #10 x 4" - 52043940
101.6mm



2 x **(WL3)** - 1/4 x 1-3/8" - 52613216
6.4 x 34.9mm




20 x **(WL5)** - 1/4 x 2-1/2" - 52613222
6.4 x 63.5mm



1 x **(D4)** - #2 x 2" - 9200014




1 x **(D6)** - 3/16" - 9200019
4.8mm




Hardware Identification (Actual Size)


3 x **G5** - 5/16 x 4-1/2" - 53703342
7.9 x 114.3mm



6 x **G8** - 5/16 x 2" - 53703320
7.9 x 50.8mm




12 x **G7** - 5/16 x 5-1/2" - 53703352
7.9 x 139.7mm




1 x **G9** - 5/16 x 2-1/2" - 53703322
7.9 x 63.5mm



5 x **G10** - 5/16 x 3" - 53703330
7.9 x 76.2mm




7 x **G21** - 5/16 x 3-3/4" - 53703333
7.9 x 95.2mm




1 x **G36** - 5/16 x 2-3/4" - 53703323
7.9 x 69.9mm




1 x **H8** - 1/4 x 4-1/4" - 53703241
6.4 x 108mm




6 x **WB1** - 5/16 x 1" - 53613310
7.9 x 25.4mm




62 x **WB2** - 5/16 x 1-3/8" - 53613316
7.9 x 34.9mm




2 x **WB4** - 1/4 x 2" - 53613220
6.4 x 50.8mm




2 x **WB8** - 5/16 x 2-3/8" - 53613326
7.9 x 60.3mm




3 x **WB7** - 5/16 x 3" - (53613330)
7.9 x 76.2mm




2 x **WB9** - 5/16 x 2-1/8" - 53613324
7.9 x 54mm




49 x **PB1** - 1/4 x 3/4" - 53453203
6.4 x 19.1mm




6 x **WB10** - 5/16 x 2-5/8" - 53613329
7.9 x 66.6mm




4 x **PB2** - 1/4 x 1-1/4" - 53433212
6.4 x 31.8mm




11 x **PB6** - 1/4 x 1" - 53413210
6.4 x 25.4mm



2 x **Z** - 5/16 x 6" - 53703360
7.9 x 152.4mm




1 Inventory Parts - Read This Before Starting Assembly



Inventory should be completed before starting installation. KidKraft will not cover costs of any additional installation trip due to missing or damaged pieces.

- A. Referencing the parts identification sheets, inventory all hardware, wood and accessories. This will assist you with your assembly.
- The wood pieces will have the key number stamped on the ends of the boards. Organize the wood pieces by step, as per the key numbering system below.



- B. Read the assembly manual completely, paying special attention to EN71 and ASTM warnings, notes and safety/maintenance information on pages 1 - 8.

**If there are missing or damaged pieces,
please contact the KidKraft Consumer Engagement Team
before going back to the retailer.**

Request Replacement Parts 24/7

You can request replacement parts for this product 24 hours a day / 7 days a week:

Outdoor Swing Set and Playhouse Parts Ordering
<https://parts.kidkraft.com/partsorderemail>

If you have assembly or product questions, please refer to the front cover for direct contact information for our Consumer Engagement Team OR you can also use this QR code with your smartphone for common questions and contact information.






KidKraft Help Center <https://kidkraft.zendesk.com/hc/en-us/>

2 Panel B Assembly



Assemble T-Nuts first with hammer!
Make sure the assembly is square.



Wood Parts

1 x **11543** 31.8 x 76.2 x 605 mm (1-1/4" x 3" x 23-13/16") 1 x **11546** 31.8 x 76.2 x 605 mm (1-1/4" x 3" x 23-13/16")
 1 x **11544** 31.8 x 76.2 x 2197.1 mm (1-1/4" x 3" x 86-1/2") 1 x **11548** 31.8 x 76.2 x 2197.1 mm (1-1/4" x 3" x 86-1/2")

Hardware

4 x **WB2** 7.9mm x 34.9 mm
 (5/16 x 1-3/8")(FW2, TN2)





parts.kidkraft.com

customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100

3

Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

1 x 11552 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")

Hardware

2 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

4

Assemble T-Nuts first with hammer!
Make sure the assembly is square




Back View



Note notch orientation

Note hole orientation



Wood Parts

- 1 x 11550 31.8 x 76.2 x 395 mm (1-1/4" x 3" x 15-9/16")
- 1 x 11549 31.8 x 104.8 x 395 mm (1-1/4" x 4-1/8" x 15-9/16")

Hardware

- 2 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

5

Assemble T-Nuts first with hammer!
Make sure the assembly is square



Note hole orientation



Wood Parts

1 x 11551 31.8 x 101.6 x 927.1 mm (1-1/4" x 4" x 36-1/2")

Hardware

3 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)






parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

6 Panel A Assembly



Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

- 1 x 11543 31.8 x 76.2 x 605 mm (1-1/4" x 3" x 23-13/16")
- 1 x 11544 31.8 x 76.2 x 2197.1 mm (1-1/4" x 3" x 86-1/2")
- 1 x 11546 31.8 x 76.2 x 605 mm (1-1/4" x 3" x 23-13/16")
- 1 x 11548 31.8 x 76.2 x 2197.1 mm (1-1/4" x 3" x 86-1/2")

Hardware

- 4 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8") (FW2, TN2)





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

7

Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

1 x 11552 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")

Hardware

2 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100


8

Assemble T-Nuts first with hammer!
Make sure the assembly is square



Back View

Note notch orientation



Note hole orientation

Wood Parts

- 1 x 11545 31.8 x 104.8 x 395 mm (1-1/4" x 4-1/8" x 15-9/16")
- 1 x 11572 31.8 x 76.2 x 395 mm (1-1/4" x 3" x 15-9/16")

Hardware

- 2 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

9

Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

1 x 11547 31.8 x 101.6 x 927.1 mm (1-1/4" x 4" x 36-1/2")

Hardware

3 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

10 Panel C Assembly



Assemble T-Nuts first with hammer!
 Make sure the assembly is square
 Note hole orientation



Wood Parts

- 1 x **11553** 31.8 x 82.6 x 807.4 mm (1-1/4" x 3-1/4" x 31-13/16")
- 2x **11554** 31.8 x 76.2 x 925 mm (1-1/4" x 3" x 36-7/16")
- 2 x **11555** 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")

Hardware

- 6 x **WB2** 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, LW2, TN2)





parts.kidkraft.com

customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100

11 TNR Fort Frame Assembly



Pre-drill each hole using a 1/8" drill bit.
Make sure the assembly is square.



Wood Parts

1 x 11589 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")

Hardware



4 x S4 #8 x 76.2mm (#8 x 3")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

12



Pre-drill each hole using a 1/8" drill bit.
Make sure the assembly is square.



Wood Parts

1 x 11556 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")

Hardware




4 x S4 #8 x 76.2mm (#8 x 3")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

13



Pre-drill each hole using a 1/8" drill bit.
Make sure the assembly is square.



Wood Parts

- 1 x 11556 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")
- 1 x 11563 31.8 x 123 x 807.4 mm (1-1/4" x 4-7/8" x 31-13/16")

Hardware

- 8 x S4 #8 x 76.2mm (#8 x 3")







parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

14

Pre-drill each hole using a 1/8" drill bit for WL5






Hardware

6 x  6.4mm x 63.5 mm (1/4 x 2-1/2")

15 Fence Wall Assembly



Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

- 1 x **11580** 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")
- 1 x **11587** 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")
- 1 x **11586** 31.8 x 76.2 x 2336.8 mm (1-1/4" x 3" x 92")
- 1 x **11588** 31.8 x 76.2 x 2336.8 mm (1-1/4" x 3" x 92")


Hardware

- 4 x **WB2** 7.9mm x 34.9 mm (5/16" x 1-3/8") (FW2, TN2)




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

- 2 x 11607 15.9 x 76.2 x 152.4 mm (5/8" x 3" x 6")
- 1 x 11593 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")

Hardware




- 4 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8") (FW2, TN2)



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Assemble T-Nuts first with hammer!



Wood Parts

- 1 x **11580** 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")
- 1 x **11581** 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")

Hardware

- 2 x **WB2** 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)
- 2 x **WB1** 7.9 x 25.4 mm (5/16 x 1") (FW2, TN2)





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Assemble T-Nuts first with hammer!



Wood Parts

1 x 11602 31.8 x 76.2 x 1346.2 mm (1-1/4" x 3" x 53")

Hardware

1 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8") (FW2, TN2)

1 x WB1 7.9 x 25.4 mm (5/16 x 1") (FW2, TN2)




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

19


Assemble T-Nuts first with hammer!



Back View



Note notch orientation



Wood Parts

2 x 11578 31.8 x 76.2 x 369.9 mm (1-1/4" x 3" x 14-9/16")

Hardware

4 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8") (FW2, TN2)






parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

20 Twisty Ladder Wall Assembly



Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

- 1 x **11580** 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")
- 1 x **11581** 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")
- 1 x **11579** 31.8 x 76.2 x 2336.8 mm (1-1/4" x 3" x 92")
- 1 x **11584** 31.8 x 76.2 x 2336.8 mm (1-1/4" x 3" x 92")


Hardware

- 2 x **WB2** 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)
- 2 x **WB1** 7.9 x 25.4 mm (5/16 x 1") (FW2, TN2)




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

- 2 x **11607** 15.9 x 76.2 x 152.4 mm (5/8" x 3" x 6")
- 1 x **11594** 31.8 x 76.2 x 923.9 mm (1-1/4" x 3" x 36-3/8")

Hardware



- 4 x **WB2** 7.9mm x 34.9 mm (5/16 x 1-3/8") (FW2, TN2)



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Assemble T-Nuts first with hammer!



Wood Parts

1 x 11583 31.8 x 76.2 x 1143 mm (1-1/4" x 3" x 45")

Hardware

1 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)

1 x WB1 7.9 x 25.4 mm (5/16 x 1") (FW2, TN2)





parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

23

Assemble T-Nuts first with hammer!



Back View



Wood Parts

2 x 11578 31.8 x 76.2 x 371.5 mm (1-1/4" x 3" x 14-5/8")

Hardware

4 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8")(FW2, TN2)



parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

24

Hammer T-Nut
into the hole



Back View




Hardware

1 x (TN2)

25 SW Wall Assembly



Assemble T-Nuts first with hammer!
Make sure the assembly is square



Wood Parts

- 1 x 11595 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")
- 1 x 11596 31.8 x 133.4 x 807.4 mm (1-1/4" x 5-1/4" x 31-13/16")
- 2 x 11598 31.8 x 76.2 x 990.5 mm (1-1/4" x 3" x 39")


Hardware

- 6 x WB2 7.9mm x 34.9 mm (5/16 x 1-3/8") (FW2, TN2)



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100






Hardware

3 x  #8 x 22.2mm (#8 x 7/8")

Other Parts

1 x 

27



Wood Parts

1 x 11595 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")

Hardware




3 x S0 #8 x 22.2mm (#8 x 7/8")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Assemble T-Nuts first with hammer!



Hardware

2 x  7.9mm x 34.9 mm (5/16 x 1-3/8") (FW2, TN2)



parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

29 Fence Fort Frame Assembly




Twisty Ladder Wall Assembly

Fence Wall Assembly



Pre-drill each hole using a 1/8" drill bit.
Make sure the assembly is square.



Wood Parts

- 1 x 11589 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")
- 2 x 11556 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")

Hardware

- 12 x S4 #8 x 76.2mm (#8 x 3")







parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

30

Pre-drill each hole using a 1/8" drill bit



Hardware

6 x  6.4mm x 63.5 mm (1/4 x 2-1/2")


4 x  #8 x 76.2mm (#8 x 3")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100


31



Pre-drill each hole using a 1/8" drill bit.
Make sure the assembly is square.



11556



Note hole orientation

11556

1-1/4" (3.2 cm)

11556

Flush

Flush

x 4 per board

S4

Wood Parts

2 x 11556 31.8 x 76.2 x 807.4 mm (1-1/4" x 3" x 31-13/16")


Hardware

8 x S4 #8 x 76.2mm (#8 x 3")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Wood Parts

2 x 11571 25.4 x 76.2 x 508 mm (1" x 3" x 20")

Hardware

12 x S7 #12 x 50.8mm (#12 x 2")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Underneath View



Wood Parts

2 x 11619 25.4 x 50.8 x 1168.4 mm (1" x 2" x 46")


Hardware

10 x S7 #12 x 50.8mm (#12 x 2")



parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



(Hidden)

9205933

29"
(73.7cm)



Hardware

8 x **S0** #8 x 22.2mm (#8 x 7/8")






Other Parts

2 x **9205933**

Top View



Notice Angle Orientation



Caution: The Spring Loaded Quick Link must be attached to the Heavy Duty Swing Hanger in the closed position.

Wood Parts

1 x 2614 76.2 x 133.4 x 2235.2 mm (3" x 5-1/4" x 88")

Hardware

12 x G7 7.9 x 139.7 mm (5/16 x 5-1/2") (FW2 x 2, LN2)

Other Parts

6 x 9210010



6 x 9200025

36

Assemble T-Nuts first with hammer!



IT IS IMPORTANT THAT THIS BOLT IS ATTACHED. IT WILL MINIMIZE CHECKING OF WOOD.





Hardware

1 x  7.9mm x 76.2mm (5/16 x 3") (FW2 , TN2)



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100





Hardware

4 x (S20) #8 x 34.9mm (#8 x 1-3/8")

Other Parts

1 x 3320353



Notice Angle Orientation

Hardware

2 x  7.9mm x 95.2 mm (5/16 x 3-3/4") (FW2 x 2, LW2, LN2)


Other Parts

2 x 




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Do not tighten bolt until next step.



Wood Parts

- 2 x **10917** 50.8 x 76.2 x 2100 mm (2" x 3" x 82-11/16")
- 1 x **11608** 76.2 x 76.2 x 1515.7 mm (3" x 3" x 59-11/16")

Hardware

- 2 x **Z** 7.9 x 152.4 mm (5/16 x 6") (LW2, FW2 x 2, LN2)





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



40

IT IS IMPORTANT THAT THESE BOLTS ARE ATTACHED. THEY WILL MINIMIZE CHECKING OF WOOD.

Assemble T-Nuts first with hammer!



Tighten all bolts.



Wood Parts

1 x **2616** 23.8 x 82.6 x 1181.1 mm (15/16" x 3-1/4" x 46-1/2")


Hardware

3 x **G5** 7.9mm x 114.3mm (5/16 x 4-1/2")(LW2, FW2 x 2, LN2)
 2 x **WB7** 7.9mm x 76.2mm (5/16 x 3")(FW2, TN2)



parts.kidkraft.com

customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100





Hardware

5 x 7.9mm x 95.2 mm (5/16 x 3-3/4") (FW2 x 2, LW2, LN2)

Other Parts



1 x 9200144

1 x 9200143




Hardware

4 x 7.9mm x 50.8mm (5/16" x 2") (FW2 x 2, LW2, LN2)



Pre-drill each hole using a 1/8" drill bit for WL5
Assemble T-Nuts first with hammer!



Wood Parts

- 2 x **2606** 23.8 x 82.6 x 362 mm (15/16" x 3-1/4" x 14-1/4")
- 2 x **2607** 31.8 x 76.2 x 558.8 mm (1-1/4" x 3" x 22")

Hardware

- 2 x **WB9** 7.9mm x 54 mm (5/16 x 2-1/8")(FW2, TN2)
- 2 x **WL5** 6.4mm x 63.5 mm (1/4 x 2-1/2")(FW2)
- 6 x **S11** #8 x 50.8mm (#8 x 2")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100





Overlap panels as shown



Note: Structure partly removed for clarity

Inside View



Wood Parts

6 x 11573 9.5 x 76.2 x 188.5 mm (3/8" x 3" x 7-7/16")


Hardware

12 x S0 #8 x 22.2mm (#8 x 7/8")




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Inside View



Overlap panels as shown



Note: Structure partly removed for clarity

Wood Parts

3 x 11605 9.5 x 76.2 x 356.8 mm (3/8" x 3" x 14-1/16")


Hardware

6 x 50 #8 x 22.2mm (#8 x 7/8")




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Inside View



Overlap panels as shown



Note: Structure partly removed for clarity

Wood Parts

3 x 11582 9.5 x 76.2 x 409.6 mm (3/8" x 3" x 16-1/8")



Hardware

6 x 50 #8 x 22.2mm (#8 x 7/8")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



23-1/16"
(58.6cm)

Underneath View



Wood Parts

1 x 11616 31.8 x 76.2 x 452.7 mm (1-1/4" x 3" x 17-13/16")


Hardware

2 x S24 #10 x 101.6mm (#10 x 4")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Evenly space the boards





Wood Parts
 6 x 11600 15.9 x 76.2 x 527.1 mm (5/8" x 3" x 20-3/4")

Hardware
 24 x S20 #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com

customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100



Wood Parts

1 x 11618 23.8 x 108 x 605.1 mm (15/16" x 4-1/4" x 23-13/16")





Hardware

5 x S11 #8 x 50.8mm (#8 x 2")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Wood Parts

2 x 11604 15.9 x 57.2 x 554.8 mm (5/8" x 2-1/4" x 21-13/16")

Hardware



4 x S20 #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

51



Wood Parts

9 x 11600 15.9 x 76.2 x 527.1 mm (5/8" x 3" x 20-3/4")

Hardware


36 x S20 #8 x 34.9mm (#8 x 1-3/8")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Assemble T-Nuts first with hammer!



Note: Some parts hidden for clarity



Wood Parts

2 x 11592 38.1 x 38.1 x 857.2 mm (1-1/2" x 1-1/2" x 33-3/4")

Hardware

4 x WB10 7.9mm x 66.6 mm (5/16 x 2-5/8")(FW2, TN2)

4 x S3 #8 x 63.5mm (#8 x 2-1/2")





parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

53

Assemble T-Nuts first with hammer!



Note: Some parts hidden for clarity



Wood Parts

2 x 11566 38.1 x 38.1 x 536.6 mm (1-1/2" x 1-1/2" x 21-1/8")

Hardware

2 x WB10 7.9mm x 66.6 mm (5/16 x 2-5/8")(FW2, TN2)

4 x S3 #8 x 63.5mm (#8 x 2-1/2")




parts.kidkraft.com



customerservice@kidkraft.com
1.800.933.0771
972.385.0100

54

Make sure the [11561] part is level



Rotated View



Wood Parts

1 x [11561] 31.8 x 76.2 x 541.5 mm (1-1/4" x 3" x 21-5/16")

Hardware


4 x (S4) #8 x 76.2mm (#8 x 3")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Make sure the [11620] part is level



Rotated View



Wood Parts

1 x [11620] 31.8 x 76.2 x 860.4 mm (1-1/4" x 3" x 33-7/8")

Hardware

4 x (S4) #8 x 76.2mm (#8 x 3")





parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100

56

Assemble T-Nuts first with hammer!
Make sure the [11567] part is level



Rotated View



Wood Parts

2 x [11567] 31.8 x 44.5 x 285 mm (1-1/4" x 1-3/4" x 11-1/4")

Hardware

2 x [WB8] 7.9mm x 60.3 mm (5/16 x 2-3/8")(FW2, TN2)

4 x [S11] #8 x 50.8mm (#8 x 2")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

57

Make sure the [11568] part is level



Wood Parts

1 x [11568] 31.8 x 50.8 x 285 mm (1-1/4" x 2" x 11-1/4")



Hardware

4 x (S3) #8 x 63.5mm (#8 x 2-1/2")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100





Wood Parts
 2 x **11565** 31.8 x 76.2 x 355 mm (1-1/4" x 3" x 14")

Hardware
 2 x **S4** #8 x 76.2mm (#8 x 3")
 2 x **S3** #8 x 63.5mm (#8 x 2-1/2")



parts.kidkraft.com

customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100



Wood Parts

2 x **11565** 31.8 x 76.2 x 355 mm (1-1/4" x 3" x 14")



Hardware

4 x **S4** #8 x 76.2mm (#8 x 3")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Wood Parts

1 x 11574 15.9 x 63.5 x 183.6 mm (5/8" x 2-1/2" x 7-1/4")



Hardware

2 x S20 #8 x 34.9mm (#8 x 1-3/8")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Pre-drill each hole using a 1/8" drill bit for WL5




Wood Parts

4 x **11591** 31.8 x 76.2 x 355 mm (1-1/4" x 3" x 14")



Hardware

4 x **G10** 7.9mm x 76.2mm (5/16" x 3") (FW2 x 2, LN2)


4 x **WL5** 6.4mm x 63.5 mm (1/4 x 2-1/2") (FW2)



Top View



IMPORTANT!
Follow hole pattern



Wood Parts

1 x 11609 15.9 x 114.3 x 431.8 mm (5/8" x 4-1/2" x 17")

2 x 11610 34.9 x 63.5 x 1292.5 mm (1-3/8" x 2-1/2" x 50-7/8")

4 x 11611 15.9 x 136.5 x 431.8 mm (5/8" x 5-3/8" x 17")

4 x 11612 15.9 x 136.5 x 431.8 mm (5/8" x 5-3/8" x 17")

1 x 11613 15.9 x 76.2 x 431.8 mm (5/8" x 3" x 17")

Hardware

32 x S7 #12 x 50.8mm (#12 x 2")

4 x S20 #8 x 34.9mm (#8 x 1-3/8")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

63

Note: Make sure all hardware is used to properly secure each rock



Hardware

- 4 x **PB2** 7.9 x 32 mm (5/16 x 1-1/4") (FW0, LW1, BN1)
- 4 x **S10** #8 x 25.4 mm (#8 x 1")



Other Parts

- 1 x **9320197LG** 1 x **9320297RD**
- 1 x **9320197BL** 1 x **9320296**



parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Pre-drill each hole using a 1/8" drill bit for WL5



Flush

Center in the opening




Hardware

2 x WL5 6.4 x 63.5 mm (1/4 x 2-1/2") (FW2)





Pre-drill S7 holes using a 1/8" drill bit





Hardware

4 x S7 #12 x 50.8mm (#12 x 2")



Assemble T-Nut first with hammer!

Rotated Inside View



Wood Parts

1 x **11614** 31.8 x 76.2 x 460.2 mm (1-1/4" x 3" x 18-1/8")

Hardware

1 x **G36** 7.9mm x 69.9mm (5/16 x 2-3/4") (LW2, FW2, TN2)
 4 x **S0** #8 x 22.2mm (#8 x 7/8")

Other Parts


1 x **9205975**



parts.kidkraft.com


customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100

67



9320040

Pre-drill each hole using a 1/8" drill bit for WL3



6-1/2" (16.5 cm)

Hardware

2 x 6.4mm x 34.9mm (1/4 x 1-3/8")


Other Parts

1 x




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Evenly space the boards



Wood Parts

- 2 x 11562 15.9 x 114.3 x 805.4 mm (5/8" x 4-1/2" x 31-11/16")
- 1 x 11564 15.9 x 88.9 x 805.4 mm (5/8" x 3-1/2" x 31-11/16")


Hardware

- 12 x S20 #8 x 34.9mm (#8 x 1-3/8")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Evenly space the boards



Wood Parts

- 4 x **11559** 15.9 x 114.3 x 805.4 mm (5/8" x 4-1/2" x 31-11/16")
- 1 x **11560** 15.9 x 82.6 x 805.4 mm (5/8" x 3-1/4" x 31-11/16")


Hardware

- 30 x **S20** #8 x 34.9mm (#8 x 1-3/8")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Evenly space the boards



Wood Parts

- 7 x 11559 15.9 x 114.3 x 805.4 mm (5/8" x 4-1/2" x 31-11/16")
- 1 x 11590 15.9 x 56 x 805.4 mm (5/8" x 2-1/4" x 31-11/16")




Hardware

- 45 x S20 #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Evenly space the boards



11597
x 7

Tight

S20
x 4 per board

Tight

Wood Parts

- 7 x 11597 15.9 x 76.2 x 495.3 mm (5/8" x 3" x 19-1/2")
- 2 x 11625 15.9 x 76.2 x 889 mm (5/8" x 3" x 35")


Hardware

- 36 x S20 #8 x 34.9mm (#8 x 1-3/8")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



2-9/16" (6.5 cm) TYP 6 Places



11601 x 5

S20 x 4 per board

Tight

Wood Parts

5 x 11601 15.9 x 76.2 x 679.5 mm (5/8" x 3" x 26-3/4")




Hardware

20 x S20 #8 x 34.9mm (#8 x 1-3/8")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Rotated Inside View



Wood Parts


1 x 11615 31.8 x 76.2 x 807 mm (1-1/4" x 3" x 31-3/4")

Hardware



8 x S6 #12 x 25.4mm (#8 x 1")
 4 x S24 #10 x 101.6mm (#10 x 4")

Other Parts

2 x 9205975



Underneath View




Wood Parts


2 x 11603 31.8 x 76.2 x 215.9 mm (1-1/4" x 3" x 8-1/2")

Hardware

4 x S4 #8 x 76.2mm (#8 x 3")



Inside View




Hardware

8 x (S0) #8 x 22.2mm (#8 x 7/8")


Other Parts

2 x 9205933

76



Inside View



Centered in the opening

Hardware

6 x **S0** #8 x 22.2mm (#8 x 7/8")

Other Parts

1 x **9340500**




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Inside View



Centered in the opening





Hardware

18 x  #8 x 22.2mm (#8 x 7/8")

Other Parts

3 x 





Wood Parts

1 x **11599** 31.8 x 76.2 x 630.3 mm (1-1/4" x 3" x 24-13/16")

Hardware

1 x **G9** 7.9mm x 63.5mm (5/16 x 2-1/2") (FW2)
 1 x **G10** 7.9mm x 76.2mm (5/16 x 3") (FW2 x 2, LN2)



Wood Parts

1 x **11585** 15.9 x 136.5 x 539.8 mm (5/8" x 5-3/8" x 21-1/4")




Hardware

4 x **S20** #8 x 34.9mm (#8 x 1-3/8")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100






Hardware

2 x 6.4 x 50.8 mm (1/4 x 2") (FW1, LN1)


Other Parts

- 1 x
- 1 x

Make sure the Fireman Pole is straight and that the bottom of the pole is inserted into the ground as needed.



pole is to be 1-1/4" into the ground when installed



Hardware

2 x  7.9mm x 50.8mm (5/16" x 2") (LW2, FW2 x 2, LN2)

Other Parts

1 x 



MOVE FORT TO FINAL LOCATION PRIOR TO STAKING
FINAL LOCATION MUST BE LEVEL GROUND



Warning! To prevent tipping and avoid potential injury, stakes must be driven 9-13/16" (250mm) into ground. Digging or driving stakes can be dangerous if you do not check first for underground wiring, cables or gas lines.

SEE COVER PAGE FOR SAFETY CLEARANCE



Hammer U-Style Ground Stakes into the holes in the plate until they are fully anchored into the ground.



9200087

9200087

Other Parts
2 x 9200087



Wood Parts

1 x 9510 31.8 x 441.3 x 1152.6 mm (1-1/4" x 17-3/8" x 45-3/8")



Hardware

4 x S37 #7 x 15.9mm (#7 x 5/8")

Other Parts

1 x 9207713

1 x 9207711






Hardware

2 x S37 #7 x 15.9mm (#7 x 5/8")

Other Parts

1 x 9207711



Hardware

6 x S37 #7 x 15.9mm (#7 x 5/8")



Other Parts

2 x 9207712




parts.kidkraft.com

customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100





Front View



Hardware



6 x  #7 x 15.9mm (#7 x 5/8")

87



Important: Use a hand held screw driver and DO NOT over tighten.

Close door and vertically center magnetic catch to catch plate to assemble.



Wood Parts

1 x 11575 25.4 x 63.5 x 152.4 mm (1" x 2-1/2" x 6")

Hardware

3 x S11 #8 x 50.8mm (#8 x 2")

2 x S13 #6 x 15.9mm (#6 x 5/8")




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Front View



Back View



Wood Parts

- 3 x **9998** 31.8 x 63.5 x 127 mm (1-1/4" x 2-1/2" x 5")
- 1 x **11617** 15.9 x 88.9 x 923.9 mm (5/8" x 3-1/2" x 36-3/8")



Hardware

- 6 x **S11** #8 x 50.8mm (#8 x 2")




parts.kidkraft.com

customerservice@kidkraft.com
 1.800.933.0771
 972.385.0100





Underneath View



Hardware

8 x  #8 x 34.9mm (#8 x 1-3/8")



Tight

Note notch orientation

Flush

Wood Parts

1 x 9511 25.4 x 172.4 x 923.9 mm (1 x 6-13/16" x 36-3/8")

Hardware

3 x S11 #8 x 50.8mm (#8 x 2")







3 x S2 #8 x 38.1mm (#8 x 1-1/2")



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Complete this step four times






Hardware

32 x 6.3 x 19 mm (1/4 x 3/4") (LN1)

Other Parts

8 x









Hardware

4 x (PB1) 6.3 x 19 mm (1/4 x 3/4") (LN1)

Other Parts

1 x 3310122

1 x 3310123





Hardware




8 x 6.3 x 19 mm (1/4 x 3/4") (LN1)

Other Parts

- 1 x
- 1 x



**Note: Keep all bolts loose until further step.
Use Quadrex Driver as a guide pin for each hole before inserting bolt.**



Align each elbow using the molded arrows.






Other Parts

- 6 x 54902200
- 6 x 53453202 1/4" x 12.7mm

Complete this three times



Note: Keep all bolts loose until further step. Use Quadrex Driver as a guide pin for each hole before inserting bolt.



Align each elbow using the molded arrows.

Other Parts


- 18 x 54902200
- 18 x 53453202 1/4" x 12.7mm









parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

Use a 7/16" open end wrench to hold nut and then tighten bolt with Quadrex Driver.



Rotate Slide Exit



Hardware


5 x 6.4 x 19 mm (1/4 x 3/4") (LN1)

Other Parts

1 x

97

Tighten all slide bolts before the clamp rings go on in the next step.



Other Parts

- 6 x 54902200
- 6 x 53453202 1/4" x 12.7mm




parts.kidkraft.com





customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Warning. Do not over tighten the clamp rings.



After the clamp rings are attached to the elbows, fasten them end to end with two pan bolts and lock nuts





Note: For ease of assembly bottom set of clamp rings can be rotated 90 degrees to install bolts.

Hardware






10 x (PB6) 6.4 x 25.4 mm (1/4 x 1") (LN1)

Other Parts

10 x (9300130)



Pre-drill each hole using a 1/8" drill bit. Making sure the pre-drilled holes are a minimum of 1" deep.



Pre-drill each hole using a 1/8" drill bit. Making sure the pre-drilled holes are a minimum of 1" deep.



Hardware

- 10 x  #12 x 25.4mm (#12 x 1")
- 8 x  #12 x 50.8mm (#12 x 2")
- 8 x  #12




parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Remove PB1 (1/4 x 3/4" Pan Bolt), The bolt (PB1) will no longer be needed, but keep the lock nut (LN1)



9200158



Note: Flat end down


Install PB6 (1/4 x 1" Pan Bolt) with flat washer (FW1)

Hardware


- 1 x PB6 6.4 x 25.4 mm (1/4 x 1") (FW1)
- 1 x S6 #12 x 25.4mm (#12 x 1")

Other Parts

- 1 x 9200158



Assemble T-Nut first with hammer!




Wood Parts





- 1 x **8965** 31.8 x 76.2 x 514.4 mm (1-1/4" x 3" x 20-1/4")
- 1 x **11576** 31.8 x 76.2 x 908.1 mm (1-1/4" x 3" x 35-3/4")

Hardware

- 1 x **S11** #8 x 50.8mm (#8 x 2")
- 1 x **H8** 6.4mm x 108mm (1/4 x 4-1/4") (LW1, FW1, TN1)



Rotated View



Pre-drill with a 1/8" drill bit.

Hardware

- 1 x S37 #7 x 15.9mm (#7 x 5/8")
- 2 x S6 #12 x 25.4mm (#12 x 1")
- 3 x S7 #12 x 50.8mm (#12 x 2")

Other Parts


- 1 x 54902200
- 2 x 9200157
- 1 x 9200156
- 1 x 53452209 1/4 x 14.5mm
- 1 x 9200770



Complete this step four times

Note notch orientation

Note notch orientation



Wood Parts

- 4 x **11557** 34.9 x 76.2 x 1033 mm (1-3/8" x 3" x 40-11/16")
- 4 x **11558** 34.9 x 76.2 x 1033 mm (1-3/8" x 3" x 40-11/16")

Hardware

- 4 x **S4** #8 x 76.2mm (#8 x 3")




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Complete this step
four times



Wood Parts

4 x **11623** 15.9 x 101.6 x 228.6 mm (5/8" x 4" x 9")

Hardware

16 x **S20** #8 x 34.9mm (#8 x 1-3/8")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

105

Complete this step twice



Wood Parts

2 x 11624 31.8 x 63.5 x 871 mm (1-1/4" x 2-1/2" x 34-5/16")

Hardware

4 x S24 #10 x 101.6mm (#10 x 4")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

106

Complete this step twice.
Pre-drill each hole using a 1/8" drill bit.



Wood Parts

4 x 11570 31.8 x 50.8 x 854.1 mm (1-1/4" x 2" x 33-5/8")

Hardware

16 x S4 #8 x 76.2mm (#8 x 3")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

107

Complete this step twice.
Pre-drill each hole using a 1/8" drill bit.



Wood Parts

4 x 11570 31.8 x 50.8 x 854.1 mm (1-1/4" x 2" x 33-5/8")


Hardware

16 x S4 #8 x 76.2mm (#8 x 3")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Complete this step eight times

Pre-drill each hole using a 1/8" drill bit in the GRASS. Ensure holes are centered in the valleys.




Other Parts

8 x 9347701

109

Complete this step twice.
Note hole orientation.






Hardware

8 x  #8 x 22.2mm (#8 x 7/8")

110

Complete this step twice.
Note hole orientation.



Hardware

12 x  #8 x 22.2mm (#8 x 7/8")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

111

Complete this step twice.
Note hole orientation.






Hardware

8 x  #8 x 22.2mm (#8 x 7/8")

112

Complete this step twice.
Note hole orientation.



Hardware

12 x  #8 x 22.2mm (#8 x 7/8")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Complete this step twice



Wood Parts

- 2 x 11569 15.9 x 101.6 x 923.9 mm (5/8" x 4" x 36-3/8")
- 2 x 11626 15.9 x 101.6 x 923.9 mm (5/8" x 4" x 36-3/8")



Hardware

- 14 x S10 #8 x 25.4 mm (#8 x 1")
- 12 x S20 #8 x 34.9mm (#8 x 1-3/8")






parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Hardware

3 x  #10 x 101.6mm (#10 x 4")



Wood Parts

2 x **11622** 38.1 x 38.1 x 337 mm (1-1/2" x 1-1/2" x 13-1/4")


Hardware

4 x **S3** #8 x 63.5mm (#8 x 2-1/2")




parts.kidkraft.com




customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Front View






Back View




Hardware

4 x  #8 x 63.5mm (#8 x 2-1/2")





Hardware

3 x  #10 x 101.6mm (#10 x 4")



Side View



Inside View

Wood Parts

2 x 11621 15.9 x 63.5 x 831.8 mm (5/8" x 2-1/2" x 32-3/4")


Hardware

8 x S20 #8 x 34.9mm (#8 x 1-3/8")





parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Side View




Hardware



- 4 x  #8 x 22.2mm (#8 x 7/8")
- 8 x  #8 x 12.7mm (#8 x 1/2")

Other Parts

- 4 x 



Underneath View



Hardware






2 x #8 x 22.2mm (#8 x 7/8")

Other Parts

1 x	1 x
1 x	1 x

121

Important: Use a hand held screw driver and DO NOT over tighten



Hardware

6 x (S0) #8 x 22.2mm (#8 x 7/8")



Other Parts

1 x 9320382	2 x 52040302	1 x 9322282
1 x 9332608	1 x 9320881	1 x 3332609



parts.kidkraft.com


customerservice@kidkraft.com
1.800.933.0771
972.385.0100



Tight

Note: Pre-drill all holes using a 1/8" drill bit before installing the pan screws.

Place Slide centered in the opening.





Tight

Hardware

3 x S7 #12 x 50.8 mm (#12 x 2")

Other Parts

1 x 3318115




Hardware

2 x  #8 x 34.9mm (#8 x 1-3/8")

Other Parts




1 x 



Warning! To prevent tipping and avoid potential injury, stakes must be driven 13" (33 cm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.

SEE COVER PAGE FOR SAFETY CLEARANCE

Rotated View




Hardware

- 1 x **S6** #12 x 25.4mm (#12 x 1")
- 2 x **S7** #12 x 50.8mm (#12 x 2")

Other Parts


- 3 x **9290318**



Warning! To prevent tipping and avoid potential injury, stakes must be driven 13" (33 cm) into ground. Digging or driving stakes can be dangerous if you do not check first for under-ground wiring, cables or gas lines.


Hardware
4 x #12 x 50.8mm (#12 x 2")

Other Parts
4 x



ATTACH THIS WARNING & I.D. PLAQUE TO THIS LOCATION ON YOUR PLAY EQUIPMENT!

This provides warnings concerning safety and important contact information. A Tracking Number is provided to allow you to get critical information or order replacement parts for this specific model.



9320374

WARNING
AVERTISSEMENT

CONTINUOUS ADULT SUPERVISION REQUIRED!

STRANGULATION HAZARDS
Never allow children to play with ropes, doilies, ties, pet leashes, cables, chains or cordlike items when using the playset or to attach these items to play-set.
Never allow children to wear loose fitting clothing, ponchos, hoods, scarves, capes, neckties, or items with drawstrings, cords or ties when using this play-set.
Never allow children to wear bike or sport helmets when using this play-set.
Failure to prohibit these items increases the risk of serious injury and death to children from entanglement and strangulation.

SERIOUS HEAD INJURY HAZARD
Maintain shock absorbing material under and around play-set as recommended in the Installation & Operating Instructions. Installation over concrete, asphalt, dirt, grass, carpet and other hard surfaces creates a risk of serious injury or death from falls to the ground.

SURVEILLANCE CONSTANTE D'ADULTE EST REQUIS!

Risques D'Étranglement
Ne jamais laisser les enfants jouer avec des cordes, cordes à linge, basses pour animaux, des câbles, des chaînes ou ces type articles pendant de l'utilisation de cet portique de jeu ou à l'attaché de ces éléments à la portique de jeu.
Ne jamais laissez les enfants de porter des vêtements amples, des ponchos, des toques, des foulards, capes, des colliers ou des articles avec cordes attaché ou les cordons pendant l'utilisation de cet portique de jeu.
Ne jamais laissez les enfants porter un casque de vélo ou de sport quand ils utilisent ce portique de jeu.
D'éviter d'installer ces éléments sur une surface dure qui crée un risque de blessures graves et de décès des enfants de enchevêtrement et d'étranglement.

RISQUE DE BLESSURES GRAVES DU TÊTE
Maintenir le matériau absorbant les chocs sous et autour de la portique de jeu comme recommandé dans les instructions.
D'installer sur béton, de l'asphalte, sol de l'herbe, tapis et autres surfaces dures crée un risque de blessure à la tête graves ou la mort causé par tomber à la sol.

THIS PRODUCT IS INTENDED FOR USE BY CHILDREN FROM AGES 3 TO 10, weight limit of 110 lbs., per child. Maximum number of users. Installation & Operating Instructions; other information is available at: www.kidkraft.com
POUR LES ENFANTS DE 3 À 10 ANS D'ÂGE, limite de 110 Livres par enfant. Nombre maximum d'utilisateurs. Installation et d'utilisation, d'autres informations sont disponibles sur: www.kidkraft.com

Contact us at: Backyard Kids, LLC DBA KidKraft
317 S. Main St., Ann Arbor, MI 48104
1-800-933-0771

Tracking Number:
Numero de Suivi:

Hardware

4 x **S5** #8 x 12.7mm (#8 x 1/2")

Other Parts


1 x **9320374**




parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

127




9200025



9201225
9201254


Tighten Threaded Quick Link using adjustable wrench



9201254

9200020

9320130




9201225

9201254

9200131

9201254

9320130




9201225

9200020

9200131

9200133

Caution: Threaded Quick Links must be installed with the gate completely down covering the threads and tighten as instructed.



9200020
Quick Link

Threaded Quick Links attach to seat and acro bar

Tighten Threaded Quick Link using adjustable wrench

Other Parts

- 4 x 9201254 2 x 9320130
- 2 x 9201225 2 x 9200133
- 1 x 9200131 6 x 9200020



parts.kidkraft.com

customerservice@kidkraft.com
1.800.933.0771
972.385.0100

