






















# ASSEMBLY INSTRUCTION

## TWIN LOUNGE BED

<b>A</b> Headboard  1 pc	<b>B</b> Back Panel  1 pc	<b>C</b> Footboard  1 pc	<b>D</b> Side Rail  1 pc
<b>E</b> Slat Roll  1 pc	<b>F</b> Long Rail Support  2 pcs	<b>G</b> Short Rail Support  2 pcs	<b>H</b> Big Leg  3 pcs
<b>I</b> Small Leg  1 pc	<b>J</b> Allen Bolt Ø5/16" x 32mm  20 pcs	<b>K</b> Allen Bolt Ø5/16" x 38mm  7 pcs	<b>L</b> Allen Bolt Ø5/16" x 50mm  16 pcs
<b>M</b> Spring Washer Ø5/16"  43 pcs	<b>N</b> Flat Washer Ø5/16" x 19 mm  27 pcs	<b>O</b> Flat Washer Ø5/16" x 22 mm  16 pcs	<b>P</b> Screw Ø8 x 30mm  50 pcs
<b>Q</b> Wood Dowel Ø8 x 40mm  1 pc	<b>R</b> Metal Connector 150 x 70 x 38 x 3mm  4 pcs	<b>S</b> Allen Key 4mm  1 pc	<b>T</b> Mattress Cover  1 pc



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


### IMPORTANT NOTE:

1. Do not tighten all screws / bolts until all completely assembled.
2. Keep all hardware parts out of reach of children.

**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**

**1**


Attach Big Leg (H) to Headboard (A) using Allen Bolt (K), Spring Washer (M) and Flat Washer (N) with Allen Key (S).




**2**

Attach Long & Short Rail Support (F&G) to Back Panel (B) using Allen Bolt (L), Spring Washer (M) and Flat Washer (O) with Allen Key (S).

OPTION 1:



OPTION 2:





**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**

**3**

Attach Long & Short Rail Support (F&G) to Side Rail (D) using Allen Bolt (L), Spring Washer (M) and Flat Washer (O) with Allen Key (S).

OPTION 1:

OPTION 2:





**4**

Attach Big Leg (H) to Back Panel (B) using Allen Bolt (K), Spring Washer (M) and Flat Washer (N) with Allen Key (S).

OPTION 1:

OPTION 2:





**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**

**5**

Attach Small Leg (I) to Side Rail (D) using Wood Dowel (Q) and Allen Bolt (K), Spring Washer (M) and Flat Washer (N) with Allen Key (S).

OPTION 1:


OPTION 2:



**6**


Attach Headboard (A), Back Panel (B), Footboard (C) and Side Rail (D) by Metal Connector (R) using Allen Bolt (J), Spring Washer (M), Flat Washer (N) with Allen Key (S) and using Screw (P) with Phillips Head Screwdriver (not provided).

OPTION 1:




**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**

## OPTION 2:



Phillips Head Screwdriver (not provided)  
is required for assembly.  
Use the Phillips Head Screwdriver to  
tighten the wood screws.



**7** Attach Slat Roll (E) on Side Rail (D) using Screw (P) with Phillips Head Screwdriver (not provided).  
OPTION 1:



Phillips Head Screwdriver (not provided)  
is required for assembly.  
Use the Phillips Head Screwdriver to  
tighten the wood screws.

**\*\*\* Do not tighten screws & bolts until the entire unit is completely assembled.**

OPTION 2:



Phillips Head Screwdriver (not provided)  
is required for assembly.  
Use the Phillips Head Screwdriver to  
tighten the wood screws.

**Cleaning & Care**

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.