



















ASSEMBLY INSTRUCTION

2020TBK-1(3A) AVERNY BLACK METAL TWIN PLATFORM BED


A LSF Headborad Post	B RSF Headborad Post	C LSF Footborad Post	D RSF Footborad Post
			
1PC	1PC	1PC	1PC
E Headboard/ Footboard	F Rail Section(1)	G Rail Section(2)	H Rail Support Leg
			
2PCS	2PCS	2PCS	2PCS
I Center Support Bar	J Slat	K Slat Connector	L Finial
			
1PC	16PCS	32PCS	4PCS
M Bolt 1/4"*13mm	N Bolt 1/4"*36mm	O Nut 1/4"	P L-Allen Key 4mm
			
20PCS	4PCS	4PCS	1PC
Q Wrench			
			
1PC			



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1

Align the LSF Headboard Post(A) and RSF Headboard Post(B) to the Headboard/Footboard(E), insert the Bolt(M) to the holes, turn the L-Allen Key(P) to tighten them. Align the LSF Footboard Post(C) and RSF Footboard Post(D) to the Headboard/Footboard(E), insert the Bolt(M) to the holes, turn the L-Allen Key(P) to tighten them.




2

Attach the Rail Section(1)(F), the Rail Section(2)(G) to the Headboard/Footboard(E), insert the Bolt(M), turn the L-Allen Key(P) to tighten them. Attach the Rail Support Leg(H) to the rail, insert the Bolt(M), turn the L-Allen Key(P) to tighten them.




3

Attach the Center Support Bar(I) to the rail, insert the Bolt(N) and the Nut(O), turn the L-Allen Key(P) and Wrench(Q) to tighten them.




4

Attach the Finial(L) to the post, then tighten it.



5

Attach the Slat(J) and the Slat Connector(K) to the rail, then tighten it.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratchresistant. Clean surfaces with a dry or damp soft cloth.Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.