

Item: HANB4C

Assembly Instructions




Please visit our website for the most current instructions, assembly tips, to report damage or request parts. www.walkerredison.com

Revised 04/2024 - V2


General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The two main types of hardware used to assemble this product are: wood dowels and screws.
- V. A Phillips head screwdriver is required for the assembly of this product (not included)










Parts List



Keep the sticker for reference in case you need a replacement part in the future



Part #	Description	Qty
01	Top Panel	1
04	Bottom Panel	1
09	Back Panel	1
10	Shelf	1
12	Right Side Panel	1
13	Left Side Panel	1
14	Foot	4
15	Drawer Front	1
16	Drawer Side	2
17	Drawer Bottom	1
18	Drawer Back	1


Hardware List

A		Ø8x30	Wooden Dowel	20 pcs
B		Ø7x30mm	Cam Bolt	12 pcs
C		Ø15x10mm	Cam Lock	12 pcs
D		Ø3,5x12mm	Screw	10 pcs
E		Ø3x16mm	Screw	4 pcs
F		Ø3,5x40mm	Screw	4 pcs
G		Ø5x40mm	Screw	8 pcs
H		14x14mm	Support	4 pcs
I		Ø 19mm	Sticker	8 pcs
K1		300mm	Metal Slider	1 pcs
K2		300mm	Metal Slider	1 pcs
L1		300mm	Metal Slider	1 pcs
L2		300mm	Metal Slider	1 pcs



The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.



Step 1




Please assemble on a clean soft surface to avoid damage.




Insert wooden dowel (A) to parts (12,13,10) and insert cam bolt (B) to parts (1,12,13).

A	 $\varnothing 8 \times 30$	12
B	 $\varnothing 7 \times 30 \text{mm}$	8


Step 2



G		Ø5x40	8
---	---	-------	---

Attach feet (14) to part (4) with screw (G).


Step 3





Please assemble on a clean soft surface to avoid damage.



Attach Metal Slider (K1,L1) to parts (12,13) with screw (D).

K1		300mm	1
L1		300mm	1
D		Ø3,5x12mm	6



Step 4



Secure part (10) to part (12) using cam lock (C) as per diagram.

C			Ø15x10mm	2
---	--	--	----------	---


Step 5




Secure parts (12,10) to part (13) using cam lock (C) as per diagram.

C			Ø15x10mm	2
---	--	--	----------	---


Step 6



Secure part (4) to parts (12,13) using screw (F)





Step 7



Slide back panel (9) into side panel (12,13).


Step 8



Secure part (1) to parts (12,13) using cam lock (C).

C		Ø15x10mm	4
---	--	----------	---


Step 9





Secure back panel (9) using screw (E) and support (H).

E		Ø3x16mm	4
H		14x14mm	4


Step 10



Insert wooden dowel (A) to parts (16,16) and insert cam bolt (B) to part (15,18).

A		Ø6x30	8
B		Ø7x30mm	4


Step 11



First: Secure parts (16,16) to part (18) using cam lock (C).
 Second: Slide part (07) into grooves as per diagram.
 Third: Secure part (15) to parts (16,16) using cam lock (C).

C		Ø15x10mm	4
---	---	----------	---


Step 12




Attach Metal Slider (K2,L2) to parts (16,16) with screw (D).

D	 Ø3,5x12mm	4
K2	 300mm	1
L2	 300mm	1



Step 13



Place sticker (I) over holes as per diagram.

I	 Ø 19mm	8
---	--	---

Step 14



Step 15

