


# Item: ELIB5B

## Assembly Instructions






Please visit our website for the most current instructions, assembly tips, to report damage or request parts. [www.walkeredison.com](http://www.walkeredison.com)

Revised 09/2024-V2


# General assembly guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. A Phillips head screwdriver, hammer and tape measure is required for the assembly of this product.





Tape measure

- VI. Power tools should not be used to assemble this product.



# Parts List
















The side drawer with WARNING LABEL, should be mounted in highest drawer.




Part #	Description	Qty
01	Top panel	01 pc
02	Left side panel	01 pc
03	Right side panel	01 pc
04	Bottom panel	01 pc
05	Front Rail	01 pc
06	Top back panel	01 pc
07	Lower back panel	01 pc
08	Division	01 pc
09	Center Foot	01 pc
10	Slider Support	06 pcs
13	Small right drawer front	01 pc

Part #	Description	Qty
14	Small drawer back	02 pcs
15	Drawer bottom	06 pcs
16	Drawer front	04 pcs
17	Drawer back	04 pcs
20	Small left drawer front	01 pc
26	Foot	04 pcs
29	Small left drawer side	02 pcs
30	Small right drawer side	01 pc
39	Right drawer side with warning	01 pc
51	Left drawer side	04 pcs
52	Right drawer side	04 pcs

# Hardware List


A		Ø8*30mm	Wooden dowel	34 pcs
B		Ø3,5*30mm	Screw	24 pcs
C		Ø6,0*8mm	Screw	18 pcs
D		Ø6,0*20mm	Screw	18 pcs
E		Ø15*12mm	Cam lock	29 pcs
F		Ø3,5*14mm	Screw	48 pcs
G	 Ø7*80mm		Screw	05 pcs
H		Ø4,0*20mm	Screw	07 pcs
I		Ø6*31mm	Cam bolt	29 pcs
J		Ø4,0*40mm	Screw	13 pcs
K		Ø6*35mm	Plastic bush	01 pc
L			Threaded foot insert	01 pc
M			Leveling foot	01 pc
N			Wall anchor	01 pc
O			Washer	02 pcs



Hammer recommended for assembly (not included)











Phillips head screwdriver required for assembly (not included)



Tape measure required for assembly (not included)



*The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.*

# Hardware List



P		Ø30mm	Felt Sticker	04 pcs
Q		Ø26mm	Plastic fixing device	06 pcs
R		Ø250mm	Right Drawer slide support	06 pcs
S		Ø250mm	Left Drawer slide support	06 pcs
T		Ø250mm	Right Drawer slide	06 pcs
U		Ø250mm	Left Drawer slide	06 pcs
V			Handle	06 pcs
W		50x50x50mm	Hex Key	01 pc

# Step 1


Insert wood dowel (A) into parts 02, 03, 05, 08, 26, 29, 30, 39, 51 and 52.





Please assemble on a clean soft surface to avoid damage.




# Step 2



1 - Ensure cam bolt is installed straight and not at an angle.  
2 - Tighten cam bolt until shoulder on cam bolt is flush. Do not over-tighten.






Attach cam bolt (I) into the holes in parts 01, 02, 03, 13, 16 and 20 with Phillips head screwdriver.



# Step 3



Tap the Plastic fixing device (Q) carefully.




Use a hammer to tap the Plastic fixing device (Q) into parts 02 and 03.





# Step 4



Secure Right side slide support (R) to part 10 and 03 with screw (D) and phillips head screwdriver.






1st



2nd






D		09
	Ø6,0*20mm	
F		03
	Ø3,5*14mm	
R		03
	ø250mm	

Secure Right side slide support (R) to part 10 with screw (F) and phillips head screwdriver.



# Step 5




Secure Left side slide support (S) to part 10 and 02 with screw (D) and phillips head screwdriver.

## 1st



## 2nd




D	 Ø6,0*20mm	09
F	 Ø3,5*14mm	03
S	 ø250mm	03

Secure Left side slide support (S) to part 10 with screw (F) and phillips head screwdriver.

# Step 6

Secure Right side slide support (R) to part 08 with screw (C) and phillips head screwdriver.


## 1st




Pay attention to the identification




## 2nd

Secure Right side slide support (S) to part 08 with screw (F) and phillips head screwdriver.



Rotate 180°





C		Ø6,0*8mm	09
F		Ø3,5*14mm	03
R		ø250mm	03

# Step 7




Secure Left side slide support (S) to part 08 with screw (C) and phillips head screwdriver.




## 1st



TOP ↑

## 2nd



C		09
	Ø6,0*8mm	
F		03
	Ø3,5*14mm	
S		03
	ø250mm	

Secure Left side slide support (S) to part 08 with screw (F) and phillips head screwdriver.

# Step 8

Use a hammer to tap the Threaded foot insert (L) into the hole of part 09.

Insert Leveling foot (M) into the Threaded foot insert (L) and rotate until the part fits fully.

**1st**

**2nd**

M		01
L		01

**!** Tap the Threaded foot insert (L) carefully.

# Step 9



Secure part 09 to part 04 with screw (G) and tighten with a Hex Key (W).

W		01
G		01


50x50x50mm

Ø7\*80mm


# Step 10



Remove the felt sticker (P) from the paper.  
Glue the felt to the bottom of the foot.





# Step 11



Attach parts 26 to part 04, using screws (G) and tighten with hex key (W).



# Step 12

Attach part 02 to part 04 with Screw (J) and Phillips head screwdriver.




# Step 13


Attach part 08 to part 04 with Screw (J) and Phillips head screwdriver.





# Step 14



Align the opening in cam lock to the cam bolt and press into opening. Using a screwdriver, rotate the cam lock until it engages with the cam bolt and locks in place (anywhere between 90-180 degrees). Do not over-tighten the cam lock. Doing so may result in damaged or broken parts.






Fit part 05 to part 08 and 02.  
Insert Cam lock (E) in the hole of the part 05 and attach with a Phillips head screwdriver.





# Step 15



Fit part 03 to parts 04 and 05.


Attach part 03 to part 04 with Screw (J) and Phillips head screwdriver.

Insert Cam lock (E) in the hole of the part 05 and attach with a Phillips head screwdriver.


J		03 Ø4,0*40mm
E		01 Ø15*12mm

# Step 16


Insert parts 06 and 07 between the grooves of parts 02 and 03.

 Two people are needed to this step.

Name and address of the supplier and date of production.




**2nd**





Fit parts 01 to parts 02, 03 and 08.

# Step 17





Secure part 07 to parts 02 and 03 with screw (J) and Phillips head screwdriver.



J		04
		Ø4,0*40mm



# Step 18





**FRONT**

Insert Cam lock (E) in the hole of the part 08 and attach with a Phillips head screwdriver.


Attach parts 02 and 03 to part 01 with screw (H) and Phillips head screwdriver.

H		06
		ø4,0*20mm
E		03
		Ø15*12mm


# Step 19




Attach part 51 and 52 to part 16. Insert Cam lock (E) into the holes in the parts 51 and 52, and attach with Phillips head screwdriver.







# Step 20



Insert part 15 between the grooves of parts 51 and 52. Secure part 17 to parts 11 and 12 with screw (B) and Phillips head screwdriver.




# Step 21







Attach part 29 and 30 to part 20. Insert Cam lock (E) into the holes in the parts 29 and 30, and attach with Phillips head screwdriver.


Attach part 29 and 39 to part 13. Insert Cam lock (E) into the holes in the parts 29 and 39, and attach with Phillips head screwdriver.




# Step 22





Insert part 15 between the grooves of parts 29, 30 and 39. Secure part 14 to parts 29, 30 and 39 with screw (B) and Phillips head screwdriver.



# Step 23



4x







F		Ø3,5x14	08
---	--	---------	----

V			04
---	--	--	----

Attach handle (V) into part 16 with screw (F) and Phillips head screwdriver.

# Step 24



F		Ø3,5x14	04
---	--	---------	----

V			02
---	--	--	----











Attach handle (V) into parts 13 and 20 with screw (F) and Phillips head screwdriver.

# Step 25

Secure Right drawer slide (T) into parts 30,39 and 52 with screw (C), tighten with a Phillips head screwdriver.

Secure Left drawer slide (U) into parts 29 and 51 with screw (C), tighten with a Phillips head screwdriver.



Rotate 90°



# Step 26



1 - Fit the Right drawer slide (T) into the Right side slide support (R).

2 - Fit the Right drawer slide (U) into the Right side slide support (S).



Fit the assembled drawers between parts 02, 08 and 03.

# Step 27



Rotate the Leveling foot to align it with the floor.




# Step 28

# WARNING


**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

**Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.**





## ! 1st






Attach part (N) with screw (H) and washer (O), in the frame of top panel unit using Phillips head screwdriver.




## ! 2nd

With drilling machine make one hole in the wall, insert part (K) in the hole. Secure part (N) with screw (J) and washer (O) in the wall using a Phillips head screwdriver.



H	 Ø4,0*20mm	01
J	 Ø4,0*40mm	01
K		01
N		01
O		02



Name and address information for the manufacturer responsible for the anti-tip hardware and date of production can be found on the label on the back of the furniture.

Step 29

# Assembly Complete!

