














ASSEMBLY INSTRUCTION

416 METAL DAYBED


A	Left Arm Post Leg	B	Right Arm Post Leg	C	Lsf Arm	D	Rsf Arm
							
2PCS		2PCS		1PC		1PC	
E	Back Frame	F	Rail	G	Slat	H	Slat Connector
							
1PC		2PCS		22PCS		44PCS	
I	Spacer	J	Bolt 1/4"*55mm	K	Bolt 1/4"*16mm	L	L-Allen Key 4mm
							
21PCS		2PCS		14PCS		1PC	




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1


Attach Left Arm Post Leg (A) & Right Arm Post Leg (B) into the Lsf Arm (C), insert the Bolt (K), turn the L-Allen Key (L) to tighten them.

**2**

Attach Left Arm Post Leg (A) & Right Arm Post Leg (B) into the Rsf Arm (D), insert the Bolt (K), turn the L-Allen Key (L) to tighten them.


**3**

Attach the Back Frame (E) into the Lsf Arm (C) and Rsf Arm (D), insert the Bolt (K) and the Bolt (J), turn the L-Allen Key (L) to tighten them.




4

Attach Rail (F) to the Lsf Arm (C) and the Rsf Arm (D), Left Arm Post Leg (A) & Right Arm Post Leg (B), insert the Bolt (K), turn the L-Allen Key (L) to tighten them.




5

Insert the Slat Connector (H) to the both sides of Slat (G), press the Slat (G) into the correct place.




6

Attached the Slat (G) to rails, put the Slat Connectors (H) into the correct place and press them down.



7

Make the Spacer (I) to connect two slats as below instruction.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.