



Step 1

- Fold template where indicated.
- Position template on the door edge at desired latch height (suggested height is 970mm from floor).
- Firmly hold template and mark latch height and handle fixing holes at 60mm backset (refer to template).
- Measure door thickness and mark centre.
- Drill 25mm latch hole.
- Note:** it is important to drill this hole separately.
- Drill one 54mm hole through door face at required backset as marked on template.




Step 2

- Mark and chisel door edge for latch face plate to a recess of 2mm or until flush with door. Use latch face plate as a template.
- Pre-drill wood screw holes with suitable drill size.
- Insert latch support within the drilled 54mm hole.
- Insert latch and fasten with wood screws provided.




Step 3

- Attach QuickFix furniture with preinstalled studs and screws.



Step 4

- Remove rose cover from opposite lever.
- Align holes with screw heads and install furniture.



NOTE: Carefully follow these instructions when installing. Screws to be hand tightened to a recommended 2.5Nm torque.

Continued on next page



Mark centre-line
of latch hole

Mark centre-line
of latch hole

FOLD HERE

Fit here on door edge

Fit here on door edge

BACKSET 60mm

54mm hole – refer Step 1.



ALLEGION™


Allegion (New Zealand) Limited
 Freephone 0800 477 869
 Email nzinfo@allegion.com
www.allegion.co.nz



07/2025
 PDSC0064


Step 5

- Rotate bezel to lock in place and tighten screws.




Step 6

- Measure Ø8mm either side of centre mark, drill Ø25x15mm hole.
- Use strike as a guide to mark and chisel recess, allowing space behind strike plate for dust box.
- Insert dust box, drill holes and screw strike in place.




Step 7

- Fit rose cover.



Step 8 (For privacy function only)

- Depress latchbolt (A) and screw the privacy pin tightly into the hole on the internal side of the door. Ensure this is completely tightened, then release latchbolt.



Tip: To use, press the privacy pin inward and rotate the lever to release.

NOTE: Carefully follow these instructions when installing. Screws to be hand tightened to a recommended 2.5Nm torque.



Mark centre-line of latch hole

Mark centre-line of latch hole

FOLD HERE

Fit here on door edge

Fit here on door edge

BACKSET 60mm

54mm hole – refer Step 1.



ALLEGION™

Allegion (New Zealand) Limited
 Freephone 0800 477 869
 Email nzinfo@allegion.com
www.allegion.co.nz



07/2025
 PDSC0064