

Item # : BR6DODDDR

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 23/10/2020 (L)

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are: wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver is required for the assembly of this product .




- VII. Power tools should not be used to assemble this product.






- VIII. Drill may be needed for securing product to wall.

Parts List




Hardware List

A		Ø8x30mm	Wooden dowel	46 pcs
B		Ø8x50mm	Wooden dowel	1 pc
C		Ø6x35mm	Cam bolt	75 pcs
D		Ø6x64mm	Cam bolt	1 pc
E		Ø15x11mm	Cam lock	47 pcs
F		Ø15x9mm	Cam lock	30 pcs
G		Ø30mm	Sticker	77 pcs
H			Handle	12 pcs
J		Ø4x10mm	Handle Bolt	24 pcs
K		Ø6x50mm	Screw	10 pcs
L			Plastic wedge	24 pcs
M		Ø3x17mm	Screw	24 pcs
N		M4	Hex Key	1 pc
P		Ø4x38mm	Screw	30 pcs
Q		Ø3x12mm	Screw	72 pcs
R			Velcro strap	2 pcs
S		Ø4x25mm	Screw	2 pcs
T			Nut	2 pcs
U		Ø4x12mm	Screw	2 pcs
V		Ø6x30mm	Wooden dowel	12 pcs
W		12"	Drawer slider	6 Sets

* Note: This piece comes preassembled for shipping purposes and must be disassembled to complete the desk assembly.


Hardware List

X



Glue tube



3 pcs



Philips head screwdriver required for assembly
(not included)



*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Insert wooden dowel (A) into parts (19,20,21) and insert wooden dowel (V) into part (29), wooden dowel (B) into part (20) , then secure cam bolt (C) into part (1),using cam lock (E) secure cam bolt (D) into part (20) with Philips head screwdriver as per diagram.

Step 2




Insert wooden dowel (A) into part (22) , then secure cam bolt (C) into part (23), using cam lock (E) secure part (23) into part (22) with Philips head screwdriver as per diagram.

Step 3




Using screw (K) attach part (8) to parts (21,22) with Hex key (N) as per diagram.

Step 4




Insert wooden dowel (A) into parts (12,13,14,15), then secure cam bolt (C) into parts (5,6,12,13,14,15) with Philips head screwdriver as per diagram.

Step 5





Insert wooden dowel (A) into parts (2,3,4,9,10,11) as per diagram.

Step 6




Pick up the slider arm (W) and separate the slide runner for the following Steps. Extend the slide runner all the way forward, press the plastic release lever of the slider arm up and pull the slide runner complete out .

Step 7





Using cam lock (E) secure parts (5,6) to part (2) and part (4) , then using screw (Q) attach drawer slider (W) to parts (2,4) with Philips head screwdriver as per diagram.

Step 8




Using screw (Q) attach drawer slider (W) to parts (3) with Philips head screwdriver as per diagram.

Step 9




Using cam lock (E) secure parts (12,13) to part (9) ,and parts (14,15) to part (11) with Philips head screwdriver as per diagram.

Step 10




Using screw (Q) attach drawer slider (W) to parts (9,11) with Philips head screwdriver as per diagram.

Step 11





Using screw (Q) attach drawer slider (W) to parts (10) with Philips head screwdriver as per diagram.

Step 12





Using screw (K) attach part (10) into parts (21,22) with Hex key (N) as per diagram.

Step 13




Attach part (20) into parts (9,13) ,then using Cam lock(E) secure part (20) to parts (9,13) with Philips head screwdriver as per diagram.

Step 14





Attach parts (21,22,23) into parts (9,12,13) ,and part (10) into part (20) ,then using Cam lock(E) secure parts (21,22,23) to parts (9,12,13) with Philips head screwdriver as per diagram.

Step 15





Put part (18) as per diagram.

Step 16





Using cam lock (E) secure part (19) to part (12) with Philips head screwdriver as per diagram.

Step 17




Attach part (20) into part (10) ,then using Cam lock(E) secure part (20) to part (10) with Philips head screwdriver as per diagram.

Step 18





Attach parts (11,14,15) into parts (19,20,21,22,23) , then using Cam lock(E) secure parts (11,14,15) to parts (19,20,21,22,23) with Philips head screwdriver as per diagram.

Step 19





Put part (18) as per diagram.

Step 20




Attach part (4) into part (1) , then using Cam lock(E) secure part (4) to part (1) with Philips head screwdriver as per diagram.

Step 21




Attach parts (2,3) into part (1) , then using Cam lock(E) secure parts (2,3) to part (1) with Philips head screwdriver as per diagram.

Step 22




Put part (16) as per diagram.

Step 23





Using screw (K) attach part (17) to parts (2,3,4) with Hex key (N) as per diagram.

Step 24




Secure cam bolt (C) into part (17) with Philips head screwdriver as per diagram.

Step 25




Attach part (17) into parts (9,10,11) , then using Cam lock(E) secure part (17) to parts (9,10,11) with Philips head screwdriver as per diagram.

Step 26



Using screw (M) secure plastic wedge (L) to parts (16,18) with Philips head screwdriver as per diagram.


Step 27



x 2

Using screw (Q) attach drawer slider (W) to parts (24,25), then using handle bolt (Y) secure handle (H) and secure cam bolt (C) into part (27) with Philips head screwdriver as per diagram.



Step 28



x 4



Using screw (Q) attach drawer slider (W) to parts (30,31) ,then using handle bolt (J) secure handle (H) and secure cam bolt (C) into part (7) with Philips head screwdriver as per diagram.

Step 29





Using screw (P) attach parts (24,25) to part (26) , parts (30,31) to part (32) with Philips head screwdriver as per diagram.

Step 30






Put part (28) as per diagram.

Step 31






Attach part (29) into part (26,32) ,and using screw (P) attach part (29) to parts (26,32) with Philips head screwdriver as per diagram.

Step 32





Using Cam lock(F) secure part (27) to parts (24,25,29) , part (7) to parts (29,30,31) with Philips head screwdriver as per diagram.

Step 33



Place sticker (G) cover the holes as per diagram.


Step 34



x 2


Insert the assembled drawers into the unit frame, extend the Ball Bearing Slide Tracks (W) on the pedestal Side Panel all the way forward .Then align the Slide Runners on the assembled drawers with the Slide Tracks and push the drawer carefully inside until it stops. Note : if the drawer does not go in smoothly, please take it out and repeat the step. If you need to remove the drawer, please pull the drawer all the way out,press or lift the plastic release lever and pull out the drawer and then re-assembled the drawer until it was going in smoothly .

Step 35



Position the assembled unit at the desired location ,if necessary adjust the floor leveler at the bottom of the support leg to level the unit .


Step 36



Using screw (U) attach Velcro strap (R) into part (1) with Philips head screwdriver as per diagram.


Step 37

WARNING



Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

Wall



Using screw (S) attach Velcro strap (R) into Nut (T) to wall with Philips head screwdriver as per diagram.

Step 38



Final Assembly