



| | | | | |
|---|--|---|---|---|
| <p>Record your model number.</p> | <p>⚠ CAUTION: Risk of personal injury. Do not use this product as a grab or support bar when entering or exiting the bath. The product is not designed to support weight.</p> | <p>NOTICE: Adequate floor support is required. Standard 2x6 lumber is NOT sufficient for this application. NOTE: Concrete can be used as the floor support. Follow all local plumbing and building codes.</p> | <p>1 Roughing-In</p> | <p>2 Roughing-In</p> |
| <p>3 Construct a wood support under the floor according to the roughing-in dimensions.</p> | <p>4 Use the base to mark the mounting holes on the wood support.</p> | <p>5 Using a 3/16" drill bit (provided), drill 1-1/2" (38 mm) deep holes at the marked locations. Use a masonry bit if drilling into concrete.</p> | <p>6 Secure the base to the support with the screws and washers.</p> | <p>7 Apply sealant tape to the supply pipes and thread into the base. The cold supply goes over the notch.</p> |
| <p>8 Insert the plug into the base. Turn on the water and check for leaks.</p> | <p>9 Turn off the water and secure the guard onto the base.</p> | <p>10 Finish the floor, leaving a 3" (76 mm) diameter hole for the guard.</p> | <p>11 Cut the guard flush with the finished floor.</p> | <p>12 Remove the plug from the base.</p> |
| <p>13 Secure the faucet to the base with the screws and washers.</p> | <p>14 Install the check valve and handshower hose to the diverter.</p> | <p>15 Turn on the water to flush debris from the hose.</p> | <p>16 Install the handshower to the hose.</p> | <p>17 Remove the aerator. Run water to remove debris. Reinstall the aerator.</p> |