


Item # : AF18CRFST

Assembly Instructions




Walker Edison®

Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com

Revised 15/04/2019


General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The main type of hardware used to assemble this product are: bolts and screws.
- V. Power tools should not be used to assemble this product.





- VI. Drill may be needed for securing product to wall.


Parts List



Hardware List

A		Ø8x30mm	Wooden dowel	19 pcs
B		Ø8x32mm	Cam bolt	8 pcs
C		Ø15x11mm	Cam lock	8 pcs
D		Ø30mm	Sticker	8 pcs
E		Ø3.5x12mm	Screw	12 pcs
F		Ø4x38mm	Screw	10 pcs
G		Ø6x12mm	Bolt	16 pcs
H			Handle	1 pc
J		Ø4x22mm	Bolt	2 pcs
K		M4	Hex key	1 pc
L			Drawer slider	1 set






*Note: This piece comes preassembled for shipping purposes and must be disassembled to complete assembly



Philips head screwdriver required for assembly
(not included)


*The hardware quantities listed above are required for proper assembly.
Some extra hardware may also have been included.*

Step 1




Separate the slider arm (L) using trigger , using screw (E) secure slider arm (L) to parts (3,4,11,12) as per diagram.

Step 2




Insert wooden dowel (A) to parts (3,4,5,6) and insert cam bolt (B) to part (1).

Step 3




Attach part (5) to part (6) as per diagram.

Step 4





Attached parts (3,4) to parts (5,6) as per diagram.

Step 5




Using screw (F) secure part (2) to parts (3,4) .

Step 6




Using cam lock (C) secure part (1) to parts (3,4) as per diagram.

Step 7






Using bolt (G) secure part (7) to part (20 with hex key (K) ,then using sticker (D) cover the hole as per diagram.

Step 8




Using screw (F) secure parts (11,12) to part (10), using bolt (J) secure handle to part (9),and using cam bolt (B) secure part (9) with Philips head screw driver as per diagram.

Step 9



Put part (8) to parts (10,11,12) , then attach part (9) to parts (11,12) as per diagram.

Step 10



Step 11



Final Assembly