


Item # : BR60BRX6D

Assembly Instructions




Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 11/2022 V-1

General Assembly Guidelines


- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The three main types of hardware used to assemble this product are wood dowels, screws and bolts.
- V. The provided glue is to secure wood dowels in place. When first inserting dowels, locate the appropriate hole for the dowel, place a small amount of glue in the hole and insert the dowel. Wipe away excess glue immediately.




In future assembly steps when dowels are necessary to attach assembly parts together, place a small amount of glue on the end of the dowel before attaching parts together. Wipe away excess glue immediately.



- VI. A Phillips head screwdriver and hammer is required for the assembly of this product.



- VII. Power tools should not be used to assemble this product.









VIII. Maintenance Guide

To maintain long term performance and easy gliding of your solid wood drawers, we recommend applying wax to the wooden guide rails.


1. Bee's wax is recommended or Paraffin wax from a standard candle can be used.
2. Apply the wax by rubbing it on the wooden guide rails where there is wood-on-wood contact when opening and closing the drawer. (Wax should be room temperature, do not melt the wax onto the wood)
3. Wax should be applied every few months for the first year and then only when needed after that to keep the drawers sliding smoothly.

Hardware List

| | | | | |
|---|-------------------------------------------------------------------------------------|-----------|-------------|--------|
| A |  | Ø8*30mm | Wood dowel | 54 pcs |
| B |  | Ø8*20mm | Wood dowel | 24 pcs |
| C |  | Ø4,0*25mm | Screw | 24 pcs |
| D |  | Ø3,5*30mm | Screw | 50 pcs |
| E |  | Ø4,0*40mm | Screw | 09 pcs |
| F |  | Ø10*10 | Nail | 36 pcs |
| G |  | Ø7*60mm | Screw | 05 pcs |
| H |  | 4mm | Hex Key | 01 pcs |
| I |  | | Glue | 01 pcs |
| J |  | 1476mm | "H" Profile | 01 pc |
| K |  | | Wall anchor | 01 pc |
| L |  | | Washer | 02 pc |
| M |  | | Ø6mm | 01 pc |
| N |  | Ø4,5*30mm | Screw | 24 pcs |




Tape measure and hammer recommended for assembly (not included)





Philips head screwdriver required for assembly (not included)

The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.

Parts List





The side drawer with WARNING LABEL, should be mounted in highest drawer.




| Part# | Description | Qty |
|-------|------------------------------|-----|
| 1 | Top panel | 01 |
| 2 | Right side panel | 01 |
| 3 | Left side panel | 01 |
| 4 | Bottom panel | 01 |
| 7 | Back panel | 02 |
| 8 | Foot | 04 |
| 9 | Narrow drawer runner | 06 |
| 10 | Upper and Lower drawer front | 04 |
| 11 | Left drawer side | 06 |

| Part# | Description | Qty |
|-------|---------------------|-----|
| 12 | Right drawer side | 06 |
| 13 | Drawer bottom | 06 |
| 14 | Drawer back | 06 |
| 15 | Middle drawer front | 02 |
| 16 | Drawer handle | 12 |
| 18 | Center Foot | 01 |
| 21 | Division | 01 |
| 22 | Large drawer runner | 06 |

Step 1




Attention to the
dowel size:
Ø8*20mm



| | | |
|---|---------------------------------------------------------------------------------------------|----|
| B |  Ø8*20mm | 24 |
| I |  | 01 |

Insert wood dowel (B) and glue (I) into part (9).



Step 2



| | | |
|---|---------------------------------------------------------------------------------------------|----|
| A |  Ø8*30mm | 42 |
| I |  | 01 |



Insert wood dowel (A) and glue (I)
into parts (2, 3, 11, 12, 21).

Step 2




Attach part (4) to parts (2,3,21) with screws (E)

Step 3



Use screw (G) and hex key (H) to attach the feet to the body.


Step 4



Use screw (D) to attach part (1) to body

| | | |
|---|--|-----------|
| D | | 09 |
| | | Ø3,5*30mm |


Step 5



| | | |
|---|--|--------|
| F | | 36 |
| | | Ø10*10 |
| J | | 01 |
| | | 1476mm |

Secure back panel (7) with part (J) to body with nails (F)


Step 6



| | | |
|-----------|-------------------------------------------------------------------------------------|----|
| C |  | 24 |
| Ø4,0*25mm | | |

Use the screw (C) to attach the parts (9) to the parts (2,3)
Use the screw (C) to secure the parts (22) to the part (21)
NOTE: The extra holes in the part (9,22) must be top


Step 7



Insert wood dowel (A) into the front hole
in the drawer rails (9,22)



| | | |
|---------|---------------------------------------------------------------------------------------|----|
| A |  | 12 |
| Ø8*30mm | | |

Step 8




Attach parts (16) to part (10), with screws(N), using the predrilled holes.

Attach parts (11,12) to part (10) and attach with screw (D), insert panel (13) into groves and secure part (14) with screws(D).


| | | | |
|---|-------------------------------------------------------------------------------------|-----------|----|
| D |  | Ø3,5*30mm | 32 |
| N |  | Ø4,5*30mm | 16 |

Step 9





Attach parts (16) to part (15), with screws(N), using the predrilled holes.

Attach parts (11,12) to part (15), insert panel (13) into groves and secure part (14) with screws(D).

| | | | |
|---|-------------------------------------------------------------------------------------|-----------|----|
| D |  | Ø3,5*30mm | 32 |
| N |  | Ø4,5*30mm | 16 |


Step 10




WARNING
Children have died from furniture tipover. To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- NEVER put a TV on this product.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!




Insert wood dowel (A) on the inside of all drawers while drawers is inside the unit. Make sure dowel is flush with panel.



WARNING


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.



1st



Attach part (K) with Screw (D) and Washer (L), in the frame of superior panel unit.




2nd

With drilling machine make one hole in the wall, Insert part (M) in the hole.

Secure part (K) with Screw (D) and Washer (L), in the wall.



Wall



| | | |
|---|-----------|----|
| D | Ø3,5*30mm | 02 |
| K | | 01 |
| L | | 02 |
| M | | 01 |

Name and address information for the manufacturer responsible for the anti-tip hardware and date of production can be found on the label on the back of the furniture.