8 3 Note: Applicable Rack Configurations Condensate piping shall be CPVC or 2 x TRW02CU PVC material and shall not be smaller 2 x TRS02CUIL than the drain connection on the 2 x TSR02CUILW appliance. D 2 x TRS04CU Low Temp Supply Components of the condensate TRS04CU + TRS03CU drainage shall be CPVC or PVC material. All components shall be **Optional Tank** selected for the pressure and **Bypass** temperature rating of the installation. For this application: High Temp Supply Do not use electronic cascade controls Where the drain pipes from more than one unit are manifolded together for with storage recovery system. condensate drainage, the pipe or tubing Reference mixing valve manufacturer shall be sized in accordance with an instructions regarding recirculation. approved method as dictated by local codes. Storage Tank Storage Tank Condensate must be disposed of (No Burner or (No Burner or according to local codes. Heating Element) Heating Element) Circulation Pump should be controlled Submersible Submersible Aquastat (Set at Aquastat (Set at by an Aquastat or Combination 20F below Rinnai 20F below Rinnai Condensate Drain Line Aguastat and Timer. Aguastat should be Temperature Temperature set to a 10-20F differential of water Settina) Setting) heater set temperature. Circulation Pump should be sized to maintain circulation loop temperature. Gas Supply Circulation Pump should be sized to overcome the pressure loss through the Pump / Aquastat tankless water heater, supply, and Controller **Optional Pump** return plumbing. Reference the Rinnai **Bypass** Hot Water System Design Manual for circulation pump sizing guidelines. Cold Water Supply **Aquastat Connection** Recovery and Circulation Pumps should Low Temp Return be of bronze or stainless construction. **Aquastat Connection** Reference the Rinnai Hot Water System High Temp Return Design Manual for recovery pump sizing guidelines. THIRD ANGLE PROJECTION This is not an engineering drawing; it is intended only as a guide and not NAME DATE Rinnai. UNLESS OTHERWISE SPECIFIED as a replacement for professional engineering project drawings. This Reference the Common Vent DRAWN TOLERANCES: Sheet Metal X.XX = ±0.030 11.16.2018 drawing is not intended to describe a complete system. It is up to the Installation Manual for common vent TITLE: contractor or engineer to determine the necessary components and CHECKED SH 12.15.2018 options. Air intake manifold shown for configuration of the particular system to be installed. The drawing does Systems Design Manual RINNAI AMERICA CORPORATION ENG APPR. 12.15.2018 not imply compliance with local building code requirements. It is the direct vent installations only. 103 INTERNATIONAL DRIVE Tankless Rack System PEACHTREE CITY, GA 30269 responsibility of the engineer or contractor to ensure that the installation is COMMENTS: Angle = $\pm 0.010^{\circ}$ 1-800-621-9419 in accordance with all local building codes. Confer with local building 4-8 Unit Back2Back InLine w 2 Storage Tanks INTERPRET GEOMETRIC PROPRIETARY AND CONFIDENTIAL officials before installation. TOLERANCING PER: THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF RINNAI AMERICA. ANY REPRODUCTIONIN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF RINNAI AMERICA IS PROHIBITED. SIZE DWG. NO. MATERIAL TRSCU-IL4BB8-BC2 FINISH

8

6

DO NOT SCALE DRAWING

2

SCALE: NTS WEIGHT:

SHEET 1 OF 1